

This is a digital copy of a book that was preserved for generations on library shelves before it was carefully scanned by Google as part of a project to make the world's books discoverable online.

It has survived long enough for the copyright to expire and the book to enter the public domain. A public domain book is one that was never subject to copyright or whose legal copyright term has expired. Whether a book is in the public domain may vary country to country. Public domain books are our gateways to the past, representing a wealth of history, culture and knowledge that's often difficult to discover.

Marks, notations and other marginalia present in the original volume will appear in this file - a reminder of this book's long journey from the publisher to a library and finally to you.

Usage guidelines


Google is proud to partner with libraries to digitize public domain materials and make them widely accessible. Public domain books belong to the public and we are merely their custodians. Nevertheless, this work is expensive, so in order to keep providing this resource, we have taken steps to prevent abuse by commercial parties, including placing technical restrictions on automated querying.

We also ask that you:

- + Make non-commercial use of the files We designed Google Book Search for use by individuals, and we request that you use these files for personal, non-commercial purposes.
- + Refrain from automated querying Do not send automated queries of any sort to Google's system: If you are conducting research on machine translation, optical character recognition or other areas where access to a large amount of text is helpful, please contact us. We encourage the use of public domain materials for these purposes and may be able to help.
- + Maintain attribution The Google "watermark" you see on each file is essential for informing people about this project and helping them find additional materials through Google Book Search. Please do not remove it.
- + Keep it legal Whatever your use, remember that you are responsible for ensuring that what you are doing is legal. Do not assume that just because we believe a book is in the public domain for users in the United States, that the work is also in the public domain for users in other countries. Whether a book is still in copyright varies from country to country, and we can't offer guidance on whether any specific use of any specific book is allowed. Please do not assume that a book's appearance in Google Book Search means it can be used in any manner anywhere in the world. Copyright infringement liability can be quite severe.

About Google Book Search

Google's mission is to organize the world's information and to make it universally accessible and useful. Google Book Search helps readers discover the world's books while helping authors and publishers reach new audiences. You can search through the full text of this book on the web at http://books.google.com/



The Automobile Handbook

A Manual of Practical Information for Automobile Owners, Repair Men and Schools

L. ELLIOTT BROOKES

Revised and Enlarged By HAROLD P. MANLY

Author of "Automobile Starting and Lighting."

Subjects Arranged in Alphabetical Order and Indexed

FULLY ILLUSTRATED

CHICAGO FREDERICK J. DRAKE & CO. Publishers Copyright 1918 and 1916
By FREDERICK J. DRAKE & CO.
Copyright, 1905, 1907, 1910 and 1913
By FREDERICK J. DRAKE & CO.,
CHICAGO.

Preface to Fifth Edition.

The reason for the present complete revision of Brookes' Automobile Handbook is found in the automobile industry itself, in the radical changes and remarkable developments that have taken place. The new principles, new types of construction and the changes in operating conditions have affected every part of the car. For this reason it has been considered advisable, not only to supplement existing information with descriptions of new products, but to treat every subject presented from the standpoint of present-day ideas and developments so that the user may not be confused by statements that apparently conflict, as would be the case if the revision had ended with the addition of new data.

A glance at present designs discloses many changes, among them being the decrease in cylinder diameters and the increase in number of cylinders from four and six to eight and twelve; the growing popularity and importance of the sliding sleeve engine; the modern methods of battery ignition applied to high speed engines; the development and adoption of vacuum fuel feed, and many other details of equal importance.

The universal use of electric lighting and engine starting devices has made this subject of

importance second to none, and the present edition therefore covers the details of construction and operation of all existing types and makes that are in common use. With the use of the electric generating system operated from the car's engine has come the electric gear shift; and along similar lines, though independent in conception, the magnetic transmission.

Due to the fact that, for so many years, Brookes' Automobile Handbook has been the recognized authority in this field, the arrangement of subject matter has not been altered and nothing has been omitted that caused the preceding editions to attain their popularity. The size of the volume has been kept within reasonable limits because of the fact that the information given has been presented in the smallest possible space through the free use of illustrations and the formulation of definite rules for care and adjustment of devices used for ignition and carburetion.

An examination of the pages will show that no subject of importance to owners or repairmen has been omitted, while details for the proper upkeep and care of each component of the modern gasoline automobile have been given. Suggestions from users will be welcomed to the end that the publishers may always keep the value of the Handbook up to the high mark attained in the past.

INTRODUCTION

Progress in the automobile industry in the United States during the past ten years has been phenomenal. The mechanical propulsion of a wheeled vehicle along an ordinary road is not by any means a new idea. History tells us that speculations upon the possible road use of "fire, and steam engines" were made by Roger Bacon (1214-1294), and in the year 1619 a patent was granted in England to Ramsay, which had as a part of its subject "drawing carts without horses." Many attempts were made from that time on to perfect a self-propelling road vehicle, using steam as the propelling force, but it was not until the end of the year 1883 that Delamare-Debouttville constructed what is thought to be the first gas tricycle which actually ran on a public road. The general employment of gasoline motors is due to two Frenchmen, Levassor, and Panhard, who in 1889 exhibited in Paris a tram car having a Daimler motor. Since then the development of the gasoline motor car has been remarkable, due no doubt to the fact that some of the best engineering talent in the world has been, and is at present being directed toward the perfection of the various types of automobiles, and it is entirely within the bounds of reason to expect that a machine requiring so high a grade of talent for its design and construction, should in its operation be under the care of a skilled and reliable chauffeur, one who not only understands the principles of operation of each and all of the various parts which go to make up the whole, but who also is competent in case of minor accidents on the road, to make such repairs as will enable him to proceed. He also should be able to make such adjustments, and give the machine such care as to reduce the expense of maintenance to a minimum. It is with a view of assisting owners and drivers of automobiles, in fact all who are in any way interested in a study of this remarkable, and at the same time most useful machine, that the Automobile Hand Book has been rewritten and revised, thus bringing it strictly up to date, and in touch with modern practice in the art of automobiling. While a

considerable portion of the subject matter found i former editions of the book has been retained for the reason that it is standard, by far the larger portion of the volume is new matter, and embodies the most receimprovements in automobiles, together with instruction concerning their care and operation. Each part of the machine is thoroughly treated upon, and its construction and the principles governing its operation are explained and illustrated in detail. While the gasolismotor with its various accessories naturally occupie the major portion of the book, still a considerab space is devoted to steam, and electric motor car special attention is given to ignition mechanism in cluding the various types of carbureters, magneto etc., all being clearly described and illustrated. Tran mission apparatus of all kinds is dealt with in detail wheel construction receives a large share of attention and the important subject of tires is freely discussed.

A large space is given to repair work in the sho and garage. As the subject of state license laws contemplating the appearance of the chauffeur before a examining board is one in which all motorists an vitally interested, this book will prove to be a reliable and trustworthy guide to all persons taking suc examinations.

Note—The author gratefully acknowledges his in debtedness to the following named gentlemen, consulting engineers, and authors of standard works of engineering subjects:

Oscar C. Schmidt, consulting editor American Tex Book Co., author of Practical Treatise on Automobiles Paul N. Hasluck, author of Construction of Moder Motor Cars.

The International Text Book Company, Scranton.

The Automobile Handbook.

Acetylene Gas. The gas used in gas lamps is generated by water, in minute quantities, dropping on acetylene (carbide of calcium); the gas thus formed passes from the generating chamber into the body of the lamp and is consumed at the lava tips, which are placed in front of a highly polished mirror. The generators in some cases are separated from the lamp itself and placed on the dashboard, or under the hood, a rubber hose conveying the gas to the lamp.

The interior of the carbide chamber or basket being more or less in contact with the water distribution apparatus, the parts of both apparatus are liable to clogging by the formation of lime residue in the generation of gas. If this residue is allowed to collect, it will have to be removed with a chisel, which is a ticklish operation in a light construction like that of a generator, especially around the water valve or its outlet. Acids are sometimes used to remove the deposit, but as they eat the metal, their use should be prohibited. The basket and pot should be thoroughly washed out after each run

with water, the water outlets being cleaned with special brushes, when these are obtainable, or by wires, removing all traces of lime. The water valve should be scraped and tested to see whether it seats properly, care being taken not to damage the valve or its seat in so doing. While the valve is dismounted for cleaning it would be well to see that its stem is straight, and that it works with some ease in the threaded portion attached to the water chamber. The gas valves should be cleaned and should seat snugly, so that there will be no leakage past them. This applies also to the gas valves on the lamps.

The best position for the generator is on the running-board just back of the change-gear quadrant, and sufficiently far out from the frame to allow a free circulation of air all around it. The generator will keep cool in this position and will perform its work to the best advantage when properly cooled.

The system of acetylene gas lighting that is generally used on cars having this source of illumination is that making use of tanks in which the gas is stored under compression. These tanks are designed to hold 40, 60 or 100 cubic feet of gas and from them the illuminant is carried to the various lamps through tubing. Attachments are furnished by means of which the lamps may be lighted, dimmed or extinguished from valves and buttons located on the dash or cowl of the car.

Acetylene Lamp System—Care of. As there is little night running during the winter months, the acetylene lighting system is more or less neglected, the generator being left with stale or partially used carbide in the chamber, and the residue being allowed to clog up the water port and the waste ports. The rubber lamp connections and gas-bag suffer also by deterioration as well as the burners and gas valves. For the proper maintenance of the system, strict cleanliness should be maintained at all times, and the various parts should be examined and replaced from time to time as necessary. The results of neglect are seen every spring in lime deposits which have to be removed by means of a cold chisel, in porous connections and in clogged burners which resist the cleaning wire and necessitate the scraping of the burners. By following the accompanying directions, the automobilist can depend on having his lighting system in good shape whenever he desires to use it.

Acid Solutions. The electrolyte, or solution used in storage battery cells, is made by pouring sulphuric acid into distilled water until the specific gravity becomes 1.25. The solution becomes extremely warm and should not be used until its temperature is about 60 degrees.

Active Coil, or Conductor, A coil, or conductor, conveying a current of electricity.

Adams Revolving Cylinder Motor. The Adams motor rated at 50 horse power has a five

cylinder engine with a bore and stroke of $5\frac{1}{2}$ and 5 inches. In this motor the crankshaft is mounted vertically and has but one throw, the same as ordinarily used for a single-cylinder engine. This crankshaft is stationary—it never revolves, but the five cylinders revolve around it, as does the front wheel of a motor car on the steering spindle. The car is without a radiator, being an air-cooled machine; as the motor cylinders revolve, a cooling fan is not needed. It is without a muffler, each cylinder exhausting directly into a box which incloses the motor. The motor is directly above the transmission set, and as the motor is without a flywheel of any sort, it has been necessary for the designer to carry the double cone clutch within the selective gear set. The drive from the revolving cylinders to the gear-set is through a bevel gear attached to the base of the revolving crank case, and which meshes with a bevel gear on one of the transverse shafts of the transmission. From the transmission to the rear axle, a chain drive is employed. This car is without a float feed carbureter, but uses instead, a pump to maintain a gasoline level in a chamber in which a spraying nozzle and an air valve complete the carbureter. Instead of controlling the motor speed by advancing or retarding the spark, and opening and closing the throttle, it is done by controlling the length of time each intake valve is This motor has but one cam to open and

of the ten valves. This cam being in two parts, it is possible to shift one, thereby varying the length of opening given a valve, and allowing a part of the mixture drawn into a cylinder to escape during a compression stroke, so that the explosive pressure can be varied from 90 lbs. to 0, and the power of the motor, and its speed




Fig. 1 Sectional View of Adams Motor

correspondingly varied. There is no branching manifold to convey the mixture to the cylinders, neither is there an exhaust manifold.

In Fig. 1 is a sectional view of the motor with its five cylinders designated respectively 1, 2, 3, 4 and 5, with five pistons shown in relative position. The crankshaft A has its one offset B. As each cylinder makes, in unison with the

other four, two complete revolutions, it passes through the four cycles of operation common to any four-cycle engine—inspiration, compression, explosion, exhaust. No. 4 cylinder is shown at the end of the out stroke, and the other four at different parts of the stroke; and as each in succession occupies the position of




Fig. 2 Cam Diagram—Adams Revolving Cylinder Motor

No. 4, its piston will be at the end of the out stroke. When diametrically opposite to No. 4 they will be at the inner end of the stroke. Thus, as the five cylinders bolted firmly together to a hublike crankcase revolve, the pistons reciprocate in the cylinders, thus performing in perfect sequence, the four functions of cycling. The valves are located in the cylinder

heads and opened by rocker arms with push rods paralleling the cylinders on their lower sides. One diagram illustrates the single cam construction and valve operation. On the lower end of the crankshaft is the two-part cam C, CI—Fig. 2. The latter, shown in dotted line, is the movable half for controlling the intake valve period of opening. Both parts of the cam are stationary. On each of the five cylinders is a push rod P, the inner end of which has a peculiar foot P2 pivoted on the crankcase with the curve portion bearing upon the cam, and the short straight arm connected with the push rod P. As the cylinder revolves, the rounded foot follows the contour of the cam, which has been designed so that the four cycles follow one another in order as they do in a fourcycle vertical engine.

The principles of construction and operation of the motor just described are similar to those found in aeronautical work, such as the Gnome and other types of revolving motors. In all of these types the crankshaft is stationary and the cylinder unit revolves. The power for driving is secured by connections on the cylinders. As a general rule, these revolving motors are started from rest by revolving the propeller blades by hand until the first firing stroke is secured. The valve mechanism will differ according to the make of motor. In many cases the fuel mixture is introduced through hollow shafts and castings leading to the cylinders.

Air. Air consists, by weight, of oxygen 77 parts and nitrogen 23 parts; by volume, of 21 parts oxygen and 79 parts nitrogen. One pound of air at atmospheric pressure, and 70 degrees. Fahr., occupies 13.34 cubic feet of space. One cubic foot of air weighs 1 1-7 ounces.

TABLE 1.

PROPERTIES OF COMPRESSED AIR

| Comp. in Atmos pheres. | *Mean Pressure. | Temp. in, Degrees Fah. | Gauge Pres- sure. | *Absolute Pressure. | *Isother- mal Pres- sure. |
|------------------------------|--------------------|------------------------------|-------------------------|------------------------|---------------------------------|
| 1 | 0 | 60 | 0 | 14.7 | |
| 1.68 | 7.62 | 145 | 10 | 24.7 | 30.39 |
| 2.02 | 10.33 | 178 | 15 | 29.7 | 39.34 |
| 2.36 | 12.62 | 207 | 20 | 34.7 | 48.91 |
| 2.70 | 14.59 | 234 | 25 | 39.7 | 59.05 |
| 3.04 | 16.34 | 252 | 30 | 44.7 | 69.72 |
| 3.38 | 17.92 | 281 | 35 | 49.7 | 80.87 |
| 3.72 | 19.32 | i 302 [| 40 | 54.7 | 92.49 |
| 4.06 | 20.57 | 324 | 45 Ì | 59.7 | 104.53 |
| 4.40 | 21.69 | 339 | 50 | 64.7 | 116.99 |
| 4.74 | 22.76 | 357 | 53 | 69.7 | 129.84 |
| 5.08 | 23.78 | 375 | 60 | 74.7 | 143.05 |
| 5.42 | 24.75 | 389 | 65 | 79.7 | 156.64 |
| 5.76 | 25.67 | 405 | 70 | 84.7 | 170.58 |
| 6.10 | 26.55 | 420 | 7 5 | 89.7 | 184.83 |

^{*}In pounds per square inch.

Air Properties of Compressed. Table 1 gives the Mean pressure, Temperature in degrees Fahr., Gauge pressure, Absolute pressure and the Isothermal or heat pressure of air under compression of from 1 to 6.10 atmospheres.

As energy in the form of power must be used to compress air to any desired pressure, so is energy in the form of latent or stored heat given up by the air during the operation of compression. This heat consequently increases the pressure resulting from the compression,

but not directly in proportion to the degree of compression in atmospheres.

This increase of pressure above the Adiabatic or calculated pressure is known as the Isothermal or heat-pressure. As the values of this pressure cannot be calculated by the use of ordinary mathematics, but involve the use of logarithms, Table 1 gives these values for each degree of compression given.

Many persons who are not familiar with the properties of gases, estimate the pressure resulting from the compression to a given number of atmospheres, as the number of atmospheres multiplied by the atmospheric pressure, which at sea level is taken as 14.7 pounds per square inch.

This assumption is erroneous and will often lead to grievous mistakes in motor design, generally giving too much compression, which results in premature ignition, commonly known as backfiring. Such methods of calculation would be true if the air, after compression, was stored in a reservoir and allowed to cool, but under no other conditions.

Air, Relation of to Gasoline. Owing to the fact that automobile gasoline is composed of various percentages of the several available fractions of hydrocarbon distillates, it is not possible to fix an exact basis for the relative proportions of air to fuel. However, the average carbureter is capable of altering the ratio of air to fuel over broad ranges, and it is not necessary to know the exact ratio in order to

attain the best results. But it is necessary to approximate an average ratio as nearly as possible in designing and adjusting carbureters in order to allow for these variations up and down.

The mixture becomes explosive when 10,000 volumes of air dilute one volume of gasoline, but the best results follow when the ratio is one volume of liquid gasoline to 8,000 volumes of air. With one of gasoline to 3,500 of air the mixture is non-explosive.

The proper proportions, from a theoretical standpoint, are not always best for practical use because a mixture slightly weaker than the one found by calculation is more economical in the use of gasoline. Such a mixture, of course, reduces the power slightly, but the proportion of power lost is much less than the proportion of gasoline saved. Because of the differences in speed of the mixture and the differences in the volume being admitted to the engine, it is almost impossible to secure a proportion that will be uniformly satisfactory over a range of all engine speeds. A larger volume of mixture, at a slow speed, may be required in ascending a hill at ten miles per hour than in traveling on a level road at three times this speed. In the latter case, the velocity of the mixture will, however, be much greater. It is best to secure a mixture that will give satisfactory results from the standpoint of power at low and medium speeds rather than at high.

Air, Relation of in Gasoline Mixture. Gasoline is a somewhat uncertain mechanical mixture of several hydrocarbon (fractional) distillates, in which the compound "hexane" is supposed to be the major portion. This compound answers to the formula C_6 H_{14} , the products of combustion of which will be $CO_2 + CO + H_2O_4$, in which CO will not be found if the combustion is complete. A final expression of complete combustion will be as follows:

$$2 C_6 H_{14} \times 19 O_2 = 12 C O_2 + 14 H_2 O.$$

Taking into account the atomic weight of the elements, the volume of air required in the complete combustion of 1 pound of hexane may be set down as follows—atomic weight of the elements involved:

| Carbon (C) | 12 |
|--------------|--------|
| Hydrogen (H) | 1 |
| Oxygen (0) | 16 |

The molecular weight of $C_8 H_{14} = 6 \times 12 + 14 \times 1 = 86$; the required oxygen will weigh (molecular) $19 \times 16 = 304$; the ratio of the compound hexane, then, to the combining oxygen will be

Considering 1 pound of hexane, the weight of oxygen required for its complete combustion will be equal to the ratio as above given, i.e., 3.54 pounds, nearly.

Since the oxygen is taken from the air, it is

necessary to consider dry air in the attempt to determine as to the weight of the same. This air, under a pressure of 1 atmosphere, and at a temperature of 60 degrees Fahrenheit contains 0.23 pounds of oxygen, hence the required air=

$$\frac{3.54}{---} = 15.39$$
, in pounds. .23

Air Resistance, Horsepower Required to Overcome. The power required to move a plane surface, such as the vertical projection of an automobile, against the air, does not become of much importance until the car attains a speed of 10 to 12 miles per hour, when it becomes an important factor.

The horsepower required to propel an automobile against the resistance of the air may be approximately calculated by the following formula. Let V be the velocity of the car in feet per second, and A the projected area of the front of the car in square feet—this may be assumed as the height from the frame to the top of the body multiplied by the width of the seat at the floor line of the car—let H.P. be the horsepower required to overcome the air resistance, then

$$H.P. = \frac{V^3 \times A}{240,000}$$

To simplify the use of the above formula, Table 2 gives speeds in miles per hour corresponding to their respective velocities in feet per second and also cubes of velocities in feet per second.

TABLE 2.

CUBES OF VELOCITIES IN FEET PER SECOND.

| Miles per Hour of Car. | Feet per Second. | Cube of Velocity in Ft. per Second. | Miles per Hour of Car. | | Cube of Velocity in Ft. 1 er Second, |
|------------------------------|---------------------|--|------------------------------|----|---|
| 10.2 | 15 | 3,375 | 34.0 | 50 | 125,000 |
| 13.6 | 20 | 8,000 | 40.9 | 60 | 216,000 |
| 17.2 | 25 | 15,625 | 47.7 | 70 | 343,000 |
| 20.4 | 30 | 27,000 | 54.4 | 80 | 512,000 |
| 27.2 | 40 | 64,000 | 61.3 | 90 | 729,000 |

To ascertain approximately the horsepower that will be necessary to drive a car against a wind of known velocity, the speed of the car must be added to that of the wind, and the required horsepower may be found either by use of the formula given or by reference to Table 3, which gives the horsepower per square foot of projected surface required to propel a car against the resistance of the air, with varying speeds in miles per hour or velocities in feet per minute.

TABLE 3.

HORSEPOWER REQUIRED PER SQUARE FOOT OF SURFACE, TO MOVE
A CAR AGAINST AIR RESISTANCE.

| Miles per Hour of Car. | Feet per Second. | Horse- power per Square Foot of Surface. | Miles per Hour of Car. | Feet per Second. | Horse- power per Square Foot of Surface. |
|------------------------------|---------------------|--|------------------------------|---------------------|--|
| .10 15 | 14.7 | 0.013 | 40 | 58.7 | 0.84 |
| 15 | 22.0 | 0.44 | 50 | 73.3 | 1.64 |
| 20 | 24.6 | 0.105 | 60 | 87.9 | 2.83 |
| 25 | 36.7 | 0.205 | 80 | 117.3 | 6.72 |
| $\overline{30}$ | 44.0 | 0.354 | 100 | 146.6 | 13.12 |

The horsepower given by the formula and Table 3 simply refers to the additional power

necessary to overcome air resistance and not to the actual power required to propel a car at a given speed; this is entirely another matter.

Alcohol. There are two kinds of alcohol; methyl, or wood, alcohol, CH₄O, and ethyl, or grain, alcohol, C₂H₆O. The former has been found objectionable for use in internal-combustion engines, because it apparently liberates acetic acid, which corrodes the cylinders and valves.

As alcohol is a fixed product, and the same the world over, it has a great advantage as a motive power over gasoline and other petroleum products. Denatured alcohol contains 4,172 heat units per pound as compared to 18,000 for gasoline, and, as its cost is higher, this fuel would not seem practicable from an economic standpoint. By mixing the alcohol, however, with a high grade of gasoline, its price is lowered, and the number of heat units per pound greatly increased. Mixtures containing 50 per cent alcohol have a calorific power of 11,086 heat units per pound, and as it has been found by numerous tests in France that it requires no more of this mixture than of gasoline to develop a certain power, its efficiency is considerably greater, reaching a value of 24 per cent as compared to 16 for the gasoline motor. In some recent experiments in France with a motor specially constructed for the use of alcohol, the consumption was lowered to 0.124 pound

per horse power, using 50 per cent carburetted alcohol.

Grain, or ethyl, alcohol has a specific gravity of .795, and may be obtained by distillation from corn, wheat, and other grains, potatoes, molasses, or anything containing sugar or starch. When pure, it absorbs water rapidly from the air, more rapidly in fact than it loses its own substance by evaporation; but when diluted to the proportion of about 85 per cent. alcohol and 15 per cent. water, it evaporates practically as if it were a single liquid and not a mixture. In France, it is denatured for motor purposes by the addition of 10 liters of 90° wood alcohol, and 500 grams of heavy benzine, to 100 liters of 90° ethyl alcohol. In Germany, benzól is added to the extent of 15 per cent. for denaturing, no wood alcohol being used. In the United States the so-called "denatured" alcohol, which is that used in the arts and industries, is composed of ethyl or grain alcohol, to which have been added certain diluents calculated to make it unfit for drinking. The Internal Revenue regulations specify that to 100 volumes of ethyl alcohol there must be added 10 volumes of methyl (wood) alcohol and onehalf of one volume of benzine, or to the same quantity of ethyl alcohol must be added 2 volumes of wood alcohol and one-half of one volume of pyridine bases.

As compared with gasoline as a fuel for in-

ternal-combustion motors, alcohol exhibits several striking peculiarities.

First, the combustion is much more likely to be complete. A mixture of 90° alcohol vapor and air will burn completely when the proportion varies from 1 of the vapor with 10 of air to 1 of the vapor with 25 of air, thus exhibiting a much wider range of proportions for combustibility than is the case with gasoline. As the combustion is complete, the exhaust is practically odorless, consisting only of water vapor and carbon dioxide.

Second, the inflammability of an alcohol mixture is much lower. This is due partly, no doubt, to the presence of water in the alcohol, which is vaporized with the alcohol in the engine and must be converted into steam at the expense of the combustion.

For these reasons, the compression of an alcohol mixture is carried far above that permissible with a gasoline mixture, without danger of spontaneous ignition. The rapidity of combustion of alcohol in an engine is considerably less than that of a gasoline mixture, and for this reason the speed of alcohol engines must be somewhat slow.

The facts that alcohol of sufficient purity for use in engines can be produced from the waste products of many of the country's industries, and at a nominal cost, and that many thousands of acres of land, unfit for the cultivation of first-class grain, etc., may be utilized for the

production of vegetable matter rich in the elements which form alcohol upon fermentation, lead to the supposition that within a few years, or as soon as there is a sufficient demand for alcohol to warrant the erection of special distilleries, it may be purchased at such a low price that it will not only be commercially possible, but will in a measure force gasoline and other petroleum distillates from the field.

A carbureter designed to operate with alcohol can always be used with gasoline, but the reverse conditions are not true, that is, a gasoline carbureter will not operate successfully with alcohol, except in some rare instances. Alcohol evaporates slower than gasoline and its time of combustion is much slower, but it maintains its mean effective explosion pressure far better than gasoline.

Explosive motors fitted with alcohol carbureters make far less noise than when using gasoline as a fuel, due to the slower burning of the explosive charge, they also make less smoke and smell.

The jet or spray of a float-feed carbureter will have to pass nearly 40 per cent. more liquid fuel than when using gasoline, consequently the opening in the nozzle must be proportionally larger.

A carbureter using alcohol must be fitted with some form of device to heat the alcohol to ensure rapid evaporation—this is usually done by surrounding the mixing-chamber with an ex-

The same quantity of alcohol will only take a car two-thirds of the distance that gasoline will, hence greater storage capacity would be needed on a car using alcohol as a fuel.

An explosive motor designed to use alcohol requires a greater degree of compression than a motor of the same bore and stroke designed to use gasoline, in order to develop the same power.

Alternating Current, Use of. It is not only useless but absolutely injurious to attempt to charge a storage battery directly from an alternating current circuit. This can only be done by means of a rotary converter, which is in reality a motor-generator, receiving its power from the alternating current and transforming it into a direct current which can be used to charge the batteries.

Aluminum. A soft ductile malleable metal, of a white color, approaching silver, but with a bluish cast. Very non-corrosive. Tenacity about one-third that of wrought iron. Specific gravity 2.6. Atomic weight 27.1. It is the lightest of all the useful metals, with the exception of magnesium.

Aluminoid, Composition and Use of. Aluminoid is composed by weight of 60 parts aluminum, 30 parts tin and 10 parts zinc. It has a tensile strength of about 18,000 pounds and is a very suitable material for crank chambers, gear

cases and small brackets, being light, extremely ductile and readily machined.

Aluminum Solder. The following formula is for a solder which will work equally well with aluminum or aluminoid: Tin, 10 parts—cadmium, 10 parts—zinc, 10 parts—lead, 1 part. The pieces to be soldered must be thoroughly cleansed and then put in a bath of a strong solution of hyposulphate of soda for about two hours before soldering.

Alloys, Composition of. The proper composition of alloys of metals for the bearings and other parts of an automobile is a very important consideration from a constructive standpoint. Table 4 gives the composition of various alloys of metals and also solders for different uses.

TABLE 4, COMPOSITION OF ALLOYS.

| | Tin, | Copper. | Zinc | Antimony. | Lead. | Bismuth. |
|--|-------|------------|------|-----------|-------|----------|
| pronse, for Motor bearings | 13 | 110 160 | 1 5 | | | |
| Bronze, for Axle bearings Brass, for light work, other than | 20 | יטמו | a- | - | 1 9 5 | * - 1 |
| bearings | | 2 | 1 | | 4 1 1 | |
| Bronze flanges, to stand brazing | | 32 | 1 | | 1 | |
| Genuine Babbitt metal | 10 | | | 1 | 143 | |
| Bronze, for bushings | 16 | 130 | 1 | 1 1 1 | | |
| Metal to expand in cooling, for | ļ ļ | [1 | | | | |
| patterns | مردا | | | 2 | 922 | 1 |
| Genulae bronze | 2 | 90 | 5 | | 2 | |
| Bolder, for tln | 1 | * ! | 151 | | 2 | |
| Spelter, bard | + + + | 1.1 | 1 | | | - 1 . |
| Spelter, soft | 1 | 4 | 3 | 1 1 7 | 1 4 1 | |

It should be understood that no definite rule can be given for the proportioning of any one alloy for the reason that a slight change in the amount of one or more of the elements may the metal exactly for some proposed use, wh porportion only slightly different might give satisfactory results.

Ammeter, Construction of. Ammeters automobile use are constructed on the princ




Fig. 3

of the D'Arsonval galvanometer with a per nent magnetic field. The special feature i small oscillating coil mounted on cone-p bearings surrounding a stationary armat which is centrally located between the p pieces of a permanent magnet, with a poil or index-finger which indicates the electr variations on a graduated scale. The construction of an ammeter is fully show in the two views in Figure 3. The permanent magnets used in its construction are of a special quality of hardened steel, made only for this purpose and possessed of great magnetic permeability. The pole-pieces, which are of soft steel and well annealed, are attached to the inside of the lower part of the magnet legs, the joints between the pole pieces and the mag-




Fig. 4

net legs are usually ground to insure the full efficiency of the magnetic circuit. The soft iron core of the coil is for the purpose of rendering uniform the magnetic field in which the coil must oscillate. A coil of insulated wire is wound upon the stationary armature at right angles to its axis, in the same manner that thread is wound upon a spool, and is short-circuited on itself, that is to say, the ends of the wire forming the coil are connected together. This coil of wire is for the purpose of choking

the magnetism induced in the stationary armature by the oscillating coil, as it generates what are known as eddy currents within itself, thus making the instrument periodic, or dead-beat, in its indications. Around the armature core and outside the short-circuited coil of wire is wound the active or oscillating coil and at right angles to the direction of the winding of the first coil. The oscillating coil consists of a number of turns of fine insulated copper wire, to which the current is conveyed through the medium of the controlling springs at each end of the spindle, which is in two parts and connected together by a suitable sleeve of insulating material, as shown.

The pointer or index-finger is made with a boss or hub to go over the end of the spindle of the active coil and also has an extension with a small counterweight or balance, so that the pointer may be accurately adjusted.

The only difference in the construction of a voltmeter and an ammeter is that in the former the active or oscillating coil is in series with a high resistance, while in the latter it is connected across the terminals of a shunt-block. The voltmeter is in reality an ammeter, the resistance serving to keep the amperage in step with the voltage.

Reference to the three views, marked respectively A, B and C in Figure 4, will show clearly the principle of the operation of an ammeter or voltmeter, and the reason that they

ecord the current strength or pressure of an ectric current accurately.

Ammeters are of two kinds, the double-beat pe, as shown in Figure 3, which indicates the irrent strength or number of amperes flowing the electric circuit, without any regard to be polarity of the terminals of the circuit, by the pointer or index-finger moving either to the ght or to the left of the zero position. The




Fig. 5

ngle-beat type of ammeter only records in ne direction, by the pointer moving from the ft to the right of the graduated scale of the istrument, consequently the polarity of the rminals of this type of ammeter are marked its outer casing and the polarity of the terlinals of the electric circuit must consequently e determined before connecting them with the mmeter. Ampere. The unit of electric current flow. An ampere is that volume of current who would pass through a circuit that offered a sistance of one ohm, under an electromote force of one volt.


Ampere-hour, Definition of. The term a pere-hour is used to denote the capacity o storage or a closed-circuit primary battery current. A storage battery that will keep ampere lamp burning for 8 hours is said have a 16 ampere-hour capacity. In a sim manner an 80 ampere-hour battery would crate the same lamp 40 hours. The voltage co battery does not enter into the calculation its ampere-hour capacity.

Anti-Freezing Mixtures. If a solution of cohol and water is used, the best results will obtained by having it just strong enough stand the lowest temperature to which it likely to be subjected in the climate where is to be used.

The reason for this is that the alcohol evarates out from the solution, and the stronger solution, the more there is to evaporate, easier it evaporates, and the greater the in ence of this evaporation upon the solution 1

The diagram shown on page 33 indicates freezing points of various solutions of detured alcohol, also of wood alcohol. From diagram a solution may be selected which stand any temperature from 50° below zero 40° above.

Other solutions may be made with calcium chloride (common salt), also the salts known as potassium carbonate. These with water form a solution that will stand zero temperatures, but are not available where lower temperatures are common.



Non-Freezing Mixtures for Radiators. In cold weather, the circulating water, the oil, and the carbureter require special attention. If the car is to be run regularly during

the winter, it is advisable to use freezing mixture in the water-jacket. car is not to be used regularly, it may be necessary to employ such a mixture, t that case great care is necessary to preven water from freezing unexpectedly. If th is kept in a barn, the water should be c off completely after the car has been used the drainage cock should be so located an piping so arranged that there are no pockets in which the water may freeze an struct the circulation. If the water free: the pump, the latter is likely to be broken the car is started the next morning. If freezes in the water-jackets, it will burs jackets unless they are made of copper. the car is left standing for an hour or so,

Proportions of Glycerine, Alcohol & Water.

| Freezing Point | | Glycerine and Alcohol (equal parts) | | |
|-------------------|-------|-------------------------------------|--|--|
| 2 8° | above | 15% | | |
| 15° | above | 20% | | |
| 10° | above | 24% | | |
| 5° | above | 28% | | |
| Zero |) | 30% | | |
| 5° | below | 33% | | |
| 10° | below | 36% | | |

or lap robes may be thrown over the radiator to check the cooling; this is cheaper and safer than leaving the motor running.

The two substances most used to prevent freezing are glycerine and calcium chloride. A 30-per-cent solution of glycerine in water freezes at 21° F.; and a solution of one part of glycerine to two parts of water is safe from freezing at 10° or 15° F.; 40-per-cent solution freezes at zero. A small amount of slaked lime should be added to neutralize any acidity in the solution. Glycerine has the objection that it destroys rubber, and the solution fouls rather quickly.

A cheaper mixture, and one preferable where the temperatures encountered are likely to be below 15° or 20° F., is a solution of calcium chloride. This must be carefully distinguished from chloride of lime (bleaching powder), which is injurious to metal surfaces. Calcium chloride costs about 8 cents a pound in bulk, and does not materially affect metals except zinc. A saturated solution is first made by adding about 15 pounds of the chloride to 1 gallon of water, making a total of about 2 gallons. Some undissolved crystals should remain at the bottom as evidence that the solution is saturated. To this solution is added from 2 to 3 gallons of water, the former making what is called a 50-per-cent. solution. A little lime is added to neutralize acidity. A 50-per-cent solution freezes at -15° F.

Whether glycerine or calcium chloride is used, loss by evaporation should be made up by adding pure water, and loss through leakage by adding fresh solution. In using the chloride, it is important to prevent the solution from approaching the point of saturation, as the chloride will then crystallize out and clog the radiator, besides boiling, and failing to cool the motor. A 50-per-cent. solution has a specific gravity of 1.21, and should be tested occasionally by means of a storage-battery hydrometer. Equally important is it to prevent the water from approaching the boiling point, whatever the density, as boiling liberates free hydrochloric acid, which at once attacks the metal of the radiator and cylinders.

A solution of two parts of glycerine, one part of water, and one part of wood alcohol has been recommended, which is said to withstand about zero temperature.

Certain mineral oils used for the lubrication of refrigerating machinery are recommended for cooling, because they remain liquid at very low temperatures. They are not particularly good heat conductors, however, and will not keep the motor as cool as the water solution. If the oil is used, it must be cleaned from the radiator by the use of kerosene and oil soap, before water can again be used effectively.

As regards lubrication, the principal danger is that the oil will thicken from the cold so that it will refuse to feed. This is avoided by using.

cold test oil, which remains liquid at lower temperatures than ordinary oil, or by adding to the ordinary oil some kerosene or gasoline, and increasing the feed. If the oil tank is located close to the engine, it will remain liquid, even in quite cold weather. But unless the car has been kept in a warm place over night, the bearings are liable to run dry before the car has warmed up.


Cooling Solutions—For Winter. Radiators are costly, delicate and composite in construction, the latter due to the plurality of metals in their make-up, hence electrolytic action takes place, due to the difference of potential natural to the different metals immersed in a saline bath. Therefore great care should be exercised in the preparation of anti-freezing solutions made up of calcium chloride (common salt and water). Any approach to the saturation limit is attended with danger of precipitation. The saturated solution is ascertained at 60 degrees F., and increasing the temperature increases the capacity of the water to hold the salts in suspension.

On the other hand, the Ohmic resistance of a solution is lowest at about half saturation. To sum up, it is experience that counts, and it is still a question as to the extent to which saline solutions can be used with safety. Of course there is no solution as good as water alone, but unfortunately water will expand when it freezes, and it will freeze on small provocation in a radiator. Oil as a cooling medium has points in its favor which some authorities claim render it more efficient than water, as for instance it has a higher boiling point, about double that of water, and as a result the oil will not waste away except by leakage. The heat exchange occurs at a higher temperature, thereby increasing the efficiency of the motor. Then also the area of radiating surface may be smaller, with a conesquent decrease in weight, while the work of the fan is rendered of less importance. A light, thin, pure mineral oil is the most reliable. Animal, and vegetable oils are more apt to become rancid, the acid in them also attacks the metal of the radiator.

Armatures, Dynamo. The armature, or revolving member of lighting dynamos, is composed of a core made from wrought iron or mild steel. It is customary to make this core by assembling a sufficient number of thin plates made in the form of the cross section of the core, these plates being covered with an insulating composition and then fastened together on the shaft. This construction prevents the formation of harmful "eddy currents" within the metal.

The assembled core has a number of slots running lengthwise of its body and in these slots are placed the armature coils or winding of insulated wire. The coils are then connected to a commutator mounted on one end of the shaft in such a way that the current generated may be collected by the brushes.

Armatures, Slotted and Shuttle Types of. An armature is the rotating part of a dynamo or electric motor which generates electricity or develops power.



The armature shown at right of Fig. 6 is known as the Siemen's H or shuttle type and is the simplest form of wire-wound armature known. The current given by this form of armature is of the alternating type and is converted into a direct-current, when desired, by means of a two-part commutator on the armature shaft.

The slotted type of armature shown at the left of Fig. 6 has a more intricate system of winding than the shuttle type just described. It has, however, a far greater electrical efficiency and gives off a steadier current than the shuttle type. It is the form most generally used for automobile and street railway motors. Like the shuttle type of armature, the current generated by the slotted type of armature is alternating, and is converted into a direct current by means of a commutator of very complicated form.

Assembling a Car. In assembling the car the engine had best be put together first. When putting the pistons in their respective cylinders see that the splits or joints in the piston rings are not in line, but are spaced evenly around the piston. See that all parts are thoroughly clean and that no grit, or stray strands of waste happen to be caught on any projection. All nuts and bolts should be screwed tight and the jaws of the wrench should be properly adjusted to them, that the corners of the nuts and cap screws may not be rounded off. Insert the cotter pin after each nut has been screwed home. In joints where packing is required the old packing may be used if it is in good shape. Joint faces should, of course, be perfectly clean. A stout grade of manila wrapping paper soaked in linseed oil will make an excellent packing for crankcase and other joints having a good contact surface.

While the engine is being reassembled it will be found advantageous to check up the valve timing. To do this, turn the fly-wheel until the inlet valve plunger of No. 1 cylinder just touches the lower end of its valve stem. At this point the line on the fly-wheel indicating "Inlet No. 1 Open" should coincide with the pointer on the engine base. If the contact between the valve stem and the plunger is made before the mark on the fly-wheel lines up with the pointer, the valve opens too early. In most cars the adjustments may be made by the screw cap and

lock-nut on the plunger. As the valve stems are lowered by repeated grindings of the valves, the plungers require adjustment occasionally to compensate for this movement. Insert a piece of paper between plunger and valve stem, and by lightly pulling on the paper the time of contact and the moment of release may be determined to a nicety. When the paper is held tightly, a good contact is assured, and the moment the paper becomes loose and can be moved about, the contact is broken. In many cars the reference or index mark on the engine bed is omitted; in this case the markings on the flywheel must be brought directly to the top. The other inlets and the exhaust valves should then be similarly checked up and adjusted.

Most cars base the valve setting on a 1-32 inch clearance space between valve stem and plunger rod when the valve is closed. This may be taken as the minimum amount, and should not be increased. A larger amount of clearance will cause the exhaust valve to open too late, and, the exploded gases not being entirely expelled, the power of the motor will be impaired. This clearance is necessary to allow for the expansion of the valve stem when it becomes heated.

Too much stress cannot be laid on the necessity of going about the work in an orderly and methodical manner. A mechanic who leaves parts lying about carelessly will rarely be found a good one, and certainly he is not a proper

model for the amateur to copy. With the proper circumspection, then, and with a little "horse sense" in applying the directions to his particular make of car, the amateur owner should have no difficulty in making a good job of overhauling, thus bettering the condition of his machine and at the same time acquiring a valuable stock of knowledge for the future.

Automobile Driving. When on the open road, away from cities or towns, the lowing rules should be borne in mind. Drive with moderate speed on the level, slow. speed down hill, and wide open throttle for hill climbing, or getting up speed only. (2) The condition of the road should be noticed, the presence of mud or dust thereon furnishing sufficient reason for slowing down somewhat for the sake of other road users. (3) The ordinary rules of the road regarding the negotiation of turns, and crossings, also the overtaking or passing of other vehicles should be adhered to, even though a lower rate of speed is involved thereby. (4) A sharp lookout should always be kept for traffic of all kinds, as well as on approaching schools, churches, or public buildings, and also for road signs indicating danger, caution, etc. (5) When on the road the autoist should show courtesy to other road users. Courtesy in autoists is much appreciated, and goes a long way toward removing the prejudice which exists in many places against automobiles.

GEAR—CHANGING. In changing gears the autoist should endeavor to have the motor and car moving at nearly corresponding rates of speed before the clutch is engaged. With the planetary type of gear, changing is simple, and drivers usually guess at the proper period at which to make the change, any mistake in estimating the rates of the car and motor being of little consequence, as the bands will slip instead of transmitting the shock to the gear. A similar action occurs in the case of individual clutch or friction gears, but with the sliding type severe strains and shocks have to be taken up by the clutch, and are usually transmitted in part to the gear if the clutch is not slipped. What applies to the sliding type in general applies to the other types as well.

In changing from a lower to a higher gear it will be necessary to speed up the motor by means of the throttle or accelerator in order to store enough energy in the flywheel to furnish the work needed to accelerate the car to its new speed. As the speed of the car increases the higher gear should be engaged, the autoist not being in too great a hurry to make the change. The movement of the change gear lever should be made quickly in order that the car does not lose way. When changing from a higher to a lower gear the change should be made as quickly as possible before the car has time to slow down. When climbing a steep hill it should be ascended as far as possible on the

high gear by proper use of the throttle and spark, and the change down to the lower gear made as soon as the motor begins to labor or is in danger of stopping. The presence of an unusual number of passengers in the car will affect its ability to negotiate grades which ordinarily are taken on the high gear, and the autoist should remember this and not attempt to force the car to travel on that gear with the increased load, but resort to a lower gear.

REVERSING—BACKING UP. Among other things connected with driving which is apt to be neglected, is reversing, or driving a car backward. Usually a car is never reversed for more than a few yards at a time and the maneuvering involved requires no great skill. Steering a car when running backwards is diametrically opposite to that when running forward. A turn of the wheel to the left steers the car in the opposite direction to the right, and vice versa. The usual mistake made in reversing is in turning the steering wheel too far, and describing zigzags in the road as a result. The autoist should remark that the reverse gear of a sliding change gear should never be engaged until the car has been brought to a full stop.

Brakes, Proper Use of. Next to the motive power in importance come the brakes. There are a number of points regarding brakes that every autoist should know and remember. First and most important is the fact that brakes vary in their effectiveness, and that freedom from dis-

aster depends upon the brakes being kept in good condition and properly adjusted. Second, while a brake may be perfectly satisfactory for slowing down, it by no means follows that it will bring a car to a stop as it should, nor hold the car from going backward. Third, brakes should be tested frequently with the car in motion, the pedal or hand lever being applied until the car slows down, or stops. The distance covered in making this test should be noted, and a greater distance allowed in making stops on the road.

In applying brakes, the application should be gradual, reducing the speed of the car as quickly as possible without locking the wheels. As long as the tires retain their grip on the road, the powerful retarding action of the brake continues, but when the wheels are locked the brakes have little or no effect, and the car will either slide along, or skid, in either case being beyond the control of the driver. Should the wheels become locked while descending a hill, the brakes should be released until the wheels are again revolving, and then reapplied gradually, until they act satisfactorily.

Brakes should be examined at regular intervals in order to ascertain if the lining is in good condition. If worn, the old lining should be replaced with new. If the brakes are of the internal-expanding type, the shoes may have become worn, in which case they should be renewed. Toggle joints and adjusting nuts

should be inspected, and any looseness taken up. Brakes should be adjusted on the road, as any improper adjustment of the equalizer bar will have a strong tendency to make the car skid. Both brakes should be adjusted alike, that the braking force applied by the equalizer may be transmitted to the wheels equally.

SIDE SLIP, OR SKIDDING. If the rate of rotation of a wheel is greater than the rate of advance over the road, the wheel loses adhesion and thereafter it is just as easy for it to move in one direction as in another.

The wheel can now slip sideways as easily as it can slip forwards, particularly when it has the rounded section slightly flattened, which is the case with pneumatic tires. When traveling straight ahead, and with the motor out of gear, skidding does not usually occur. A slight turn given to the steering wheel checks the speed and introduces a side pressure on both front and rear wheels, due to the machine tending to continue its path in a straight line. Generally this side pressure will not cause skidding. If, however, the motor be suddenly thrown in gear, or the brakes suddenly applied, or, what amounts to the same, a large turn is given the steering wheel, the wheels find themselves either rotating more than in proportion to their advance, or advancing more than in proportion to their rotation. This immediately causes a loss of adhesion, which, once established, causes the car to skid or side-slip.

SPARK—REGULATION OF. Upon the proper use of the sparking device depends the economy of the motor, and in many cases the safety of the driver. On some cars the sparking point on the magneto is fixed, and the autoist controls the car by the throttle only. There are a number of cars in use which employ the battery in connection with separate coils or a single spark system, or a magneto on which the spark can be regulated by the driver. When starting, the spark should be retarded in the case of battery ignition, to prevent backfiring, and slightly advanced to a certain point, depending on the motor and magneto, in the case of magneto ignition. When it is desired to slow the motor down below the point obtained by throttling only, the spark is likewise retarded. In ordinary running, a position of the spark lever can be found which will give fair average results through a considerable range of speed without changing its position, and this position varies with each motor, and can be found by experience. When a higher rate of speed is desired, the throttle is opened and the spark advanced gradually. If a grade is to be negotiated it should be "rushed" if possible, the throttle being opened full and the spark well advanced until the motor begins to slow down and "knock," when the spark should be retarded to correct this. The autoist should always keep the spark as far advanced as possible, without causing the motor to knock.

When to Retard the Ignition. Always reretard the ignition before starting the motor, and take great care that the ignition is retarded and not by mistake advanced. Some cars are fitted with a device which prevents the starting crank being turned unless the spark is retarded. If it is not clear as to which way to move the ignition lever to retard the ignition, move the commutator in the same direction as the camshaft rotates.

As soon as the motor slows a little when going uphill, retarding the spark enables more power to be obtained from the motor at the slow speed, that is to say, if the spark is not retarded the motor will go slower than if it is retarded. Do not retard the lever to the utmost under these conditions; on the contrary, retard the lever to such a point that the knocking (due to the wrong position) ceases.

Retarding the spark causes the maximum pressure of the explosion to occur at the best part of the stroke, or, rather, the mean pressure of the explosion stroke will be lower if the best point of ignition by retarding is not found. This is a matter of some skill and practice.

To slow the motor, cut off as much mixture as the throttle allows, then slow the motor still further by retarding the spark, but on no account retard the spark when the throttle is full open (for the purpose of slowing the motor), as the motor will merely discharge a quantity of flame at a white heat over the stem of the

exhaust valve, burning it, softening it, and making it scale.

When to Advance the Ignition. With too early ignition the pressure upon the piston becomes excessive and without any adequate return of useful work or energy. If the ignition be retarded too much, the maximum explosive pressure occurs too late during the working or power stroke of the piston, and the combustion of the gases is not complete when the exhaust-valve opens. Greater motor speed requires an early ignition of the charge, but greater power calls for late or retarded ignition.

The reason for advancing the spark when fast running is required, is that the explosion or ignition of the charge is not instantaneous as may be supposed, but requires a brief interval of time for its completion.

It may be well to explain without entering into theoretical details, that when a motor is running at normal speed, the ignition-device is so set that ignition takes place before the piston reaches the end of its stroke. The later the ignition takes place the slower the speed of the motor and consequently the less power it will develop. If, however, in starting the motor the ignition-device were set to operate before the piston reached the end of its stroke, backfiring would occur, resulting in a reversal of the operation of the motor and possibly in injury to the operator.

CAR INSPECTION. Most autoists are content to make all their inspection of the car and its mechanism from above, and rarely give more than a casual glance below the frame except when trouble occurs. On cars fitted with pressure-feed on the gasoline, the piping should be frequently inspected, on account of the danger from fuel Such inspections should be made leakage. when the motor is stopped, and the pressure still turned on. The tank should be gone over for leaks arising through the opening of its seams from vibration, or the loosening of the union connecting the fuel lead with the tank. The lead and its connection to the carbureter should also be examined for leaks and abrasions due to rubbing against other parts of the mechanism. If any such are found they should be immedidiately repaired. Twine, tire tape, or rubber bands will act satisfactorily as fenders to prevent further mischief. Unions which cannot be made tight by screwing up should be taken apart and the male connections coated with soap or red lead, which will render them tight for a considerable time.

After going over the fuel system, the brake rods and steering connections should be examined for loose joints and broken oil and grease cups. Grease boots on the drive-shaft joints should be seen to be sound, and filled with grease. A cleaning out of the dirt from the interior of the mud-pan will often reveal lost cotter pins or nuts, and tend to a more agreeable handling of the draincocks, carbureter and fil-

ter. This time will be well spent when the chances of fire or accidents arising from faulty steering or brake connections are taken into account.

Dont's. In the first place don't forget to ascertain the fact that the ignition mechanism is retarded before cranking the motor. Many a sprained wrist and a few cases of broken heads or arms have been caused by the neglect of this simple precaution. It is a good plan to have the ignition-control spring so actuated that in its normal position it is always retarded.

Don't use the electric starting motor to propel the car. It ruins the battery.

Don't use a match or a small torch to inspect the carburetor. It sometimes leads to unexpected results.

Don't forget to fill the gasoline tank before starting.

Don't smoke while filling the gasoline tank.

Don't take out all the spark plugs when there is nothing the matter, except that there is no gasoline in the tank.

Don't forget to always have an extra spark plug on the car.

Don't allow the motor to race or run fast when out of gear. If the car is to be stopped for a few minutes, without stopping the motor, retard the ignition and also throttle the charge, so that the motor will run as slowly as possible.

Don't fill the gasoline tank too full, leave an

air space at the top or the gasoline will not flow readily.

Don't have any open hole in the gasoline tank. When the car is washed water may run in this hole, mix with the gasoline and cause trouble.

Don't put grease in the crank case of the motor, it will clog up the oil holes and prevent the oil from circulating.

Don't fill the gasoline tank by lamp or candle light, something unexpected may happen.

Don't keep on running when an unusual noise is heard about the car, stop and find out what it is.

Don't start or stop too suddenly, something may break.

Don't pour gasoline over the hands and then rub them together. That rubs the dirt into the skin. The proper way to do is to saturate a towel with gasoline and then wipe the dirt off.

Don't forget to examine the steering gear frequently.

Don't fail to examine the pipe between the carbureter and the admission-valve occasionally. The pipe connections sometimes get loose and allow air to enter and weaken the mixture.

Don't forget to see that there is plenty of water and gasoline in the tanks.

Don't fail to clean the motor and all the wearing parts of the car occasionally.

Don't forget to oil every part of the motor

where there is any friction, except the valve stems.

Don't forget to put distilled water in the battery every ten to fifteen days.

Automobile Tools. In Fig. 7 three types of valve lifters are shown. B and C are of the same principle, and quite efficient in almost any case; but A, when properly operated, and on its respective motor, is more quickly applied,




Fig. 7

and consequently a time saver. D is a valveseating tool, supplied as special equipment by one of the large motor car manufacturers.

In Fig. 8 are shown a couple of spanner wrenches and one or two other tools that are quite uncommon but quite necessary in the work to which they are adapted. A is made from a piece of steel tubing and used on packing glands—the tube to slip over the shaft—and the small lugs at the end engage corresponding

recesses in a packing nut. B is representat of a valve-grinder, designed especially for valves in certain motors. The spanner C is quired to conveniently remove certain types cylinder plugs; while D, which approaches conventional, is used in adjusting bearings a particular type.

There is probably a greater variety of whand gear pullers now in service than of




Fig. 8

other special tool. In Fig. 9, A looks vermuch like the standard adjustable wheel a gear puller for sale in all supply houses; a it practically is the same except that the horare larger and twisted in opposite direction and at right angles to the beam. It is for useful in removing road and flywheels and like. B is a non-adjustable tool made especial for removing flywheels. C and P are road who pullers, and are included in the regular equ

ment of tools supplied with the cars of two prominent manufacturers. C is part of the Rambler tool equipment and is used in connection with their spare wheel; and P represents the type of wheel puller supplied by the Pierce-Arrow. E is a gear-puller designed to remove the half-time-gears of an Oldsmobile, the two




Fig. 9

side-screws being intended to fit into threaded holes in the web of the gears.

WHEN THE JACK IS MISSING. Should the jack be missing or broken, an efficient substitute can be rigged from a large stone or a number of bricks piled one on another until the height is sufficient to lift the wheel from the ground.

Having gotten the stone or piled the bricks on of the floor-boards can be utilized as an incline plane and the ear backed up until the axle rest on the top of the pile. When the work has been performed, the axle will have to be pushed of the pile, but as the drop is inconsiderable no harm can come to the tire. Where stake-and




Fig. 10 Removing Dent in Gasoline Tank

rider fences abound, one of the rider timber can be utilized as a lever, with a stone as a fucrum to raise the axle, supporting the latter with another stone during the repair, and gentle casing down the axle when ready to proceed.

REMOVING DENTS. An easy method of remoing dents consists of soldering a piece of winto the bottom of the dent, then pulling the d

pressed portion out to its proper position. When the dent happens to be in an oil, or gasoline tank, or a radiator, an old valve can be most effectively used in place of the wire, as shown in Fig. 10 The top surface of the valve is filed smooth and bright, then cleaned with soldering acid and tinned with solder. A flat surface of the same area, and as near the bottom of the dent as possible, is treated in the same manner, and the valve sweated on. This sweating on is done by placing the prepared portion of the valve against the tinned surface of the dent, and then applying heat with a torch till a fusion of the solder takes place. The heat should then be removed and the solder allowed to set. When cool, it will be found that with the valve stem as a handle and lever, and probably a few light taps with a hammer around the edge of the dent, the deformed part can be most easily straightened out.

Tools Necessary. The following tools should be in the car when on the road:

Monkey wrench, 9 inch.

Machinist's screwdriver.

Ball pene hammer, one pound.

Combination pliers, 8 inch.

Set of double end, or "S" wrenches.

Flat file, mill cut.

Three cornered file.

Round file, six inch.

Center punch.

Prick punch.

Drift punch, flat ended.

Offset, or "bent-end" screwdriver.

Cold chisel, three-quarter inch.

Spark plug wrench.

Small wire cutting pliers.

Emery cloth.

Cotter pin puller.

Wire brush for spark plugs.

Break Downs, and Their Remedies.

CHAIN BROKEN. In case a chain should break, and there are no spare links available, the car may be driven by the other chain, provided the idle sprocket is secured so that it cannot revolve. An easy way to do this is as follows: Pass one end of the chain around the sprocket, secure the end link to the chain with wire, and attach the other end of the chain to some part of the car, as a running board bracket.

On shaft driven cars the universal joint pins sometimes work loose, and drop out. In such cases a temporary pin can be made from a bunch of wire, or by a rmall chisel held in place by wires, or twine.

CIRCULATING PUMP LEAKAGE. Leakage of the water circulating pump occurs usually where the cover joins the pump body by means of a ground joint. A gasket of stiff paper dipped in lubricating oil inserted between the cover and the body will remedy this, the gasket being easily formed with the pocket knife. Asbestos cord is better than paper when treated with vaseline and graphite, but few autoists

carry it. For leakage around the pump spindle the cord can be used, pushing it in with a piece of strip brass or other soft metal so as to avoid scratching the shaft. If no asbestos cord is at hand one of the strands of a piece of hemp rope treated with tallow will also answer.

CRANKING WITH SAFETY. The principle involved in safely cranking an engine is, to get the explosion at the moment the crank is pulling on the fingers, so that if the kick comes the force will simply pull the handle out of the grasp, instead of being expended against the body weight and applied force. Do not attempt to turn the crank all the way around; adjust it to start against the compression, then give a quick pull upward.

DIFFERENTIAL CASING. In cases of emergency where oil or grease cannot be obtained for filling the differential casing, beeswax may be used as a substitute.

DRY CELLS FOR IGNITION. Dry cells will give very satisfactory ignition for a four cylinder motor by using four sets of four cells each, connected in series multiple so as to get a voltage of only six volts. By having the vibration respond quickly to the pull of the magnet in the coil, battery consumption will be greatly lessened. The slightest current should separate the contact points.

GASOLINE PIPE BROKEN. When the gasoline pipe breaks, a short piece of rubber tubing forced over the broken ends will do for a short

time, but as gasoline attacks the rubber, too much dependence should not be put on it, and the pipe should be brazed at the nearest shop. If the hole is only a small one a piece of soap squeezed in and held in place by a soaped rag and string will serve if gravity feed is used. For pressure tanks a piece of rubber tubing split lengthwise and well soaped will tempora-




Fig. 11 False Teeth, Permanent Repair

rily stop the hole, if wired tightly around the pipe, but the pressure must be kept low, otherwise the rubber tubing will be loosened and the leaking commence again.

A leak is sometimes hard to locate, but if the pipe is rubbed with soap suds, and then blown through, the leak will be located by the bubbles.

GEAR TEETH BROKEN. If several teeth are

wholly, or partly broken they may be repaired in the following manner; referring to Fig. 11: Shape out a dovetail recess across the face of the wheel, cast or shape up a brass, bronze, or steel segment and dovetail it in, driving it tight from one side, and securing it with screws. Then file the teeth to a template made from the standing teeth of the wheel. For a single tooth proceed in the same way, no screws being necessary if properly fitted and the ends peened over with a hammer; or, file down the broken tooth lush with the bottom, drill and tap two or three holes, according to the width of the wheel, screw in capscrews and trim with a file. It night be well to add, when removing a timing gear for repairs, or any other purpose, care should be taken to see that it, and the gears with which it meshes, are plainly marked.

MISS FIRE CYLINDER. Should one of the cylinders miss some of its regular explosions at intervals when under a load, it may be located by stopping the engine, and touching each cylinder with the business end of an unlighted match. The cylinders that have been doing their regular work will be hot enough to ignite the match, while the missing cylinder will not.

NUTS AND SCREWS—How To Loosen. Refractory nuts may be loosened by heating, by means of a red-hot piece of iron held on or near them for a few minutes. This will expand the nuts and they will then come off readily. When a screw cannot be readily loosened with a screw-

driver, the latter should be pressed hard into the slot, while a helper applies a monkey wrench to the flat part of the blade. A tight radiator cap can be moved by winding a quantity of twine, or cloth tightly around it.

PRIMING. If a motor does not start readily, due to not getting a rich enough mixture at slow speed of cranking, tie a small bunch of waste with a wire close to the air intake of the





Fig. 12
Section of Radiator Showing Washers Held by Wires on Stick, To Stop Leak

carbureter, then prime by saturating the waste with gasoline. The added vapor will make starting easy.

RADIATOR LEAKING. In case a "honeycomb" radiator starts leaking at the end of a cell, and there is no radiator plug at hand, a substitute may be made by passing a long bolt of small diameter through the defective cell and fitting each end of the bolt with washers made of leather, or rubber backed with iron washers or

metal strips, and then screwing down the nut until the leak is stopped. If a bolt cannot be sotained a small piece of wood may be whittled down to take its place, and the washers secured by means of copper wire as shown in Fig. 12.



If a leak occurs inside one of the cells, a square peg cut from soft wood, and covered with a piece of thin cloth smeared with white lead can be used as a plug. Only a moderate force should be used in these methods, as the tubes are easily buckled. Leaks in gilled radiated may be stopped by applying a rubber patch in place by tire-tape and wire.

RODS OR LINKS BROKEN. The repair of broken link in the steering gear can be effect by placing the broken ends together and fast




Fig. 14
Valve Spring Strengthened by Inserting Metal St

ing a rod or a piece of gaspipe against the li winding the wire the entire length of the r If two hand vises can be obtained they can attached as shown in Fig. 13. The rod is t to the joined ends of the link with wire, and hand vises screwed down on both link and r Anything but slow running with either of th

repairs is out of the question. Any other rod can be similarly repaired provided there is room for the pipe or the vises alongside of it. Wire cable can be substituted for brake rods, but the brake must be kept clear of the drum by some means when not in use.

SQUEAKING SPRINGS. A frequent source of annoyance is the squeaking caused by the leaves of the springs having become dry from want of luprication. When such is the case, jack up the



Fig. 15
Method of Testing Valve Springs

car until the wheels are clear of the ground, and the springs quite free. Then with a thin cold chisel, or a large screwdriver, gently force the leaves apart, one by one, and spread a mixture of vaseline, oil and graphite between them. using an old table knife or thin wooden paddle for the purpose. Where parts cannot be reached in this way, oil should be squirted in, and if necessary the leaf clips may be removed to allow of this being done.

TREMBLER BLADES BROKEN. Corset steels may

them to the proper length, and riveting the platinum button from the broken blade through the hole which is punched near the end. After making the holes for the retaining screw, the blade is complete. A piece of the main spring of a clock will also make a good blade.

TWINE IS USEFUL IN BREAKDOWNS. Autoists should always carry 15 or 20 yards of strong




Fig. 16 Corset Steels Used As Impromptu Valve Springs

twine in their kit, as it may be put to various uses about the car, such as reinforcing weak spots in tires, protecting chafed wires, and binding together split sections of the steering wheel. Twine may also be used as a substitute in the absence of a lock washer, by forming a loop slightly larger than the diameter of the nut, and then wrapping twine around this loop, forming a "grommet," as sailors call it. When

the nut is screwed down upon the grommet it will be held as firmly as if fitted with a nutlock, and will stay tight until the twine rots.

Axles, Definitions of. The following definitions apply to the forms of rear axles that are now and have been in use on shaft-drive cars.

A "live axle" (no longer used) is one in which the driving member is carried by a bearing at each end, the outer end carries the wheel and the inner end the differential.





Fig. 17 Semi-Floating Rear Axle

A "semi-floating axle," Fig. 17, is one in which the driving member is carried on one bearing at its outer end and with the inner end supported by the differential. The outer end carries the wheel.

A "three-quarter floating axle," Fig. 18, is one in which the driving member is carried by the differential at its inner end and at the outer end is carried by the hub flange, the flange being bolted to the wheel. The wheel is carried by a bearing that runs on the outsi the end of the axle housing tube.



A "full floating axle," Fig. 19, is one in we the driving member is carried by the differe at its inner end and at the outer end is can by a jaw clutch, the clutch itself being eng

with and meshing with the wheel hub. The wheel is then carried on two bearings that run on the outside of the axle housing tube. With





Fig. 19
Full-Floating Rear Axle With Annular Ball
Bearings

this construction, the drive shaft may be entirely withdrawn from the car without disturbing the wheel or other axle parts.

Axle, Front. So far it has not been found practical to combine the tractive and steering functions of an Automobile in one set of wheels and axle. Therefore it is necessary to use a rigid front axle with knuckle jointed spindles, for steering purposes, and utilize the tractive power of the rear wheels only to propel the car. Some of the earlier forms of steering axles had the wheel pivots inclined so as to bring the projection of the pivot axis in line with the point of contact of the wheel with the ground, but as such constructions have not proved satisfactory they have in most cases been abandoned.



FRONT AXLES. Figures 20 and 21 show four yles of front axles with steering-pivot ends: shows a solid axle of square section, with te steering-pivot jaws and axle proper, of a ngle forging—B represents an axle of tubular oss-section with the steering-pivot jaws bored




Fig. 21

azed therein—C shows another style of tuburale, in which the steering-pivot jaw ends e turned down to fit the inside diameter of e tube and are also brazed in position, while illustrates a one-piece axle with vertical hubs




Fig. 22





Fig. 23




instead of jaws, which carry L-shaped steeringpivots, instead of the usual form of knuckles.

Steering Knuckles. In order to obtain ease of operation and secure the shortest turning adius with the least movement of the steering wheel or lever, the knuckle of the steering pivot should be as close to the center of the wheel as is possible. It is also of great importance that the steering knuckles should be as heavy as is practically consistent with the size and weight of the car for which they are intended. If this imporant point be neglected, rapid wear and probable fracture of the knuckles may be ooked for.

A steering knuckle with a spindle and pivot of T shape is shown in Figure 22. The spindle and pivot N and the steering arms O are usually one-piece forging. The steering arms O are connected by means of a suitable distance rod and the steering lever P is attached to one of the pivots N by turning a shoulder upon it and binning and brazing the steering lever and pivot tub together.

Figure 23 shows a steering knuckle with spindle and pivot of L shape. The steering arm R goes on the lower end of one pivot Q only, the other pivot having the combined steering arm and ever S on its lower end. The steering arms being detachable, the device may be operated from the right or left hand side by simply exchanging the levers R and S. The steering lever S has a ball upon its outer end to fit in the



ocket on the connecting rod of the steering aechanism.

Axle, Rear. A live axle is any axle containag parts which turn the wheels in addition to arrying weight.

DEAD AXLE. A dead axle is an axle which arries weight only.




Fig. 26

Two-Speed Rear Axle With Two Bevel Gears and Two Pinions

FLOATING AXLE. A special type of live axle n which the shaft that turns the wheels is inlependent of the axle proper, and may be renoved without affecting the axle's weight carying capacity.

In Fig. 24, K and L show respectively a ive solid rear axle and a rigid tubular axle,

equipped with roller-bearings. The spring form part of the roller-bearing boxes of the axle, while they are usually brazed to the lar axle near its outer ends.

A rigid tubular axle with ball-bearing driving shaft is illustrated in Figure 27, the cup or race is adjustable by means of a l gon upon its outer extension in the rear of hub of the wheel and is held securely in pos




Fig. 27

and prevented from turning by means of clamping device shown on the upper portic the bearing. No separate adjustments for inner two sets of ball-bearings are necess as the teeth of the spur gears of the differe which are keyed to the inner ends of the div driving shaft, being free to slide upon t selves, allow the shafts M to have a slight le tudinal movement within the axle tube,


taking up the wear of each pair of ball-bearings with a single adjusting mechanism.

In any style of full-floating axle the entire weight of the rear end of the car is carried on the axle housing, or casing, leaving the drive-shafts in the axle with no other work than that of revolving the wheels. In this axle, by the removal of the hub caps, the drive-shaft in each half of the axle can be pulled out, owing to its being free in the housing, and having generally a squared end which fits into the bevel gears of the differential. In a semi-floating rear axle the complete car weight at the rear is carried on the axle housing, identically as in the floating axle, but the drive-shafts of the axle are not removable by pulling endwise through the hub. This is because these shafts are tightly keyed at their inner ends with differentials, bevels or, as is the case in one or two cars, the bevel gear is formed integrally with the shaft.

The newest type of floating axle is that known as "three-quarter floating." As will be seen from the definition on a preceding page, this form combines several of the advantages of both of the other types, while, of course, having certain disadvantages of its own.

The construction used in Fig. 28 shows a full-floating type of live rear axle in which the bearings are of the annular type, and the driving jaws at the ends of the shafts engage with the hub in a proper manner to abort failure from lost motion.

In this case the tube is reduced in diametro take the bearings, and the shoulder formed is taken advantage of in the process providing for thrust. The shaft has no work do excepting to take torsional moments, a



the design throughout includes drop forgin of steel and drawn-steel parts. The inner ra of the ball bearings is a sufficiently heavy tulbut it is not shaped in such a way as to act as "preventer bearing," hence complete dependence is placed on the ball bearings and they a

made large enough to take the responsibility.

AXLE, REAR, THREE-QUARTERS FLOATING. this design, Fig. 18, the axle housing is extended outward to a point in line with the outside surface of the wheel, and the outer end is made of a diameter just large enough to allow the axle shaft to pass through it. Mounted on the outer end of the axle and directly in the center of the wheel is a single bearing, usually of the annular ball type. The wheel spokes are mounted in the hub flange in the usual manner and the flange is carried upon the outer surface of the bearing mentioned above. A large hub forging is bolted to the wheel flange and the bolts pass through the spokes which hold the brake drum on the inside. The outer end of the driving shaft is fastened into this hub forging by a key way and taper; the inner end of the driving shaft is carried by the differential in the same manner as with a full floating type. It will therefore be seen that the radial load of the wheel is carried on the single bearing at the end of the housing, and this bearing is also required to carry the end thrust. The binding strains that are imposed upon the wheel when turning corners, for instance, are provided for through the rigidity of the driving shaft, which is fastened solidly into the wheel hub at its outer end and which is carried by the differential at its inner end. This gives a leverage equal in length to the distance between the outer bearing and point of support in the differential.




Fig. 29 Diagram Illustrating Theory of Back Firing

Backfiring, Causes of. This is a term applied to an explosion or impulse which forces the flywheel of a motor suddenly backwards, that is, in the opposite direction to its proper rotation. The term is sometimes used in connection with explosions which occur in the muffler from the ignition of an accumulation of unburned gases.

When a back kick occurs and the crank-shaft rotates in the reverse direction, that rotation must first be stopped and a rotation started in the correct direction. To stop the back kick or reverse rotation requires power, and to again start the correct rotation calls for power. The forces that stop the back kick are, the arm of the person cranking the weight of the rotating flywheel, and forcing one of the other pistons to compress the mixture. The force that starts the flywheel in the correct direction is the exploding charge of gas in cylinder No. 2 as illustrated in Fig. 29, in which the piston in No. 1 cylinder has not reached the top dead center on the compression stroke when the spark occurs and the reverse movement of the crankshaft starts. In tracing out what happens the valve locations must be considered. Both valves-intake and exhaust-in No. 1 cylinder are closed on the compression stroke and they will remain closed on the back kick stroke. Had the motor been running, No. 2 cylinder would have been going down on the explosion

stroke of the piston, but as there was no previous explosion, the motor having been idle, the cylinder would be filled with mixture, with both valves closed, as they always are on the explosion stroke. The piston in this cylinder was normally going down; but, as soon as the back-fire occurred, the piston would start up and the valves remaining closed, the mixture would be compressed. This pressure would help to stop the back kick, and as soon as the power of back-kick was over the compression would start the piston down on the proper explosion stroke, which would prove of sufficient power to carry the motor past the firing point in the other cylinders. Cylinders 3 and 4 would not be factors at all, in that the piston in No. 3 would, when the back-kick occurred, be near the bottom or end of the suction stroke with the intake valve open, and when the reverse action of the piston set in it would start rising, simply driving the mixture out through the open intake valve and through the carbureter. Cylinder No. 4 was near the completion of the exhaust stroke when the back-fire started, and the exhaust valve was open. During the reverse motion caused by the back fire, the piston would start descending, the exhaust valve remaining open, exhaust gases would be drawn into the cylinder from the exhaust pipe.

Other causes of back firing are,

(1) A WEAK MIXTURE. Bearing in mind that the mixture is the fuel of the engine, and that

as in a stove, the character of the fuel influences its manner of burning, it will be evident that like poor wood, slaty coal, or other imperfect fuel, a weak mixture is a slow burner. This is point number one. Proportionate to the speed at which it is running, the motor has a certain sharply defined period of time in which it must complete each part of its cycle, if it is to operate satisfactorily. Should the parts of the cycle lap, or run over into one another, there is bound to be a hitch of some kind. The use of a very weak mixture causes just such a hitch by reason of the fact that it continues burning for some time after the completion of the part of the cycle during which it is supposed to function, i. e., the power stroke. In fact, it is still burning when the inlet valve opens to take in a fresh charge, and as its burning in the cylinder maintains considerable pressure therein, the latter, on the lift of the inlet valve, escapes through it and the carbureter with a pop. exactly similar to that of an unmuffled exhaust except that it is weaker. The remedy is more gas or less air, or sometimes both, and to find out just how much of each is required, start the motor and very gradually cut down its gasoline supply at the needle valve of the carbureter until the motor begins to miss. Then as slowly increase the supply until the motor will run steadily and without missing on the minimum opening of the needle valve. Lock the latter in place. Then speed the motor up by

opening the throttle and adjust the spring of the auxiliary intake on the carbureter until the motor is receiving sufficient air to enable it to run and develop plenty of power at all speeds.

- (2) An overheated combustion champer, due to a poor circulation of the cooling water—causing self-ignition of the charge before the proper time.
- (3) Advancing the ignition point too far ahead when the motor is running slowly under a heavy load—flywheel has not sufficient momentum to force the piston over the dead center, against the pressure of the already ignited and expanding gases.
- (4) THE PRESENCE OF A DEPOSIT OF CARBON (SOOT) or a small projecting surface in the combustion chamber which may become incandescent and cause premature ignition.

Batteries. But two forms of batteries are used in automobile work, the dry cell and the storage battery. Both are described in the following pages. A distinction should be noted between battery and cell. A single unit, complete in itself and capable of giving a flow of current, whether of the dry or storage type, is a cell. The ordinary dry cell gives a voltage of 1½ while a storage cell gives approximately 2 volts. When it is desired to secure higher voltages, two or more cells are used in conjunction with each other and the set then becomes a battery. A single cell is not a battery.

Batteries—Dry. A dry battery of the usual type consists of a zinc cell which forms the negative element of the battery.






Fig. 30
Six Cells Boxed to Make
a Battery

Fig. 31 Section Through Dry Cell

DRY BATTERIES are very generally used on moderate speed and low-priced cars. They are simple in construction, comparatively simple in operation, and their action is easy to understand. Each cell is composed of three elements: The carbon, the zinc, and the electrolyte. The carbon usually takes the form of a round stick placed in the center of a cylindrical vessel made of zinc in sheet form. The space between the carbon and the zinc is filled with the electrolyte,

generally a solution of sal-ammoniac, which is poured in on crushed coke. The top is closed, or rather sealed, with pitch to prevent the loss or evaporation of the liquid. Through this, project the ends of the carbon and the zinc, these being formed into binding posts for holding the wires. As this holding of the wires must be an intimate relation, the usual form is a threaded shank upon which a pair of nuts are mounted. Between these the wire to be connected is crushed or compressed by the moving together of the nuts.

The two poles or binding posts are called the positive and the negative, and are indicated by the + sign for the former and the — sign for the latter. Carbon being the positive element, the + sign attaches to it. Now, the act of connecting these terminals together so as to allow a flow of current allows of two different methods of procedure, a right and a wrong way, it is true, but that was not what was meant.

In one respect dry batteries have a decided advantage over storage batteries for ignition purposes, from the fact that on account of their high internal resistance they cannot be so quickly deteriorated by short circuiting.

On account of this high internal resistance, dry batteries will not give so large a volume of current as storage batteries, but a set of dry batteries may be short circuited for five minutes without apparent injury and will recuperate in from twenty to thirty minutes, while a

storage battery would in all probability be ruined under the same conditions.

It is often desired to secure a greater voltage than one cell will give, or else to secure a source of current that will give a greater time of service than can be secured from the single cell. In either case, it is customary to combine two or more cells in certain definite combinations and connect them with each other in such a way that the desired voltage or length of life is realized. It is possible to make such combinations by using either dry or storage cells, although storage cells are usually boxed after forming.




Fig. 32

The Ordinary Battery Connection, in Series

Two methods are usually employed, viz.: series, and multiple, or parallel. To connect dry batteries in series, the terminals are joined alternately, that is, the zinc of the first is connected to the carbon of the second, the zinc of the second to the carbon of the third, etc.

When so joined, the positive element is left free at one end, and forms the positive terminal of the group, which is then considered as a unit. The other free end (the negative) forms the negative terminal of the unit, see Fig. 32, which shows four cells connected in series.

Figure 33 shows four cells connected in parallel which means that all of the positive terminals are connected to one common wire, and all negatives are connected to another wire.

This mode of wiring up the cells gives a smaller output for the group. Thus if the individual batteries have an internal resistance





Fig. 33
Parallel Connections are Not as Frequently Used

which is low in comparison with the external resistance, the total output will be but slightly more than that of a single cell. If, on the other hand, the internal resistance is high relative to the external, the current will be roughly proportional to the number of cells.

Where the cells are divided into sets or groups of a small number (four is usual), and more than one of these sets are used at a time, there are again two methods of joining them. These two are the same as before, viz., series and multiple.

The former is very seldom used, if ever, but the other is rather common. When two or more sets of batteries, themselves connected in series are, as sets, joined in multiple the whole is spoken of as connected in series-multiple.



Batteries—Storage. A storage battery as used in ignition service, is usually of the leadacid type, in which the electrolyte is sulphuric acid and water of a density about 1.2— specific gravity. The plates are of two classes—positives and negatives—there being one more negative than positive in each nesting in a cetl. The elements of a cell of storage battery are

given In Fig. 35, and consist of the following: Positive plates A, of which there is one fewer than of negatives; negative plates B, of which there is always one more than positives; sepa-



Fig. 35
Elements of Assembled Battery

rators C, which may be of wood, rubber, or other suitable material, and if of wood must be treated; positive strap D, the function of which is to connect all the positive plates, across the top, into electrical relation; negative strap E, the function of which is to connect all the negative plates, at the top, in electrical relation; battery jar F, made of rubber composition, light, strong and acid proof; cover for the jar G, with holes for the terminals of the elements, and a vent; assembled cell of battery H, showing the elements in place, separated, with cover on; ready for connections; and a battery box I, of oak, usually contrived to hold three cells of battery, sometimes two.

The positive and negative plates, called elements, consist essentially of a grid in each case, made of lead-alloy, in which antimony is used to engender stiffness. The grids are in divers forms, depending upon the views of several makers, the idea being to afford space for the active material, and to lock the same in, so that it will not drift out, as it is prone to do, under the action of the charging, and discharging current. Surface is the great requisite, and it is the aim to afford the maximum area of the finished plates, per pound of active material used; limiting the weight of the supporting grid, in so far as it is possible to do so.

The voltage of a battery of this type is usually 2.2 volts when the circuit is closed, but it drops to 2 volts within the first hour of using, which pressure it usually maintains during the next 5 hours, after which the voltage declines at a rapid rate.

ADDING WATER TO CELLS. In service water

will have to be added to the cells to compensate for evaporation, and for the loss that takes place during charge. brought about by the entraining of water with the bubbles of gas that shoot off and out of the jars, if they are open, that is to say, if the covers are removed before and left off during charging, which is not usually the case. The result in any event is in favor of increasing strength of the electrolyte, and water will have to be added from time to time in order that the plates may not be exposed to the atmosphere above the line of active material; which is a point that must be cared for if the battery is to last for a long time. The water so added should be pure-distilled-and the right quantity to add, will be determined by means of a hydrometer placed in each cell between the separators if there is sufficient room, or the electrolyte may be withdrawn through the utility of a gun made of hard rubber with a long slender neck. The test should be made when the battery is charged and every cell should be examined rather than to test one cell and conclude that all are in an average condition.

Storage Batteries—Care of. Among the troubles that ultimately attend batteries in service the following are the most conspicuous:

Hardening of negative elements; local action; buckling of plates; shedding of active material; sulphation; reversal of negative elements; disintegration of grids; protruding active material; deformation of separators; broken jars; in-

eipient short circuits; defective electrical conact; loss of capacity; loss of voltage; corrosion of plates, and needle formations.

Hardening of the negative elements will folow if they are exposed to air, as when the elecrolyte is allowed to fall below the level of the plates, from any process that will produce overexidization if the temperature is allowed to inerease much above 90 degrees Fahrenheit. When the negative elements are hard, to reduce them back to the normal condition, assuming the process is not too far gone: Remove the elements from the jar, place the negatives in a ell, with dummy positives, and charge until the negatives are corrected, taking care not to charge at a too high rate. High temperature and excess boiling should be avoided. If the regatives are charged in their own cell with the regular positives the positives will be damiged by the excess charging that will be necesary to reduce the negatives. When the negaives are sufficiently charged to correct the evil hey may be returned to their own cell, and when connected up with the positives the cell vill be ready to go into service again, if in the neantime the positives are given such attention is their condition would seem to indicate. Local iction, following impurities in the electrolyte, vill only be prevented as much as it is possible o do so when the electrolyte is removed and oure electrolyte substituted in its stead. This hould be done when the cells are fully charged

The electrolyte will hold most of the impurities when the battery is in the fully charged state.

Buckling of plates, when batteries are defective in design, rather than in cells of normal characteristics, is a trouble that will follow in any cell if the discharge is allowed to extend below 1.8 volt as indicated by the cadmium test, rather than by the usual potential difference reading across the two sets of elements in the cell. If the rate of discharge is excessive, a condition that is not likely in ignition work, buckling will follow also. Short-circuiting the elements to see if the battery is alive will tend to buckle the plates, due to the heavy discharge, and the uneven rate of discharge over the surfaces of the elements. In defective construction, if the active material is not of the same porosity, thickness, and in the same condition all over the surfaces of the plates, buckling will follow.

Shedding of the active material, to a slight extent, is a normal condition of batteries; and to prevent trouble due to incipient short circuits, such shedding is cared for by having a space in the bottom of cells to hold such shedded material. When elements are of inferior design and improperly constructed the active material will shed at a rapid rate, and the user of the battery can do nothing more than demand a new battery to replace the defective one. If charging is done at a too rapid rate the active material will be loosened by the rapidly escaping gas, and even on discharge, if the

is high, the shedding of active material is y to follow.

alphation, which is a normal expectation ng discharge of a battery, introduces serious plications under certain conditions as when active material is not in intimate contact 1 the grids thus allowing the electrolyte to between the grids and the active material, h the result that sulphate, which is a high stance material, isolates the grids and rees the efficiency of the cell in two ways; t, by increasing the ohmic losses, and, second, lowering the chemical activity. Excess sulte is prone to form when the electrolyte is of balance, and one of the best ways to rt this action is to keep the electrolyte withhe prescribed limits of strength. If sulphate llowed to form until white crystals show over surfaces of the plates, it is highly improbthat the cells will ever be of sufficient servto warrant continuing them in service. The y way to afford relief lies in reducing the wth of sulphate by continuous charging the : elements in a cell with dummies until the shate is reduced. A slow rate for a long e may bring about a reform.

egative elements to be reversed must be w capacity, or the cells must be discharged zero and then reversed. In charging it is ays necessary to make sure that the connecs are made in such a way that current will into the battery, rather than out of it. Volt-

meters in which permanent magnets are used will serve as polarity indicators, and with them it is possible to proceed with safety. If a battery is connected up in reverse when it is put on charge, instead of being charged it will be discharged, and then charge in reverse. While it is discharging it will deliver current to the line.

Disintegration of grids will follow if the impurities are allowed to enter the electrolyte, as iron, etc. Continued charging will also have the effect of reducing the grids to form salts of lead.

Protruding active material, due to expansion and displacement of the same, indicates a lack of binding relation between the grids and the active materials. There is no remedy. Deformation of separators, when they are made of rubber compound, follows when the cells are allowed to heat beyond a certain point. This trouble will be aborted if the cells are charged at a normal rate, and if the temperature is not allowed to increase beyond about 90 degrees Fahrenheit. When wood separators are used they will slowly rot and in time it will be necessary to replace them.

Broken jars will allow the electrolyte to leak out, and frequently the fracture is but a minute crack, so that it is well to be on the lookout for just this kind of trouble. If the jars are properly nested and motion between them is prevented they will as a rule serve without breaking.

Incipient short circuits are likely to go unnoticed. They are generally due to detached particles of active material that lodge between the plates, especially in vehicle and ignition types, owing to the short distance separating the plates, and the use of separators, such as perforated rubber in the absence of wood, which have the virtue of being porous but too close to allow the active material to bridge across the space between the plates.

Defective electrical contact is due to corroding of joints that are not made by burning.

Loss of capacity may be traced to such causes as: If the electrolyte is out of balance or below the level of the top of the plate; loss of active material from the grids; sulphate formed on the surfaces of the grids, isolating the active material; lack of porosity of the active material; impurities and sulphate clogging up the pores of the active material; low temperature; high temperature; persistent sulphation, and intercell leakage due to electrolyte spilled over the surfaces, especially if jars are in actual contact with each other.

Loss of voltage, as distinguished from loss of capacity, follows in a battery when one or more of the cells are dead or below voltage. If one or more of the cells are reversed they will set up a counter-electro-motive force, and the over-all reading of the battery will be reduced accordingly. The remedy is obvious. All the cells

should read the same way, and all should hav the same difference of potential, respectively.

In view of the sulphated condition that at tends all batteries that are discharged at a lov rate for a long time, as is the case in ignition work, it is necessary to charge at a low rate fo a long time in order to reduce the sulphate which is in persistent form and very difficul to reduce. It will not be enough to correct th strength of the electrolyte once during the charging process for the reason that it will b difficult, if not impossible, to ascertain the con dition of the same with any degree of accuracy and the necessity for noting strength two o three times in the act of charging is apparent When the battery is fully charged, which may take even sixty hours of continuous charging at a low rate, the electrolyte in every cell should stand at full strength, considering a state o full charge, and the color as well as other indi cations of a full charge should be fully noted Boiling at a slow rate should be tolerated for several hours, but the temperature should be held at about 90 degrees Fahrenheit during the entire time. If a battery is charged at frequen intervals it will last longer in service, give les trouble in charging and will be more reliable in service. It is well to begin charging directly a battery is taken out of service as any delay after that time will result in a marked deteriors tion of the cells.

When a car is put out of commission, ever

for a few weeks, the battery should be given a light discharge, and a subsequent charge as often as once a week, until it is again brought back into use.

STORAGE BATTERIES — CHARGING. Positive plates in the charged state are of a velvety brown or chocolate color; negative plates have the color of sponge lead, which is very nearly light gray. When a battery is approaching a condition of full charge the color tones up quite noticeably, and it is possible to mistake a condition of full charge, if color alone is taken as the evidence; the exterior will have the appearance of full charge, since the active material, on the exterior surface, will reach its charged form first; if the thickness of active material on the grids is very thick, as it is likely to be in low discharge rate work, charging by color, as evidence of a state of full charge, will be to limited advantage. Details regarding the proper care and upkeep of storage batteries are given in the following pages.

STORAGE BATTERIES—TESTING. Tests for impurities in the electrolyte may be made as follows. For iron;


Neutralize a quantity of the electrolyte to be investigated, after diluting the same, by the addition of an equal amount of pure distilled water, using strong ammonia water for the purpose. To the solution, so neutralized, add one-thirtieth of the amount of the same of hydrogen peroxide, thus reducing any iron present

to the ferric state. If a sample of this solution is rendered alkaline by the addition of a sufficient quantity of ammonia water, then, if iron is present, enough to amount to anything of great moment, from the battery point of view, a brownish red precipitate will form. A test for chlorine is as follows:

Make a solution of nitrate of silver in the proportion of 20 grams of the same, in 1,000 cubic centimeters of pure distilled water, and add a few drops of this solution to a small quantity of the electrolyte to be investigated; if chlorine is present the solution will turn white, owing to the formation of chloride of silver, which will precipitate out.

A test for nitrates is as follows: In a test tube, holding 25 cubic centimeters of electrolyte to be tested, add 10 grams of ferrous sulphate; to this carefully add 10 cubic centimeters of chemically-pure sulphuric acid by pouring the same slowly down the side of the tube; in the presence of nitric acid, a brown solution will form between the electrolyte to be tested, and the concentrated solution of sulphuric acid.

The presence of copper may be detected from the fact that when ammonia solution is added to electrolyte, a bluish-white precipitate will form. In testing for mercury, lime water, if it is added to electrolyte in which mercury is present will evolve a black precipitate. Testing for acetic acid is as follows: To a small quantity of the electrolyte to be tested, add enough ammonia water to render the same neutral; ferric chloride added to this solution will cause the same to turn red in the presence of acetic acid and the solution will then bleach, provided hydrochloric acid is added, thus affording conclusive proof of the presence of the undesired acetic acid.



Section Through Storage Battery Used For Lighting and Engine Starting

Types. The foregoing description and instructions relating to storage batteries apply equally well to ignition, starting and lighting types. The following rules include the standard battery instructions adopted by the Society of Automobile Engineers for the installation and care of batteries used in connection with electric lighting and starting systems.

Batteries must be properly installed. Keep battery securely fastened in place. Battery must be accessible to facilitate regular adding of water to, and occasional testing of, solution. Battery compartment must be ventilated and drained, must keep out water, oil and dirt and must not afford opportunity for anything to be laid on top of battery. Battery should have free air space on all sides, should rest on cleats rather than on a solid bottom, and holding devices should grip case or case handles. A cover, cleat or bar pressing down on the cells or terminals must not be used.

Keep battery and interior of battery compartment wiped clean and dry. Do not permit an open flame near the battery. Keep all small articles, especially of metal, out of and away from the battery. Keep terminals and connections coated with vaseline or grease. If solution has slopped or spilled, wipe off with waste wet with ammonia.

Pure water must be added to all cells regularly and at sufficiently frequent intervals to keep the solution at proper height. Add water until solution is level with inside cover. Never let solution get below top of plates. Plugs must be removed to add water, then replaced and screwed on after filling. The battery should preferably be inspected and filled with water once every week in warm weather and once

every two weeks in cold weather. Do not use acid or electrolyte, only pure water. Do not use any water known to contain even small quantities of salts of any kind. Distilled water, melted artificial ice or fresh rain water are recommended. Use only a clean metallic vessel for handling or storing water. Add water regularly, although the battery may seem to work all right without it.

The best way to ascertain the condition of the battery is to test the specific gravity (density) of the solution in each cell with a hydrometer. This should be done regularly. A convenient time is when adding water, but the reading should be taken before, rather than after, adding water. A reliable specific gravity test cannot be made after adding water and before it has been mixed by charging the battery or running the car.

To take a reading insert the end of the rubber tube in the cell. Squeeze and then slowly release the rubber bulb, drawing up electrolyte from the cell until the hydrometer floats. The reading on the graduated stem of the hydrometer at the point where it emerges from the solution is the specific gravity of the electrolyte. After testing, the electrolyte must always be returned to the cell from which it was drawn. The gravity reading is expressed in "points," thus the difference between 1.250 and 1.275 is 25 points.

When all cells are in good order, the gravity

will test about the same (within 25 points) in all. Gravity above 1.200 indicates battery more than half charged. Gravity below 1.200, but above 1.150, indicates battery less than half charged. When the battery is found to be half discharged, use the lamps sparingly until the gravity is restored to at least 1.250. If by using the lamps sparingly, the battery does not come back to condition, there is trouble in the wiring or generator system which should be investigated and remedied immediately. Gravity below 1.150 indicates battery completely discharged or "run down." A run down battery is always the result of lack of charge or waste of current. If, after having been fully charged, the battery soon runs down again, there is trouble somewhere in the system which should be located and corrected. Putting acid or electrolyte into the cells to bring up specific gravity can do no good and may do great harm. Acid or electrolyte should never be put into the battery except by an experienced battery man.

Gravity in one cell markedly lower than in the other, especially if successive readings show the difference to be increasing, indicates that the cell is not in good order. If the cell regularly requires more water than the others, thus lowering the gravity, a leaky jar is indicated. Even a slow leak will rob a cell of all of its electrolyte in time and the leaky jar should immediately be replaced with a good one. If there is no leak and the gravity is, or becomes, 50 to 75 points below that in the other cells, a partial short circuit or other trouble within the cell is indicated. A partial short circuit, if neglected, may seriously injure the battery and should receive the prompt attention of a good battery repair man.

A battery charge is complete when, with charging current flowing at the finish rate given on the battery plate, all cells are gassing (bubbling) freely and evenly and the gravity of all cells has known no further rise during one hour. The gravity of the solution in cells fully charged as above is between 1.275 and 1.300.

If for any reason an extra charge is needed it may be accomplished by running the engine idle, or by using direct current from an outside source: In charging from an outside source use direct current only. Limit the current to the proper rate in amperes by connecting a suitable resistance in series with the battery. Incandescent lamps are convenient for this purpose. Connect the positive battery terminal (with red post, or marked P or +) to the positive charging wire and negative to negative. If reversed, serious injury may result. Test charging wires for positive and negative with a voltmeter or by dipping the ends in a glass of water containing a few drops of electrolyte, when bubbles will form on the negative wire. When charging, start at the starting rate and continue the charge at this rate until the cells gas freely. Then continue the charge for six hours at the finish rate. The specific gravity at the end of the charge should read between 1.275 and 1.300. If the specific gravity does not reach this point, continue the charge at the finish rate until the specific gravity stops rising, which is an indication that the battery is fully charged.

A battery which is to stand idle should first be fully charged. A battery not in active service may be kept in condition for use by giving it a freshening charge at least once a month, but should preferably also be given a thorough charge after an idle period before it is replaced in service. Disconnect the leads from a battery that is not in service, so that it may not lose charge through any slight leak in car wiring.

Bearings, Ball. Ball bearings may be broadly divided into three classes—thrust, cone and annular. Thrust bearings are those intended to sustain end thrust, and in them care must be exercised to see that the points of contact of the balls are exactly opposite, and that the grooves in which the balls run are formed to a sectional radius a little larger than that of the balls, thereby securing safe and easy movement of the balls. These grooves must be designed not only to give smooth rolling contact, but so that a measurable area of the ball's surface contacts with the race. It is also possible for a thrust bearing to act at the same time as a radial bearing, in which case, however, the four-point system must be used. In thrust bearings the balls are constantly under pressure and table 5 gives suitable loads for equal shaft diameters and revolutions for different sizes and numbers of balls:

TABLE 5.

| Shaft Diameter, in inches. | Allowable Load lbs. | R.P.M. | Number of Balls | Ball Diameter in Inches |
|----------------------------------|-------------------------|--------------------------|----------------------|-------------------------------|
| 2.55 2.55 2.55 2.55 | 1,000 1,200 1,300 | 500 500 500 500 | 22 15 14 13 | % 5% 11/16 |
| 2.55 2.55 2.55 | 1,800 1,600 1,800 | 500 500 500 | 13 12 10 | % 1 1 |

The adjustable cone bearing, Fig. 39, has been used in millions of bicycles with excellent results, but under large loads has been found inadequate. A ball can roll freely only with opposite points in contact, and every third or

fourth point of contact involves more or less spinning, or sliding movement of the ball, which shortens its life, and the bearing must operate to the detriment of the contact surfaces.

The third and great type of ball bearing is the so-called annular one intended for radial loads. It consists of three elements—two races and the balls. The new annular bearings require no adjustment or fitting, and the rolling action of the balls takes place without interference of friction. A wonderful advantage of this bearing is that as high as 96 per cent of the space between the races can be filled with balls, the balls being introduced through filling lots whose size is a little less than the diameter of the balls to be introduced, so that the balls are forced between the two races under pressure and by virtue of the elasticity of the material. In the annular bearing but 30 per cent of the balls are under load at one time, and it is possible for equal axle sizes and speeds to use different dimensions and loading according to the size of the balls. Table 6 gives suitable loads for equal shaft diameter, and revolutions for various sizes, and numbers of balls.

TABLE 6.

| Shaft Diam. inches | Allowable load on Bearing, lbs. | R. P. M. | No. of Balls | Diam. of Balls, Inches |
|--------------------------|---------------------------------------|----------|-----------------|------------------------|
| 3.14 | 1,000 | 500 | 20 | 1/2 |
| 3.14 | 1.300 | 500 | 21 | 18 |
| 3.14 | 2,500 | 500 | 12 | 1 |
| 3.14 | 3,000 | 500 | 14 | 1 1 |
| 3.14 | 4.500 | 500 | 1 11 | 1 134 |

Annular ball bearings are also made with two rows of balls, and in the majority of them each ball is in a separate cage. Experiments have proven that, where the balls contact with one another, after a few years the friction results in grooves being worn in them. In Fig. 37 is shown the form of separator used in the F. & S. bearings. If in the application of this bearing it is




Fig. 37
F & S Bearing Separator

necessary to sustain heavy axle loads, it is absolutely necessary to add an independent thrust bearing, or to employ a combination bearing which takes the place of bolt thrust and radial loads.

BALL BEARINGS—Two IN ONE. Figs. 38, 39, and 40 illustrate a ball bearing manufactured at Bristol, Conn., which owing to its dual ability as

as expressed by its name ("two in one") is especially adapted to automobile service. Its makers claim that it is able to withstand radial or thrust loads, or any combination of the two, with the use of but a single bearing with its attendant simplicity of mounting. In order to bring about this result, two rows of balls are employed in staggered relation to one another, and the ball races are so arranged that the line




Fig. 38
Assembled Bearing Complete

of pressure is either at an angle of 45 degrees or 60 degrees with the horizontal, when the axis of rotation of the bearing is in a horizontal plane.

Figure 38 shows the permanent assembly of the bearing, sufficient metal being provided in the shell to permit of drawing the latter tightly over the cups. Figure 39 shows the various parts of this bearing, and Fig. 40 is a semi-sectional view showing the order of their assembly, from the shaft outward, as follows; the cone, the separator, the two cups and the shell. It will be noticed that the line of pressure of the cone, cups,



Fig. 39

and balls is at an angle of 45 degrees with the horizontal, and this feature applies equally to both rows of balls, thus adapting the bearing to withstand a load from any angle. Two semi-circular races are turned in the cone to receive the balls, while the sheet metal separator is so stamped that the ball retaining notches are

staggered with reference to each other. These openings are made slightly larger than the ball diameter, so that the contact between the ball and separator is said to be a point contact at one end of the axis of rotation, while the weight by separator is carried on the balls at the top of the bearing. By maintaining the relative positions of the balls at all times, cross friction



Fig. 40 Sectional View of Bearing

it is claimed is entirely communated, while the friction introduced by the use of the separator is practically negligible.

Ball Bearings—Lubrication of. Ball bearings must be so housed in as to retain lubricant and exclude dust, grit, etc. An impression that ball bearings will operate without lubricant is quite general. It is barely possible that absolutely true spheres might roll on absolutely

true surfaces if both were made of materials that were absolutely inelastic, and therefore would remain true under load. But since such absolute perfection of the shape is not to be had, some means must be taken to provide and retain lubricant.

Rust and acid must be kept out of ball bearings. Experience and most carefully conducted tests have proven that long life under load can be realized from ball bearings only when the surfaces are not only true, but are also highly polished and smooth. Roughness will be broken down and leave still greater roughness. Rust and acid will destroy originally true and smooth surfaces. Since not a few lubricants contain free acids, care in their choice must be exercised. Plentiful lubrication and a properly closed mounting are safeguards against rust.

In the lubrication of ball bearings it is advisable to use vaseline; or, when a lubricant of greater body or stiffness is desired, to use a mixture of vaseline and some high-grade mineral grease. The grades known as semi-fluid are very well suited for this use and any combination may be used with success in such cases.

Annular Ball Bearings. In the annular ball bearing, Fig. 42, a race of balls C is contained between an inner retainer A and an outer race B, there being grooves in the opposing surfaces of these to receive the balls. In a Hess-Bright

bearing of this type, as illustrated in Fig. 41, the entire space between the races C and B is not occupied by balls, but is utilized in different ways. In this only enough balls to make a half circle in the bearing are used, and these are spaced apart by means of small helical springs. These springs contain oil pads of felt, and are headed by sheet-metal discs that extend far




Fig. 41 Hess-Bright Bearing

enough into the grooves to prevent sidewise displacement of the springs, without, however, producing any more than a negligible friction. Assembling this bearing one race is placed eccentric to another race and the requisite number of balls slipped into positions, after which the races are made concentric and the balls regularly distributed. This done, the separating springs with lubricating means are installed. Once the springs are in place the tension of them is such as to make the bearing self-contained.





Fig. 42 Annular Ball Bearing

It is not practicable to disassemble or repair the various forms of annular ball bearings in the ordinary shop. These forms are not adjustable and are not designed to be taken apart. It is quite possible to reform the races and to insert new balls when the bearing is badly worn or scratched, but such work must be done with machinery and tools especially designed for handling it. Ball bearing repairs are handled by various companies who specialize on such work and it will always be advisable to communicate with one of them.

HARD AND SOFT BEARINGS. There are two general classes of solid bearings, those which contain a large per cent of copper and a small amount of the softer metals; which are known

as hard metals, as brass or bronze. Those which contain a large proportion of tin or lead and a small per cent of copper are known as soft metals—as babbitt-metal, anti-friction metal and white metal.

In some instances and under certain conditions it has been found that a good close-grained cast iron makes an excellent bearing metal. Being of a granular nature, it has the property of retaining the lubricant in place, even when highly polished and under great pressure, with



a low co-efficient of friction, but is too brittle to withstand severe shocks.

Plain Bearings. Plain solid bearings are used on many parts of an automobile, particularly in the engine and transmission bearings, although ball and roller bearings are taking their place in many constructions. The majority of the cars use brass, bronze or babbitt-metal on the main and crankshaft bearings, while ball and roller bearings are used on the transmission and wheel bearings. A typical plain bearing is shown in Fig. 43, in which A is the journal made of steel, while the bearing members shown at

B. B. are made of either brass, bronze, or babbitt metal. Figures 44 and 45 show different types of connecting rod bearings. For plain-bearings, the shafts of which are continuously running at a high rate of speed, such as motors and speed-change gears, the working pressure




Fig. 45
Solid Connecting Rod Bearing

per square inch should not exceed 400 pounds. As the arc of contact or actual bearing surface of a journal bearing is assumed as one-third of the circumference of the journal itself, the pressure per square inch upon a bearing is therefore equal to the total load upon the bearing, divided

by the product of the diameter of the journal times the length of the bearing.

Let D be the diameter of the journal or shaft at its bearing, and L the length of the bearing, if W be the total load or pressure upon the bearing and P the pressure in pounds per square inch of bearing surface, then

$$P = \frac{W}{D \times L}$$

If the total load or pressure on the bearing be known and the diameter of the shaft given, then the proper length of the bearing will be

$$L = \frac{W}{D \times P}$$

If the length of the bearing be known and other conditions as before given, then the proper diameter of the journal will be

$$D = \frac{W}{P \times L}$$

Bearing, Roller. A form of bearing used in a large number of cars of all types is that known as the roller. This form is made in three distinct types, one of which is known as the taper roller, another one the solid straight roller, and the third one the flexible roller.

The taper roller bearing, Fig. 46, is composed of an inner and outer race, the inner race being




Fig. 46
Taper Roller Bearing

designed to fit over the shaft and the outer one being carried by the bearing housing. The outer surface of the inner race is conical in form and the inner surface of the outer race is of a form to correspond, that is, its internal diameter is smaller at one side than at the other. Between the two races is carried a series of steel rolls, each one of which is tapered so that it fits between, and bears along its entire length on both races. This forms a bearing of anti-friction qualities similar to the annular ball, with the exception that the contact between the rolling members and their supports




Fig. 48
Hyatt Self-Oiling Self-Contained Roller Bearing

is a line rather than a point. It is customary to maintain a predetermined distance between the separate rolls by providing cages into which the rolls fit loosely. It will be seen that because of the tapered formation it would be impossible to press the inner race hard enough to cause it to pass completely through the outer race with the rolls in place, while in the other direction the inner race would drop out because of its own weight. This feature allows the tapered roller bearing to withstand a large amount of end thrust when this thrust is applied on one side of the bearing only.




Fig. 47 Straight Solid Roller Bearing

Roller bearings are made of an inner and outer race with both surfaces of each race truly cylindrical, Fig. 47, and between these races is carried a series of straight cylindrical rolls. With plain rolls in use, the bearing will not withstand any end thrust because of the fact that the races and rollers will move freely over

each other in the direction of their axes. When it is desired to have this type of bearing withstand a thrust load, one or both of the races must be made with either a ridge or a groove at or near one edge and the rolls must then have a corresponding ridge or groove to engage the race.

The flexible roller bearing is made by the Hyatt Roller Bearing Co. and consists of two races, each of which is tubular or cylindrical in form, and between these races is carried a series of rollers, as in other types previously described, differing in that the rolls are formed from a piece of comparatively thin flat steel twisted into a spiral. It is from the springiness of this form of spiral roller that the bearing takes its name, "Flexible."

Bendix Drive. The Bendix drive, Fig. 49, consists of a solid or hollow shaft having screw threads on the outside, and a hollow gear having screw threads on the inside, so that the gear screws on the shaft like a nut on a bolt. A circular weight is fastened to the gear, and is slightly out of balance. A coil spring connects the electric motor shaft and the hollow screw shaft.




Fig. 49
Starting Motor With Bendix Drive

When the electric motor starts it drives through the spring and turns the screw shaft. Because of the weight, the gear is too heavy to turn with the screw shaft, and because the gear does not turn it must move along the screw shaft (just the same as if you turned a bolt having a nut on it, and kept holding the nut with your fingers to keep it from turning so that it would be screwed along the bolt). After the screw gear has moved along the screw shaft and engages with the flywheel gear it then keeps on moving along until it reaches

the stop at the end of the screw shaft. The two gears then are fully meshed, and it is obvious that when the screw gear has reached the stop it cannot move any farther, and it then must turn with the screw shaft. At this particular moment the screw shaft and electric motor are revolving at a great speed, and this great blow and the power of the electric motor are both taken through the coil spring. The spring keeps coiling until all this power has been applied to the flywheel gear and the engine starts turning.

As soon as the engine starts exploding and runs under its own power, the flywheel of course turns much faster than it was cranked by the starter. Because it is now turning so much faster it increases the speed of the screw gear so that the latter runs faster than the screw shaft on which it is mounted. It is therefore plain that if the screw gear runs faster than the screw shaft, that it will be screwed on the threads of the shaft (like a nut on a bolt) until it has been screwed out of mesh with the flywheel gear. This demeshing movement is entirely automatic and eliminates the use of an overrunning clutch. And now that the screw gear is out of mesh it is natural to suppose if the electric motor keeps running that the gear will be automatically screwed right back into the mesh with the flywheel gear. But the unbalanced weight on the screw gear performs its automatic function. That is, being slightly out of balance, the weight twists or cocks the screw gear so that it clutches and binds on the screw shaft and turns with it. This automatic clutching is all due to the centrifugal force of the unbalanced weight.

When the electric motor stops running, the screw gear has been fully screwed away from the flywheel gear, and it remains in that retarded position until it is again required to start the engine.

The screw shaft should never be oiled or lubricated. It is not necessary and, in fact, the screw gear works to the best advantage when the screw shaft is dry.

Through accident or otherwise, should the flywheel ever be entirely exposed and unprotected, and should the gear tend to stick on the shaft, it may then be necessary to clean the screw.

The teeth on the screw gear and flywheel are chamfered or pointed on only one side to make the meshing natural and easy. However, should the teeth meet, end to end, the screw shaft itself is designed to move automatically backwards, against and compress the coil spring. This gives the screw gear time enough to turn and enter the flywheel gear. Should sticking of gears ever occur, they can be released by throwing in the clutch and moving the car. Such trouble would be due to incorrect cham-

fering or inaccurate alignment of the gears. Also it might be due to the binding of the drive parts and prevent compressing and proper functioning. Such defects should be corrected.

If while the engine is running, the electric motor should be accidentally started, the screw gear will of course screw over against the turning flywheel gear. But instead of the clashing and smashing of gears that might be expected there is no damage whatsoever, as the gears simply touch once. This is because the flywheel gear will speed up the screw gear, and thus automatically screw it away. The turning screw gear will then automatically clutch and bind on the screw shaft, in exactly the same manner as when it is cranking and has been demeshed when the engine starts exploding.

Bodies. In the construction of automobile bodies the sills are made strong, and the superwork is rendered independent of the actual structural strains. Wood is generally used in the framing, although it is sometimes replaced by cast aluminum.

When wood is used for framing, sheet aluminum, steel and thin layers of wood are employed. The aluminum is laid on a form and beaten to the shape required for the panel. The steel sheets are die formed, while the wood is made flexible in order that it may be bent to its proper shape when fastened to the body. In order to have the car of light weight, all body builders use the lightest materials possible in

the construction of that portion which lies above the chassis.

When aluminum is used in the panels and for facings, care must be exercised to prevent water from creeping in between the metal and the framing, because water causes an electrolytic action on the aluminum plates. To prevent the oxidation of sheet steel, the plates are either coated with aluminum or zinc, or they are given a priming coat of paint on the inside.

As a general thing, putty is not used in the construction of bodies, as there are few joints which require it. In the very best body painting twenty coats are used before the paint assumes is proper finish. The first coat, or priming coat, generally consists of pure white lead mixed in oil. After that the second priming coat is given to it, and from then on the number of coats of rough paint will depend upon the nature of the surface and the degree of finish. For a very fine finish, the last coats consist of varnish, but when wagon finish is desired, the last coats consist of paint.

Finishers must take into account the fact that all cars are more or less abused in service, and it is to be expected that the magnificently equipped limousine will have a somewhat finer finish than the hard used touring car.

CLASSIFICATION OF BODIES. Besides being classified according to the type of gasoline engine, methods of transmission, number of cylinders, etc., automobiles are also classified ac-

cording to the type of body which is mounted on the chassis. While there are a considerable number of names which are given to the same types of pleasure automobiles, they may be generally classified as runabouts, roadsters, tourabouts, touring cars, town cars or taxicabs, landaulets, limousines and semi-limousines. Electric automobiles are generally divided into coupes, brougham, stanhopes, runabouts, phaetons, etc. Steam cars follow the same general classification as gasoline machines. Commercial vehicles may be classified as taxicabs, delivery wagons, trucks, busses, wagonettes, ambulances, patrol wagons and other forms for fire service.

COMMERCIAL VEHICLES. In the commercial vehicle field steam, electric and gasoline machines are used. Electric vehicles are used for certain purposes, from heavy trucks to light delivery wagons, usually only for short distances. Steam power is not at present being used to any extent for heavy trucks, while the gasoline commercial is used for trucks, business wagons and quick deliveries.

The commercial vehicle may be classed as follows: Taxicabs, general delivery, light trucks, heavy trucks, coal wagons, sight-seeing cars, busses, ambulances and particular other types for special purposes.

Since, for general purposes, the speed of commercial vehicles is small, they are not necessarily equipped with high power, as a heavy

car, which would travel at a high speed, would be apt to be dangerous. The speeds obtainable range on an average between twenty miles per hour for delivery wagons, to five miles per hour for heavy trucks.

While there are many distinct types of car bodies, there are more names in use than there are bodies, because different makers often apply different names to the same type of body, and often list a certain type of body under a name different from the one ordinarily accepted. This practice makes it difficult to state positively that a certain type of body will be called by a given name by a maker although that particular body is of its own distinctive type regardless of the name applied in the catalogues.

Bodies may be classified according to the number of persons carried, whether they are wholly or partly enclosed and according to the purpose




Fig. 50
Five-Passenger Touring Car
for which they are designed. None of these
divisions is very satisfactory, because some types

would appear in more than one division. The following definitions are those generally accepted.

Touring Car. This is an open car, Figs. 50 and 51, for general purposes which may seat four, five, six or seven persons, including the driver. It has sides and doors, but when protection from the weather is desired the operator uses a folding top and curtains.




Fig. 51

Seating Arrangement in Four-Passenger Car

A touring car scating five is called a five-passenger touring car, one scating seven is called a seven-passenger touring car, and so on for any number of passengers. The rear compartment of a touring car is called a tonneau, the front compartment is called the driver's compartment.

CLOSE-COUPLED OR TOY TONNEAU. A four-passenger touring car with the rear seat brought well forward is sometimes called by one of these names.

TORPEDO. This is a touring car having the body as small and low as possible while seating

the number of passengers desired. The body is of a form that offers the least resistance to wind pressure and is called "stream line" in shape.

RUNABOUT. This is an open body seating two passengers, mounted on a comparatively small, light or low powered chassis for use in town and city travel and short country trips.




Fig 52 Two-Passenger Roadster

ROADSTER. This is also an open body, Fig. 52, seating two passengers, but mounted on a chassis whose size, weight and power fits it for heavy work and long distance touring.

Speedster or Raceabout. This is a powerful chassis carrying small, light seats for two passengers and designed for high speed work. The body is made as small and light as possible with "bucket" seats, floor, dash, gasoline and oil tanks, but no sides or doors, and in most cases without a top.

LIMOUSINE. This is a type of body, Fig. 53, used mostly for town and city driving in bad weather or during the cold season.

It seats four, five, six or seven persons in addition to the driver. It has a permanent top and the rear compartment is entirely enclosed and has full doors. The driver's compartment is di-




Fig. 53 Limousine Body

vided from the rear by a partition and this compartment is only partly enclosed.

Berline or Berlin. This type is exactly like the limousine except that the driver's compartment is fully enclosed and has full doors.

Sedan. This body is like the Berline, that is to say, fully enclosed, but there is no partition between the driver's and rear compartment.

Landaulet or Landau. This is a limousine which has the rear half of the passenger compartment closed with a top that is rigid when raised but that lets down like those tops of closed carriages in common use.

Town Car. This type has the rear compartment entirely enclosed with full doors, and seats four or five persons in this part of the car. The driver's compartment is open, the same as in a touring car. The driver may be protected by a small canopy extending forward from the enclosed portion.




Fig. 54 Coupe

Coupe. This type of body, Fig. 54, is entirely enclosed and has full doors. It may seat two, three or four passengers in the enclosed part, the driver being one of these. It is mounted on a roadster chassis and bears the same relation to the roadster that the Sedan bears to the touring car.

CONVERTIBLE COUPE OR SEDAN. These bodies are built in such a way that they give exactly the same appearance as a regular Coupe or Sedan from either the outside or inside. The upper

portion is removable so that the Coupe or Sedan is converted into a roadster or touring car, depending on the arrangement and number of passengers carried.

CABRIOLET OR COUPLET. A convertible coupe may be called by either one of these names, both meaning the same thing.


TAXICAB. A car used as a public vehicle and being for hire according to certain designated rates of fare is called a taxicab. It is fitted with a "taximeter" which records the distance traveled and the time spent in waiting, and automatally computes and indicates the fare to be paid.

Taxicabs may be made from limousines, landaulets or town cars, the landaulet being the type most generally used.

Commercial Car Bodies. These types include those used for carrying merchandise and also those used for carrying passengers as a business. Commercial car bodies may be designated according to the type of construction, the class of work to be handled or the weight to be carried.

TRUCK Bodies. These include the express, platform, stake and panel types, and also many special designs. Truck bodies are usually made from designs prepared for each individual job and according to the customer's requirements, except in the lower priced cars.

Passenger Bodies. These include taxicals, sight seeing cars, carrying from eight to twenty persons, and closed bodies suitable for carrying passengers and baggage in interurban work.



Brakes. A brake is a mechanism which is a necessary part of the machinery of an automobile and enables the operator by exerting a slight amount of force on a lever to reduce the

momentum of the moving car. Brakes used on automobiles may be divided into three classes: Hub or rear wheel brakes, transmission and differential gear brakes. Brakes have also been applied to the tires of the rear wheels, but have proved unsatisfactory and have been abandoned. The forms of brakes in use are single, or double-acting, foot or hand operated, and of the band, block or expanding ring types.

Figure 55, at A, B and C, shows three forms of the simplest type of single-acting band-brake. This type of brake can only be operated successfully with the brake wheel running in one direction only, which is indicated by the arrows in the drawing. If the brakes be operated in the reverse direction to that indicated by the arrows the result will be to jerk the lever or pedal out of the control of the operator of the car.

The three forms of band-brakes shown at A, B and C are all of the same principle, the difference being in the location of the fixed end of the brake-band and the shape of the operating lever. Type D is a form of double acting block-brake, which is designed with a view to eliminate any strain or side thrust upon the shaft of the brake wheel which may be caused by the braking action of the device. Types E, G and H are three types of double acting band-brakes, in which the brake may be applied with the brake wheel running in either direction.

Type F is a form of double acting block-brake,

in which the right hand ends of the brake-shoe arms are pivoted to stationary supports, and the left hand ends connected together by means of a link and bell-crank lever as shown in the drawing.




Fig. 56

In Figure 56 a form of double acting block-brake I is shown, which is extremely powerful on account of its peculiar construction, in that is has a double leverage upon the brake wheel, which may be readily seen by reference to the drawing. Types J and K are of the form known

as internal brakes and of the expanding ring type, the brakes operating upon the inner surface or periphery of the brake wheel, instead of the outside. They are known as hub brakes, being usually attached to the hubs of the rear wheels of the car. Type L shows a form of block-brake in which the pivoted brake arms are drawn together by the eccentric located on the brake lever shaft. When the lever is re-




Fig. 57

leased the brake-shoe arms are forced apart by the action of the coil spring between the upper ends of the arms.

EXPANDING BRAKE. In the internally expanding brake, Figure 57, a hollow metal drum or pulley D is carried upon some continuously revolving portion of the car mechanism, and within this drum are supported two metallic shoes B B, which conform in shape to the inside

surface of the drum by means of a spring, S S. The shoes are capable of being strongly pressed against the revolving inner surface of the drum by means of a cam or toggle arrangement, T, operated through a wire rope or metal rod, R, from the operator's lever or pedal. It is important that brakes of both these types should have their bands or shoes so arranged that an equal frictional effect is produced upon their drums for a given force applied by the operator,




Fig. 58 Expanding Brake

whether the vehicle is running forward or backward. A brake so arranged is said to be double acting. Another type of expanding brake is shown in Figure 58, where D is the brake drum; S S, the brake shoes; T, the toggle arrangement which connects with the brake lever, and N is a nut which is used for adjusting the movement of the brake shoes.

ADVANTAGES OF THE EXPANDING BRAKE. The expanding brake is coming more and more

into general use, and is taking the place of the contracting brake in many cases, although the latter is still being used extensively as an emergency brake.

The advantages of the expanding brake are: (1) it is less liable to drag upon the drum; (2) it is easily made double acting; (3) it has more braking power for a given pressure; (4) the friction surfaces are better protected from mud and grit.

A form of brake designed for heavy service is that known as the "hydraulic," in which the braking force is carried by means of oil through suitable piping from a compressing cylinder to a working cylinder. The lever operated by the driver is located in the usual place and is connected to the piston of a powerful oil pump. From this pump connections, lead to a similar cylinder on the chassis and from the piston and plunger of this second cylinder connection is made with the usual forms of brake mechanism. The pump is operated by successive strokes of the lever that increase the pressure; while the brakes are released by pressing a button that opens a valve and by releasing the hand lever.

Brake Linings. For expanding brakes, metal shoes have become standard, owing to the practicability of maintaining proper lubrication between the frictional surfaces. In external brakes the metal band is provided with some form of nonmetallic lining that forms the braking surface applied to the drum. The reason

for this is that it is practically impossible to properly lubricate an external brake. Various kinds of material, viz., leather fabric, asbestos, vulcanized fibre and camel's hair belting, are used for lining external brake bands. A material which is used for this purpose must have great resisting powers, a constant co-efficient of friction, even in the presence of oil and water, and it must have the ability to resist the influence of heat due to the brake's action. In practice it has been found that leather lined brakes burn out, and fibre linings become brittle and cannot be depended upon, so that inorganic materials, which cannot be carbonized, such as asbestos fibre, are widely used. Asbestos fibre may be readily woven into a fabric which answers this requirement, but when used by itself its strength is not sufficient. When, however, it is woven over a metal wire gauze foundation it appears to have the necessary stability to withstand very severe service, and this is the method employed in manufacturing the incombustible brake linings which are being used.

Cork is the bark of the cork tree, and is the lightest known solid. Its weight is one-eleventh of aluminum, and one-thirtieth of cast-iron. It has a very high co-efficient of friction, and is not affected by many of the conditions which seriously impair the efficiency of other substances.

Cork possesses qualities which distinguish it from all other solids, namely, its power of alter-

ing its volume to a very marked degree in consequence of a change of pressure. It consists, practically of an aggregation of minute air vessels, having thin, water-tight, and very strong walls, hence, if compressed, the resistance to compression rises in a manner more like the resistance of a gas, for instance, than to that of an elastic solid, such as a spring. The elasticity of cork has a wide range and is very persistent. It is this elasticity which makes it valuable when used as an insert in a metal shoe. Cork is of rather a brittle nature, though extremely strong, and for that reason it cannot be used in the form of a lining or facing. The method of applicacation is to insert corks in holes in the brake provided for the purpose. Cork is not particularly affected by heat or oil, and will largely increase the efficiency in any application to a brake or clutch.

Where metal-to-metal surfaces, with or without cork inserts, are used, the surfaces are usually of different materials. The most common material for drums in all cases is steel, but that of shoes is either malleable cast iron, brass or a bronze. Different metals make a better wearing surface, and some combinations will have a higher degree of friction adhesion than others.

In the selection of material for brake linings, the co-efficient of friction is an important factor to be considered. Table 7 gives the relative values existing in combinations of different materials.

TABLE 7.

| Material | of friction |
|------------------|----------------------|
| Metal to Wood | 0.25 to 0.50 |
| Metal to Fibre | 0.27 to 0.60 |
| Metal to Leather | |
| Metal to Metal | 0.15 to 0.30 |
| Metal to Cork | 0.36 to 0. 65 |

EQUALIZERS. In connection with all brakes which are used in pairs, some method is used to equalize the pressure of the brake handle or foot pedal so that the same pressure will be applied




Fig. 59
Floating Lever Type of Equalizer

to both brakes. If the power is not equally applied to each brake, side slip or "skidding" will result.

The different methods of equalizing brakes are shown in Figs. 59, 60, 61 and 62, the majority of cars using what is known as the floating lever type, the cable arrangement being used only on several makes of cars. The floating lever type

of equalizer is illustrated in Fig. 59. L is the floating lever, connected at its central point to the brake lever, or pedal by means of rod R. The ends of lever L are connected to the brakes B, B, by means of the brake rods C and D. When rod R is drawn forward, lever L draws rods C and D forward thus giving an equal pressure on the hub brakes.

Fig. 60 shows another type of floating lever equalizer. Shaft S connects to the brakes by




Fig. 60
Floating Lever Equalizer

means of rocker arms located just outside the frame. Two rocker arms, C and D are connected to shaft S, and to the equalizing lever L by means of rods E and F. In some cases the equalizing lever is located outside of the frame. It then takes the form shown in Fig. 61, in which L is the lever that equalizes the pressure on both brakes connected to shaft S. Fig. 62 shows the arrangement of the cord equalizer. Shaft S is connected to the two brakes, one states.

h end, and it has two rockers, or cranks E I F attached to it. Parallel to S is another ft C, which carries a grooved roller R. A le is connected to crank E, carried over R, I then passing back, is connected to crank F. en R is moved in the direction of the arrow, the brake lever, the cord distributes the tennabetween E and F, and as a consequence the ke also. This type is much cheaper than others, but it requires more care and attentactions.





Fig. 61
Equalizer Lever Outside the Frame



Brazing. Many workmen labor under the impression that a brazing job cannot be done unless the parts are a loose fit, in order, as they say, to allow the brazing material to enter and form a bond. The result is, when they do the work, the parts are a very loose fit, with accentuated shearing tendencies in the section of the brazing material, and if the brazing happens to be poorly done, the result is anything but good, since, in the absence of brazing, there is not even a good mechanical bond.

A good mechanical bond is possible to procure without, in any way, interfering with the brazing process, since the parts, if they are well fluxed, will take a coat of brazing material, even when the recess is but a thousandth or two. In brazing, if the work is to be up to a sufficient standard to use in steering gear, it is necessary to clean and brighten the surfaces in a most thorough manner. This will best follow by mechanical scraping rather than by dipping in some corroding material. Dipping may be of value as a preliminary, but a file, and scraper, in the hands of a man of competence, will go a long ways toward success.

When the parts are well brightened, and the grease is thoroughly removed, by the use of soda water, benzine, or equally good solvents, it remains to flux the parts with borax, and then apply the heat, either by a forge or from a special form of brazing torch which uses gasoline, kerosene, or other fuel oil, to produce the necessary heat. All forms of burn-

rs have means of adjusting the flame, and or more burners are usually placed such position that their flames Torches are work. similar to 16 sunsen burner; if fire brick, or clay, is used to uild up around the parts, the heating process rill be attended with less difficulty, and the work vill be better at the finish. A rather hard brazng material may be used. This may be purhased ready for use, and there is no reason at ll why a motorist of even slight skill cannot take a good job of brazing.

Camshaft. Fig. 63 is a sectional view of a moor cylinder and illustrates the principle and acon of the camshaft. In many motors one camhaft serves to open both intake and exhaust alves, while in other motors there is a cam-shaft or each set of valves. Besides opening the valves, he cams determine the length of time the valves emain open, also the speed with which it opens nd closes. Referring to Fig. 63, A is the crankhaft, P the piston, D is the cam-shaft which arries the cam E. The speed of the cam-shaft epends upon the type of engine. The one hown in Fig. 63 is driven at half the speed of ne crank-shaft through the gear wheels B and , B being one half the size of C. H is the alve to be opened, which in opening must be fted off its seat. This is done when the cam revolves and raises the roller G on the lower ad of lifter rod F which extends upward restg against the lower end of the stem of valve

H, although between the two rods, or rather at their point of contact are nut and lock-nut L




Fig. 63
A Camshaft and Its Location

for adjusting the length of F when timing the valve. K is a spiral spring, the function of

which is to close the valve, after the cam E travels around and allows G to drop. Directly above valve H is the intake valve M, which in this case opens downward. This valve opens automatically, due to the suction of the piston in moving downwards on the intake stroke, but is kept closed during the compression and exhaust strokes of the piston, by the pressure in the cylinder.

Modern forms of construction make the camshaft and cams from one piece of steel, and the cams are then said to be integral with the shaft. This method makes it possible to place the cams in exactly the right position at the factory, and the danger of lost power from improper placing is thus greatly reduced.

Carbon Deposit—Symptoms of. One of the most fruitful sources of trouble in internal combustion motors is that of the carbon deposit. If the cylinders get too much oil, or if oil of a heavy or inferior grade is used, a portion of it will work up past the pistons, where it will be evaporated or consumed by the intense heat, leaving a deposit of carbon. This may be augmented by too rich a mixture, which serves to deposit film upon film of carbon on the inside, and top of the compression chamber, and on the head of the piston. The films thus formed will in time commence to scale, and the projections fused by the heat of the explosions will serve to prematurely ignite the charge. The symptoms are back-firing and knocking in the cylinders

-as if the spark were too far advanced. An almost infallible symptom of excessive carbon deposit in the cylinders is the motor showing plenty of power at high car speeds, but deficient in hill-climbing on high gear. At slow engine speeds the incandescent carbon projections serve to pre-ignite the charge, thereby reducing the power of the motor. The cure is to take off the cylinder head and scrape off the carbon deposit from the top of the piston and inside of the cylinder head. Carbon also will form on the porcelain portion of the spark plugs, thereby furnishing a circuit which the high tension current may follow, rather than jump the gap between the points of the plug. Usually only a part of the current will pass by way of the carbon film, still leaving a weak spark at the points, which in open air, when testing plugs, may seem strong enough. This causes intermittent firing. symptoms are similar to a poor contact commutator. This condition is difficult to detect, for the reason that when the plug is subjected to the usual test of removing from the cylinder and closing the electrical circuit, the spark is seen to jump free and fat between the sparking points. This is because electrical energy which is sufficient to jump between two points 1/2-inch apart in the open air will jump less than 1/16inch in the explosion chamber under 60 pounds compression. The causes of overheating motors may be summed up as follows: Poor oil, insufficient oil, bad mixture, slow spark, obstructed water pipe, low water and valves out of time.

Lubricating oil is charged with the crime of depositing carbon on the surfaces of the combustion chamber, and this carbon in turn causes "bucking," and pre-ignition. It probably is true that inferior cylinder lubricating oil will deposit carbon, to some extent, but the main trouble is from the gasoline which will not vaporize until it is allowed to contact with the hot cylinder walls, and this process of reducing the gasoline to vapor is bound to lead to a carbon deposit for the same reason that wood is "coked" if it is heated to a temperature of about 650 deg. C., provided the amount of air present is less than that which would cause complete combustion.

Carburetors, Principles of. Internal combution engines used for the propulsion of moticars use gasoline for fuel in almost all case Experimenting is now going on in the endeave to use kerosene or alcohol, and in some case even lower grades of fuel. Gasoline and ker sene are secured by heating crude petroleu until vapor is given off, and this vapor is passe through pipes that are kept cool enough to coldense the vapor into a liquid. Alcohol is secured by the distillation of fermented veg table matter, and may be secured in almoany part of the country if suitable means for distillation were to be developed.

Before the gasoline is ready to burn in the engine cylinders, it must be turned into a gasor vapor. If gasoline stands exposed to the a it will vaporize at a comparatively slow rat but if ejected from a small opening in a firstream it will turn to vapor and mix with a much more rapidly. It is always necessary mix the gasoline vapor with air in certain proportions to make a combustible mixture. The instrument that turns the gasoline into a gas and then mixes the gas with air is called the carburctor and the process is called carburcting.

Many forms of carburetors have been made and used, but all instruments now fitted are of the type known as automatic float feed. The spray nozzle is the small opening inside of the carburetor through which the liquid gasoling is drawn when it is to be made into a vaporation of the state of the small opening inside of the carburetor through which the liquid gasoling is drawn when it is to be made into a vaporation.

The nozzle opening is placed in a tube through which the air must pass on its way to the engine cylinders. See Fig. 64. One end of this tube is open to the outside air and the other end attaches to the piping that goes to the engine cylinders. The end open to the air is called the primary air intake.




Fig. 64

Float-Feed Carburetor Mixing Chamber and Air Valve. A, Spray Nozzle. B, Adjusting Needle Valve. C, Primary Air Intake. D, Auxiliary Air Valve. E, Air Valve Spring. F, Throttle Valve.

When the piston travels away from the cylinder head on the inlet stroke, the inlet valve opens and a cylinder full of mixture is drawn from the carburetor. The air to make the mix-

ture is drawn through the carburetor primary air intake and must pass by the nozzle opening. The gasoline is maintained at a height slightly below the nozzle opening, and the suction, or partial vacuum, of the incoming air causes some of the gasoline to be drawn out of the nozzle so that its spray mixes with the air. This is the principle on which all modern carburetors operate, but certain added features are necessary to compensate for the different conditions obtaining under different rates of car speed and engine load.

The first difficulty that would be encountered with the simple form of carburetor just described would be that of a falling gasoline level in the nozzle as the fuel was drawn into the engine. This would finally result in a failure of the fuel supply and stoppage of the engine. In actual practice, the gasoline from the car's tank does not pass directly into the nozzle, but goes first into a small tank on the carburetor, which tank is called the float chamber. Of the two openings in this small tank, one goes to the gasoline supply and the other communicates with the carburetor nozzle. Inside of the float chamber is a piece of cork covered with shellac or else a hollow metal cylinder, either of which will float on the surface of whatever gasoline may be in the chamber. At the opening of the pipe that comes into the float chamber from the gasoline tank is a small valve, Fig. 65, operated by connections attached to the float itself. When the float is low down in the chamber this valve is open; but as the float rises on the surface of the liquid coming from the tank, it finally reaches a height




Fig. 65

Carburetor Float Valve Mechanism. A, Float. B,
Float Lever Pivot. C, Float Lever. D, Float
Valve. E, Gasoline Inlet.

at which the valve is closed, and it will therefore be seen that the level of the liquid cannot rise above the point determined by the position of the float when the valve closes. When gasoline is drawn from the float chamber, through the nozzle, the float falls with the fuel level until the valve is again opened, and by this repeated action the level is maintained constant.

Other parts of the carburetor, such as the auxiliary air valve, are described in the following pages and the construction and adjustment of the well known makes are taken up.

Almost any carburetor will give a reasonagood mixture through a limited range of act Frequently, however, this range is found in ficient for a particular engine. If right for speeds, it is wrong for high speeds, and versa.

The theory of carburetor action as regathe behavior of the gasoline jet under differ air velocities is still only partially understand has been the subject of a great deal more or less blind theorizing, based in m cases on wholly inadequate data.

A non-automatic spraying carburetor (i. e simple nozzle in an air tube) makes no mixt at all till the velocity of the air stream read a certain minimum. Beyond this point, richness increases with the speed. Dilu from the auxiliary valve is therefore requionly when the richness of the mixture excepted that, so far as the spray is concern there is no difference between a wide open the tle at slow engine speed (as for instance, hill) and reduced throttle with high engaged. The spraying action is concerned of with the velocity of the air past the nozzle fore the throttle is reached.

Almost every carburetor is provided with needle valve controlling the spray orifice. We this provision it is very easy to determ whether or not the carburetor is doing as a sait should at either low or high speed.

example, suppose we start with an adjustment known to be satisfactory for medium speeds. If the low speed performance is under suspicion, it is only necessary to increase the needle valve opening slightly to ascertain whether starting is thereby made easier, and a walking pace more smoothly maintained. If overheating results, reducing the needle opening will probably cure it. Similarly slight changes in the needle opening, without changing any other adjustment, will determine whether or not the mixture is improved by less, or more gasoline at high speed. When the carburetor is set for a medium speed, if the mixture is weak at low speeds, and rich at high speeds, more air should be admitted, but if the mixture is rich at low speeds, and weak at high, less air should be admitted. Much depends upon the spring.

It is a characteristic of all springs that their flexure is in direct proportion to the load imposed, up to the elastic limit of the spring.

THE FLOAT FEED CARBURETOR, Fig. 66, consists of two principal parts: a gasoline receptacle which contains a hollow metal or a cork float, suitably arranged to control the supply of gasoline from the tank or reservoir, and a tube or pipe in which is located a jet or nozzle in communication with the gasoline receptacle. This tube or pipe is called the mixing chamber. The gasoline level is maintained about one-sixteenth of an inch below the opening in the jet




Fig. 56 Float Feed Carburetor




Fig. 67 Multiple Spray Carburetor

in the mixing chamber. The inductive action of the motor-piston creates a partial vacuum in the pipe leading from the mixing chamber of the carbureter to the motor, thereby causing the gasoline to flow from the jet and mixing with the air supply, to be drawn into the cylinder of the motor in the form of an explosive mixture.

Spraying Carburetors. In this type of carburetor the quantity of gasoline delivered is not proportional to the volume of air delivery at different rates of flow. This difficulty has, however, been met by providing a supplementary air inlet to the carbureter, which may be regulated by the driver at will.

Another method of correcting the variations in the proportions of the gasoline charge is shown in Fig. 67, and consists in providing a second spray nozzle. In the majority of cases in which multiple nozzle carburetors are used, there are two nozzles, practically two carbureters, a small one for idle running, and slow speeds, and a larger one for heavy work. In some instances, three, and even four nozzles are used.

THE VENTURI TUBE CARBURETOR operates on the principle that if two converging air nozzles have their small ends brought together, there is a point where the suction remains practically constant, therefore if the fuel nozzle be located at this point the result will be, a constant mixture at all speeds. In a carburetor of this type there are no auxiliary spring controlled valves, no moving strangling cage, nor and chanical interregulation between the airthe gasoline.

An elementary Venturi tube is shown in 68, which represents the tube A having a of water on it. The discharge at A is grincreased by the addition of the divergent zle at the outlet end. Under these condi




Fig. 68
Principles of the Venturi Carburetor

the velocity of flow in the throat at A is go than that produced by the head H. What pressure gauge is placed at A the presson found to be less than atmospheric; in fac fluid is discharging into a partial vacuum the velocity at A is due to the head H plu head due to the vacuum. Advantage is of this fact by placing the gasoline out the point A, in which case the velocity of suction controls the flow of gasoline at all times thus giving a perfect mixture.

AUXILIARY AIR-VALVE. It has been determined from the result of experiments that to get the maximum power at any speed from a gasoline motor equipped with a float-feed carburetor, the jet of the carburetor must have a larger opening for low speeds than for high speeds. As this practice would require a very delicate adjustment it consequently becomes almost impracticable, because necessitating a constantly varying regulation for each fractional variation of speed of the motor. The difficulty may be obviated by the use of an auxiliary air-valve, located in the induction-pipe close to the inlet-valve of the motor.

The jet of the carburetor is set for the maximum quantity of gasoline at the slowest speed of the motor, and as the speed is increased the auxiliary air-valve comes into action and reduces the supply of air passing through the carbureter, thereby reducing the suction or partial vacuum at this point, and maintaining a constant quality of mixture at all times.

The auxiliary air valve has been attached to a dash pot construction in many makes of modern carburetors. The dash pot may operate with air or with gasoline for its fluid, but in either case the purpose is to prevent sudden opening and closing of the valve or "fluttering." Such fluctuation is a cause of noise and also tends to destroy the proportions of the mixture.

Frequently it is observed that the intake to the carburetor is so restricted that noise issues, and a little further investigation in such cases will disclose, in all probability, that wire-drawing is one of the ills. It is not alone the noise that is objectionable in such cases; the power of the motor will be less, due to the restriction which has the effect of reducing the weight of mixture that enters into the cylinders, and the power of a motor is undoubtedly proportional to the weight of mixture that enters the cylinders, assuming, of course, that the same is in acceptable form, and that it is completely burned. True, there must be a depression in the carburetor in order that there will be a difference in pressure, so that gasoline will be sucked into the train of air; equally true, it is of the greatest importance to have the depression as low as possible in order that the power of the motor will be a maximum. If the depression is but slight, provided the carburetor is properly designed, the amount of fuel entrained will be adequate for the purpose. If, on the other hand, the depression is very large and holds considerable fuel, it will soon be found to be wasteful of the liquid.

With the low grades of fuel now in use, wiredrawing is very harmful, inasmuch as it tends to separate the gasoline from the air and causes the gasoline vapor to again become a liquid and deposit on the tubing walls. EFFECT OF COLD ON GASOLINE. The temperature has a very marked effect on the rapidity with which gasoline vaporizes, and in cold weather it is necessary to supply heat to the carburetor.

The carburetor should preferably be jacketed, and it may be warmed either from the circulating water, or by taking a small quantity of the hot gases from the exhaust pipe. If water is used it should be taken from a point just beyond the discharge of the pump, and should be delivered to the return pipe from the engine jacket to the radiator.

Whether exhaust gases or water is used, the flow should be regulated by a cock, otherwise too much heat will be received in warm weather. When the carburetor is cold, the engine may be started by pouring warm water over it, care being taken not to let any portion of the water get into the gasoline through any aperture in the top. Another method of warming up the carbureter is to wring cloths out of hot water, and wrap them around it.

While it is not generally realized, the flow of gasoline through the nozzle is greatly influenced by the temperature of the liquid. Gasoline at very low temperatures, such as freezing, and slightly above, is reduced as much as 30% in volume of flow below the point reached when the liquid itself is warmed to between 65° and 80° Fahrenheit. This forms one more reason for jacket heating on all carburetors.


Carburetor Inspection. The float valve of the carburetor should be tested for leaks by opening the valve between it and the tank and looking for gasoline drip. If gasoline escapes, it may simply be because the float is set too high, so that it does not close the needle valve before gasoline issues from the spray nozzle. Or, it may be that the valve itself leaks.

At this stage, it is well to assume that the float is properly adjusted, and to begin by shutting off the main gasoline valve, and then unscrewing the washout plug below the needle valve. It may be found that dirt, waste, or a splinter of wood has got past the strainer, through which, presumably, the gasoline passes on its way to the float, and is lodged in the needle-valve opening. It may be of advantage to open the top of the float chamber, which can usually be done without disturbing other parts, and take out the float and needle valve. A little gasoline washed down through the needlevalve orifice will then generally carry away any dirt that may have clung to the valve when the plug was unscrewed. If the gasoline still drips when the parts are reassembled, the mixing chamber should be opened and the top of the spray nozzle examined to see if gasoline is escaping from it. An electric light should be used in making an examination of the carbureter, as, with any other illuminant, a fire might be started. The portable electric flashlights answer the purpose very well.

Occasionally a carburetor is found to be too large for the engine, or to have too large a spray orifice. The advice has been given in such a case to reduce the size of the spray orifice by lightly pening the top of it with a hammer. This is counsel of doubtful value, even if the hole be afterward reamed true, since it is manifest that the burr formed in the top of the orifice cannot possibly be deep enough to be at all regular in its form. It will almost inevitably throw a jet slantwise, instead of straight, and this jet failing to strike the main part of the air stream will be only partly atomized, with resulting misfiring and general bad behavior, especially at low speeds. If a new nożzle of smaller size cannot be substituted, the best thing to do in case there is no needle valve to adjust the flow of gasoline to the jet is probably, to warm the ingoing air as much as possible, in order to make evaporation by temperature take the place of atomizing due to the air's velocity.

Holly Carburetor, Model H. This carburetor is shown in Fig. 69. Before the fuel enters the float chamber it passes a strainer disk A which removes all foreign matter that might interfere with the seating of the float valve B under the action of the cork float and its lever C. Fuel passes from the float chamber, D, into the nozzle well E, through a passage F, drilled through the wall separating them. From the

nozzle well the fuel enters the nozzle proper, G, through the hole H, and then rises past the needle valve I, to a level in its cup-shaped upper end, which just submerges the lower end of a small tube, J, which has its outlet at the edge of the throttle disk.




Holly Carburetor, Model "H"

Cranking the engine, with the throttle kept nearly closed, causes a very energetic flow of air through the tube J and its calibrated throttling plug K, but the lower end of this tube is submerged in fuel, with the engine at rest. Therefore, the act of cranking automatically primes the motor. With the motor turning over, under its own power, flow through the tube J takes place at very high velocity, thus causing the fuel entering the tube with the air to be thoroughly atomized upon its exit from the small opening at the throttle edge. This tube is called the "low speed tube" because, for starting and idle running, all of the fuel and most of the air in the fuel mixture are taken through it.

As the throttle opening is increased beyond that needed by idling of the motor, a considerable volume of air is caused to move through the passage bounded by the conical walls L of the so-called strangling tube. In its passage into the strangling tube, the air is made to assume an annular, converging-stream form, so that the point in its flow at which it attains its highest velocity is in the immediate neighborhood of the upper end of the "standpipe" M, set on to the body of the nozzle piece G. The velocity of air flow being highest at the upper, or outlet, end of the standpipe, the pressure in the air stream is lowest at the same point. For this reason there is a pressure difference between the top and bottom openings of the pipe M, thus causing air to flow through it from bottom to top, the air passing downward through the series of openings N in the standpipe supporting-bridge and then up through the standpipe.

With a very small throttle opening, the action through the standpipe keeps the nozzle thor-

oughly cleaned out, the fuel passing directly from the needle opening into the entrance of the standpipe. To secure the utmost atomization of the fuel, the passage through the standpipe is given aspirator form, which further increases the velocity of the flow through it, and insures the greatest possible mixture of the fuel with the air. A further point is that the atomized discharge of the standpipe enters the air stream at a point at which the latter attains its highest velocity and lowest pressure.



Holly Carburetor, Model "G"

There is but one adjustment, the needle valve I. The effect of a change in its setting is manifest equally over the whole range of the motor.

HOLLY CARBURETOR, MODEL G. This design is especially for Ford cars. Its method of operation is identical with that of the Model H, its chief differences as compared with the other model being structural ones, giving a horizontal instead of a vertical outlet, a needle valve controlled from above, and a general condensation of the design to secure compactness.


Fuel enters the carburetor, shown in Fig. 70, by way of a float mechanism in which a hinged ring float, in rising with the fuel, raises the float valve into contact with its seat. The seat is a removable piece and the float valve is provided with a tip of hard material.

From the float chamber the gasoline passes through the ports E to the nozzle orifice in which is located the pointed end of the needle F. It is noted that the ports E are well above the bottom of the float chamber, so that, even should water or other foreign matter enter the float chamber it would have to be present in a considerable quantity before it could interfere with the carburetor operation.

A drain valve D is provided for the purpose of drawing off whatever sediment, or water, may accumulate in the float chamber. The float level is so set that the gasoline rises past the needle valve F and fills the cup G to submerge the lower end of the small tube H. Drilled passages in the casting communicate with the upper end of this tube with an outlet at the edge of the throttle disk. The tube and passage give the starting and idling actions, as described in connection with the Model H.

The strangling tube I gives the entering air stream an annular converging form, in which the lowest pressure and highest velocity occur immediately above the cup G; thus it is seen that the fuel issuing past the needle valve F is immediately picked up by the main air stream at the point of the latter's highest velocity.

The lever L operates the throttle in the mixture outlet, and a larger disk with its lever S is a spring-returned strangler valve in the air intake, for facilitating starting in extremely cold weather. KINGSTON CARBURETOR. The Kingston carburetor, Fig. 71, uses a ball type of auxiliary



air valve instead of the employment of spring control dashpot, diaphragm or auxiliary air valve. The main air intake A communicates with the vertical mixing chamber B, in which the sides C are beveled outward, giving a center tube effect, so that the air current converges above the nozzle N, as indicated by the arrows. D marks the exit to the motor controlled by the butterfly throttle E. Auxiliary air enters through five circular openings G, arranged in a semi-circle in the floor of an extension H of the mixing chamber. Each of these five openings consists of a bushing K threaded into the opening in the extension H, and having its top beveled to receive a five-eighths inch bell metal bronze ball L, which is retained in position by a threaded bushing M, fitting in the top of the extension H. It has a pair of downward projecting hooks N for preventing the ball getting out of position, but not interfering with the ball rising vertically when forced to do so by the pull of the motor, at which time additional air is admitted. Two others of the five auxiliary entrances are shown at I and O, all of the five containing balls of the same size and weight. The air entering through the openings guarded by these balls has an unrestricted passage into the mixing chamber and thence to the motor. Any ball is easily moved by unthreading the cap M, after which the ball can be lifted out.

The gasoline enters the carburetor from the gasoline tank by way of the connection J, which is guarded by the needle valve R, operated through the lever S, pivoted in the side of the casting and with its long arm bearing on the top of the cork float. The float is fitted with a metal bushing. Complete control of the nozzle N is through the needle valve V, which, at the top of the carbureter, has a Tpiece X, by which it can be raised or lowered, thereby regulating the flow of gasoline. feature of the throttle connection T is the serrated lower face of its hub W, so that by loosening a lock nut Z, the handle T may be turned in any direction most convenient. The air intake A consists of an L-shaped piece secured to the carbureter casting by a nut P, and in the base of this is a circle of openings F where currents of air can enter, the object of these openings being that by priming the carburetor, and overflowing the open mouth of nozzle N the gasoline falls to the vicinity of the holes F, and the air entering through these openings will facilitate the breaking up of the gasoline, and thereby assist the starting of the motor.

Krebs Carburetor. In the Krebs style of carburetor, a constant proportion of gasoline and air is maintained by means of suitable sections of air and gasoline outlets. The openings are so arranged that a proper mixture is maintained at minimum suctions, after which gradually increasing quantities of supplementary air are admitted.

A number of attempts have been made to improve upon the Krebs principle by variously shaping the supplementary air openings, or the spring on the supplementary air valves, so as to insure complete compensation for the increase in richness of the mixture formed in the spray chamber with increasing suction, by the addition of the correct amount of supplementary air at all suctions. The mixture formed in an ordinary spray carbureter becomes richer as the suction increases. At first the only means provided to correct this defect was a hand-regulated air valve; but since the advent of the Krebs carbureter, practically all new carbureters brought out have some arrangement for automatically keeping the mixture constant, regardless of variations in suction. In general the means provided are close copies of the Krebs supplementary air valve, though in some

instances this valve, instead of being actu by the suction, is operated either hydraulic by means of a diaphragm in a chamber comnicating with the water cooling system, or chanically by direct connection with the thtle valve. Master Carburetor. This carburetor, shown in Fig. 72, is unique in that it has no adjust-




Fig. 72 Master Carburetor

ments, and is so simple that it may be readily taken apart and put together again. In the Master carburetor both the fuel and the air are positively regulated. This regulation is accomplished by a rotary throttle, which not only uncovers a series of minute holes in the fuel dis-




Fig. 73

Master Carburetor Vaporizing Action tributer, but eliminates the butterfly valve found in most other carburetors. This action is shown in Fig. 73. When the throttle is closed fuel is admitted through but one hole, sufficient for slow speed or idling. As the throttle is opened additional holes are uncovered, one by one, and the fuel supply increased. The rotary valve does not become worn, as it does not come in contact with the throttle chamber in which it rotates. The




Fig. 74
Master Carburetor Damper

damper shown in Fig. 74 is a rigid plate, extending entirely across the passageway, paralleling the fuel distributer. This damper lever is attached to the hand control located on the steering post by means of a steel wire passing through a brass tubing. A trap is located under the float chamber and it contains a brass screen that filters the fuel, which is again filtered by another screen of tubular form.

RAYFIELD CARBURETOR. The Rayfield carburetor has no direct adjustment for the nozzle opening such as would be provided by a screw needle valve, but to take the place of such an adjustment a type of lever mechanism is used that increases or decreases the gasoline supply according to the degree of throttle opening, and also provides means for adjusting the fuel flow for high or low speeds independently of each other. Adjustment is provided through two screws with milled heads, one of these serving to fix the position of the nozzle adjustment at low engine speeds or with a nearly closed throttle and the other one operating only when the throttle is more than half way open. The construction of this instrument is clearly shown in Figs. 75, 76 and 77, and the method of adjustment is described on the following pages.

Model D, Fig. 75—Adjusting low speeds:—Close needle valve by turning low speed screw to the left until arm U slightly leaves contact with the cam. Then turn to the right one and one-half turns, open throttle one-quarter, prime carburetor and start motor. Close throttle until motor runs slowly without stopping. Turn low speed screw to the left one notch at a time until motor idles smoothly. If motor does not throttle low enough turn screw in stop arm to the left with a screw driver. Carburetor is now adjusted for low speed.

Adjusting high speed:—Now open the throttle slowly until wide open. Should motor backfire turn high speed adjusting screw to the right, a half turn at a time, until motor runs without a miss. Should motor not backfire turn high speed adjusting screw to the left until it does, then to the right until motor runs smoothly and powerfully. Do not use low speed adjustment to get a correct mixture at high or intermediate speeds.

Should motor backfire or mixture be too light at intermediate speeds (throttle about 1/4 open)




Fig. 75

Rayfield Carburetor, Model "D". A, Float Chamber. B, Mixing Chamber. C, Flange. D, Throttle Lever. E, Gasoline Intake. H, Gas Arm. J, Dash Adjustment. K, Air Valve. L, Needle Valve. M, Regulating Cam. P, Air Adjustment. R, Air Lock. S, Drain Plug. T, Priming Cap. U, Needle Arm. F, Water Connection. G, Priming Lever. N, Low Speed Adjustment. O, High Speed Adjustment. V, Primary Air Intake. W, Cam Shaft.

turn air valve adjustment P to the right a turn or two, thus increasing the spring tension and decreasing quantity of air slightly.

Remember that it is best to use all the air that the motor will handle without being sluggish.

Do not change the float level. It is correctly set at the factory. Always prime carburetor

well before starting motor. Pull steadily on primer string. Don't jerk.

Do not cut down the air supply, unless the gasoline adjustments fail to give you a powerful and fast mixture.

If motor does not get the correct mixture at intermediate speed or high speed, do not try to remedy it through a low speed adjustment. Remember, the low speed adjustment is to be adjusted only when the motor is running idle.

In starting motor, do not open throttle more than one-quarter. The motor will start more readily with the throttle slightly opened and it is harmful as well as useless to race the motor in starting.

Before cranking motor pull dash button up. After motor has "warmed up" push dash button down to Running Position.

In stopping motor pull up dash button, open throttle about ¼ inch, and switch off ignition, thus leaving a sufficient volume of rich mixture in the cylinders, which assures easy starting when the motor is again used.

Models G and L, Figs. 76 and 77, have no air valve adjustment and only two gasoline adjustments.

Always adjust carburetor with dash control down. Low speed adjustment must be completed before adjusting "high."

Adjusting low speed:—With throttle closed, and dash control down, close nozzle needle by turning Low Speed adjustment to the left until




Fig. 76
Rayfield Carburetor, Model "G". D, Thrott
G, Priming Lever. H, Gasoline Arm. M
lating Cam. S, Drain Cock. U, Needl
Arm. X, Drain Cock. J, Gasoline Contr




Fig. 77—Rayfield Carburetor, Model "G", Construction

Block U slightly leaves contact with the cam M. Then turn to the right about three complete turns. Open throttle not more than one-quarter. Prime carburetor by pulling steadily a few seconds on priming lever G. Start motor and allow it to run until warmed up. Then, with retarded spark, close throttle until motor runs slowly without stopping. Now, with motor thoroughly warm, make final low speed adjustment by turning low speed screw to left until motor slows down, and then turn to the right a notch at a time until motor idles smoothly.

If motor does not throttle low enough, turn stop arm screw A to the left until it runs at the lowest number of revolutions desired.

Adjusting High Speed:—Advance spark about one-quarter. Open throttle rather quickly. Should motor backfire it indicates a lean mixture. Correct this by turning the high speed adjusting screw to the right about one notch at a time, until the throttle can be opened quickly without a backfiring.


If "loading" (choking) is experienced when running under heavy load with throttle wide open, it indicates too rich a mixture. This can be overcome by turning high speed adjustment to the left.

Adjustment made for high speed will in no way affect low speed. Low speed adjustment must not be used to get a correct mixture at high speed. Both adjustments are positively locked.

Starting:-Before starting motor when cold

observe the following. Open throttle not more than one-quarter. Enrich the mixture by pulling up dash control. Prime carburetor by pulling on priming lever G for a few seconds.

When stopping motor, pull up dash control. Open throttle about one-quarter and switch off ignition. This leaves a rich mixture in the motor, which insures easy starting.



Schebler Carburetor, Model "D". A, Auxiliary Air Valve. C, Choke Valve. D, Drain Cock. F, Float. M, Spray Nozzle. G, Gasoline Inlet. N, Air Valve Adjustment. S, Air Valve Spring. T, Throttle Valve Lever. V, Gasoline Adjustment Valve.

Raising dash control enriches the mixture by lifting the nozzle needle. Control button should be down for running, except when a richer mixture is required.

Pull button up full distance for starting.

Adjustment of carburetor should always be made with dash control down and motor warm.

Schebler Carburetors. This make of instrument has been built in a number of different models, the first one of which to be used in large numbers was the Model D, Fig. 78. All of the important types of Schebler carburetors now in use are described and instructions given for their adjustments on the following pages.




Fig. 79
Schebler Carburetor, Model "L". A, Auxiliary Air Valve. B, Gasoline Needle Valve. C, Priming Lever. D, Intermediate Speed Cam. E, High Speed Cam.

The Model L carburetor, Fig. 79, is a type of lift needle carburetor and is so designed that the amount of fuel entering the motor is automatically controlled by means of a raised needle working automatically with the throttle. The adjustment or control of gasoline in this instrument

can be adjusted for low, intermediate or high speed, each adjustment being independent and not affecting either of the other adjustments.

In adjusting the carburetor, first make adjustment on the auxiliary air valve A so that it seats firmly but lightly; then close the needle valve by turning the adjustment screw B to the right until it stops. Do not use any pressure on this adjustment screw after it meets with resistance. Then turn it to the left from four to five complete turns and prime or flush the carburetor by pulling up the priming lever C and holding it up for about five seconds. Next, open the throttle about one-third, and start the motor; then close the throttle slightly, retard the spark and adjust throttle lever screw F and needle valve adjusting screw B so that the motor runs at the desired speed and fires on all cylinders.

After getting a good adjustment with the motor running idle, do not touch the needle valve adjustment again, but make all intermediate and high speed adjustments on the dials D and E. Adjust pointer on the first dial D from the number 1 towards 3, about half way between. Advance the spark and open throttle so that the roller on the track running below the dials is in line with the first dial. If the motor backfires with the throttle in this position, and the spark advanced, turn the indicator a little more toward number 3; or if the mixture is too rich turn the indicator back or toward number 1, until motor is running properly with the throttle in this posi-

tion, or at intermediate speed. Now, open the throttle wide and make adjustment on the dial E for high speed in the same manner as for intermediate speed on dial D.


In the majority of cases in adjusting this carburetor the tendency is to give too rich a mixture. In adjusting the carburetor both at low, intermediate and high speeds, cut down the gasoline until the motor begins to backfire, and then increase the supply of fuel, a little at a time, until the motor hits evenly on all the cylinders. Do not increase the supply of gasoline by turning the needle valve adjusting screw more than a notch at a time in the low-speed adjustment, and do not turn it any after the motor hits regularly on all cylinders. In making the adjustments on the intermediate and high speed dials, do not turn the pointers more than one-half way at a time between the graduated divisions or marks shown on the dials.

The Model R Schebler carburetor, Fig. 80, is a single jet raised needle type of carburetor, automatic in action. The air valve controls the lift of the needle and automatically proportions the amount of gasoline and air at all speeds.

The Model R carburetor is designed with an adjustment for low speed; as the speed of the motor increases the air valve opens, raising the gasoline needle, thus automatically increasing the amount of fuel. The carburetor has but two adjustments—the low speed needle adjustment, which is made by turning the air valve cap and

an adjustment on the air valve spring for changing its tension.

This carburetor has an eccentric which acts on the needle valve, intended to be operated either from the steering column or from the dash, and insures easy starting, as by raising the needle from the seat an extremely rich mixture is furnished for starting, and for heating up the motor in cold weather. A choker in the air bend is also furnished.



Schebler Carburetor, Model "R". A, Low Speed Adjustment. B, Starting Cam Lever. C, Needle Valve Connection. D, Starting Cam. E, Needle Valve. F, High Speed Adjustment.

When carburetor is installed see that lever B is attached to steering column control or dash control, so that when boss D of lever B is against stop C the lever on steering column control or dash control will register "Lean" or "Air."

This is the proper running position for lever B.

To adjust carburetor turn air valve cap A clockwise or to the right until it stops, then turn to the left or anti-clockwise one complete turn.

To start engine open throttle about one-eighth or one-quarter way. When motor is started let trun till engine is warmed, then turn air valve cap A to left or anti-clockwise until engine hits perfectly. Advance spark three-quarters of the way on quadrant, if engine backfires on quick acceleration turn adjusting screw F up (which necesses tension on air valve spring) until acceleration is satisfactory.

Turning air valve cup A to right or clockwise ifts needle E out of nozzle and enriches mixture; turning to left or anti-clockwise lowers the needle into nozzle and makes mixture lean.

When motor is cold or car has been standing, nove steering column or dash control lever towards "Gas" or "Rich" which lifts needle E out of gasoline nozzle and makes rich mixture for starting. As motor warms up, move control ever gradually back towards "Air" or "Lean" o obtain best running conditions until motor has reached normal temperature. When this temperature is reached control lever should be at 'Air" or "Lean."

For best economy and power, the slow speed idjustment should be made as lean as possible.


STROMBERG CARBURETORS are made with a nozcle, the opening in which is not adjustable. This nozzle is a separate part of the carburetor and is screwed into place from below. In order to adjust the gasoline flow it is necessary to remove one nozzle and replace it with one having a larger or smaller opening. The nozzles are marked according to drill gauge sizes and the opening becomes larger as the number becomes lower, that is to say, a number 59 is larger than a number 60 and a number 58 is larger than a number 59.

If, after making low speed adjustment it is found that the air valve remains off its seat or that indications of a rich mixture are still present, the nozzle is too large. If the high speed adjustment has to be screwed very tight it indicates that the nozzle is too small. In changing nozzles do so one size at a time, that is, do not drop from number 60 to a number 58, but use a 59 first.

The several types of Stromberg carburetors that have been fitted up to the present time are described and adjustment instructions given in the following pages.

Instructions for type A. Type A, Fig. 81, is a water jacketed carburetor. It has its spray nozzle PN mounted in the center of the carburetor with its point 3-16 of an inch above the normal gasoline level and surrounded by a modified venturi tube. This nozzle is proportionate in size to the carburetor and never needs attention or adjustment.

After the carburetor is installed and the gasoline turned on, note the level of the gasoline in the float chamber. It should be about one inch from the lower edge of the glass. This level is adjusted at the factory and should be right. In case it is obviously wrong, remove the dust cap D and turn the adjusting screw S until the proper level is obtained. If the gasoline is too high, screw the nut down. If gasoline is too low, screw the nut up. Don't change unless absolutely necessary.



Stromberg Carburetor, Model "A"

To start the motor close the valve S3 in the hot air horn H. The motor should then start on the second or third turn of the crank. If not, open the valve and it ought to start on the next turn. Great care should be taken to see that this valve is instantly opened as the motor starts, and is kept open.

Season adjustments. Open and close shutter SA—open in summer and closed in winter.

Low speed adjustment. Turn up the adjust-


ing nut A until the spring S1, which is the low speed spring, seats the valve lightly. See that the high speed spring above B is free and does not come in contact with the nut on top of the auxiliary air valve stem. Start the motor and turn nut A up or down until motor idles properly. This is the low speed adjustment.

High speed adjustment. Advance the spark and open the throttle. If the motor backfires through the carburetor, turn high speed adjusting nut B up until backfiring ceases. If, with this adjustment and running at low speeds, motor gallops, or the carburetor loads up, the mixture is too rich. The nut B should then be turned down until galloping or loading ceases. This is the high speed adjustment. The spring above nut B should always have at least 1-32 inch clearance between it and the nut at the top when the motor is at rest.

Instructions for type B. Type B, Fig. 82, is a concentric type carburetor. It has its spray nozzle PN mounted in the center of the carburetor, and in the center of the float chamber, with its point 3-16 of an inch above the normal gasoline level and surrounded by a modified venturi tube.

The level of the gasoline in the float chamber should be about 15-16 of an inch from the lower edge of the glass marked X. This level is adjusted at the factory and should be right. In case it is wrong, remove the dust cap D and turn the adjusting screw S until the proper level is

obtained. If the gasoline is too high screw the nut down. If the gasoline is too low screw the nut up. Don't change unless absolutely neces-




Stromberg Carburetor, Model "B"

Low speed adjustment. Turn up the adjusting nut A until the spring S1, which is the low speed spring, seats the valve lightly. See that the high speed spring above B is free and does not come into contact with the nut on top of the auxiliary air valve stem. Start the motor and turn nut A up or down until motor idles properly. This is the low speed adjustment.

High speed adjustment. Advance the spark and open the throttle. If motor backfires through the carburetor, turn high speed adjusting nut B up until backfiring ceases. If, with this adjustment and running at low speeds motor gallops, or the carburetor loads up, the

mixture is too rich. The nut B should then be turned down until galloping or loading up ceases. This is high speed adjustment. The spring above nut B should always have at least 1-32 inch clearance between it and the nut at the top when the motor is at rest.



Instructions for type C. Type C, Fig. 83, is equipped with two separate gasoline spray nozzles. The first or primary nozzle PN is mounted in the venturi tube V; this nozzle supplying sufficient gasoline for all speeds up to twenty or twenty-five miles per hour. The second or auxiliary nozzle is mounted just beneath the secondary gasoline needle valve ANV in the auxiliary air passage AA, and is opened by the lever L operating over a fulcrum F by the opening of the auxiliary air valve AV.

Turn up the lower adjusting nut N, located underneath the auxiliary air valve, so that the valve is brought up to seat, then give two full turns to the right as a starting adjustment. This valve should be seated on extreme idle. The spring S1 is the low speed spring and does the work up to the opening of the auxiliary needle.


Start the motor and turn low speed nut N up or down until the motor idles properly, then advance the spark, open the throttle, and if the motor backfires turn nut LN down until it ceases. If mixture is too rich, turn it up. Be sure that nut LN and lever L have some clearance on low speed.

The proper gasoline level is about 1 inch from the lower edge of the glass. If more than 1/8 inch either way remove the dust cap and adjust by screws.

High speed adjustment. The high speed is regulated by the lock nut LN on top of the auxiliary air valve. As it is raised or lowered it determines the point at which the auxiliary needle valve ANV will be brought into play. To lock nut LN should be about 3-32 of an inch above the lever L for normal adjustment, but this distance can be increased or decreased to suit the motor.

To find primary nozzle size. If the mixture is too rich on low speed after adjustments are made according to instructions, take out the plug P and remove the nozzle PN with a screw-

driver. Insert smaller nozzle (59 is smaller than 58). If the mixture is too lean on low speed a larger nozzle should be inserted. If the engine misses on low speed it may be caused by an air leak, and all the joints between the carburetor and the motor should be examined before a large nozzle is inserted.



Stromberg Carburetor, Model "G"

Instructions for type G. Type G, Fig. 84, is a non-water-jacketed model furnished in either single or double jet according to motor requirements.

Air adjustments. There are only two adjustments that ever need attention, A, the low speed nut, and B, the high speed nut.

With the motor at rest, set the high speed nut B so there is at least 1-16 of an inch clearance between the spring G and the nut X above it. This is imperative.

Set the low speed nut A so the air valve E is seated lightly. Do not adjust carburetor until motor is thoroughly warmed up. When motor is warm and with spark retarded adjust nut A up or down until motor runs smoothly at low speed. To determine proper adjustment open the air valve with finger by depressing X slightly. If, when so doing, motor speeds up noticeably it indicates too rich a mixture and A should be turned down notch by notch. If, on the other hand, motor dies suddenly when slightly opening the air valve it indicates too lean a mixture and A should be turned up until this is overcome.

Once properly set for idling do not change this adjustment when making the high speed adjustment.

Advance the spark at the normal position and open the throttle gradually. If motor back-fires through the carburetor it is positive indication of too lean a mixture and nut B should be turned up notch by notch until this is overcome.

If mixture is too rich, as indicated by loading of the motor and heavy black smoke from the exhaust, turn B down until motor operates properly. A further test for the correct mixture at high speed can be made by depressing the air valve when the motor is running at this speed. If when so doing motor speeds up it indicates too rich a mixture.

Turning either adjusting nut up means a

richer mixture or more gas. Down means a leaner mixture or more air. To get highest efficiency from this carburetor, hot air equipment should be used.

Double jet type. If, after following the instructions given below, and with the motor running idle at low speed, the air valve E remains tightly seated, it indicates too small a primary nozzle C, and a larger one should be substituted. If with the proper adjustment, and after stopping the engine, the air valve hangs off its seat the primary nozzle is too large and a smaller one should be used. To change the primary nozzle remove the petcock, insert a narrow screwdriver and unscrew the nozzle.

If the mixture at low speed is correct, but in order to get the proper high speed adjustment it is necessary to turn the nut B up so far that the spring G is in contact with X above it, after the engine has been stopped, it indicates that the auxiliary nozzle J is too small and a larger one should be used. If it is necessary, in order to get the proper high speed adjustment, to turn the nut B down so that there is more than ½ inch clearance between G and X when the engine is idle, it indicates too large an auxiliary nozzle and a smaller one should be used.

Instructions for types H and HA. There are only two adjustments on this carburetor, Fig. 85. A, the low speed, and B for high speed. A is a needle valve, seating in an open nozzle, the opening of which is usually two sizes larger

than is ordinarily necessary, and which permits an increase in gasoline flow to that extent or allows a complete closing. The high speed adjustment controls the flow of gasoline for high speeds by regulating the time at which the secondary needle valve begins to open.





Fig. 85 Stromberg Carburetor, Models "H" and "HA"

To adjust, set the high speed nut B so that there is at least 1-32 of an inch clearance between it and the needle valve cap above it at X when the air valve E is on its seat. The needle valve does not begin to open until B comes into contact with X. Before starting the engine be sure that the rocker arm of the dash adjustment on the carburetor is not in contact with the collar above it at Z when the steering post button is all the way down.

To start the engine, pull the steering post control to its highest position, thus producing a

rich mixture. In cold weather it may also be necessary to close the air supply in the hot air horn by means of a rod connected to R. This should be again opened as soon as the engine starts. As the engine warms up, gradually lower the steering post control and make sure that it is at its lowest position before commencing to adjust the carburetor.



Stromberg Carburetor, Model "K"


The mixture at low speed is controlled by the needle valve A. If too rich is indicated, by the engine "rolling" or "loading," turn A up or anti-clockwise. If the mixture is not rich enough, turn A down or clockwise. To adjust high speed, advance the spark and open the throttle. If the mixture is not rich enough at high speeds, turn B up or anti-clockwise, and if the mixture is too rich turn B down or clockwise.

Instructions for types K and KO. The nut

A is the only adjustment on this carburetor, Fig. 86. The stem of this nut supports the lower end of a spring that controls the air valve. This air valve opens downward into the air chamber. Turning the nut A clockwise or down tightens this spring, admitting less air and producing a richer mixture. Turning A in the opposite direction or anti-clockwise produces a leaner mixture.

Before starting the engine turn A anti-clockwise until a point is reached where, when lifting or pulling up on A, a decided click is heard. This is the air valve coming in contact with its seat. Then turn A clockwise or down until the click is no longer obtained. This turning should be a notch at a time, and when the click can not be heard, turn two more notches in the same direction. To start the engine, raise the steering post control to its highest position. Gradually lower the control as the engine warms up, and make sure that this control is at its lowest position before starting to adjust the carburetor. With the engine warm, turn A up or down, notch by notch, until the engine idles properly. It should not be necessary to change the initial setting more than a few notches.

The high speed mixture can only be affected by changing the nozzle. If the high speed mixture is too thin, so that slightly closing the dash throttle valve R causes an increase of engine speed, a larger nozzle should be used. If the high speed mixture is too rich use a smaller nozzle. The nozzle size furnished is based on 18 inches of hot air tubing. If this tubing is



Zenith Carburetor, Model "O". B, Float Control Lever. C1, Dust Cap. D, Strainer Body. D1, Wire Gauze. E, Gasoline Channel. F, Float. G, Main Jet. G1, Needle Valve. G2, Float Control Collar. I, Gas Well Opening. H, Secondary Nozzle. J, Gasoline Well. K, Gasoline Passage. L, Drain Plug. N, Idling Adjustment S, Float Valve Opening. T, Throttle. X, Choke Tube.

more than 24 inches long, one size smaller nozzle can probably be used, while if the tubing is less than 10 inches long one size larger may be required.

ZENITH CARBURETOR, MODEL O. This carburetor, a cross-section of which is shown in Fig. 87, consists of a float chamber, a carbureting chamber, a system of nozzle and air passages and a hot air sleeve.

Gasoline from the tank enters the strainer body D, passes through the wire gauge D1, and enters the float chamber through the valve seat S. As soon as the gasoline reaches a predetermined height in the float chamber the metal float F, acting through the levers B and collar G2, closes the needle valve G1 on its seat. To see if there is any gasoline in the carburetor remove dust cap C1. If the needle valve can be depressed with the finger there is no gasoline in the carburetor. From the float chamber to the motor gasoline flows through three different channels in various quantities and proportions according to the speed of the motor and degree of throttle opening. With the throttle fully open, most of the gasoline flows through the channel E and main jet G. Some flows through compensator I, then through K to the cap jet H, which surrounds the main jet. The main jet and cap jet work together and their combination furnishes the mixture required for various engine speeds. At slow speed when the throttle T is nearly closed they give but little

or no gasoline, but, as there is considerable suction on the edge of the butterfly the tube J, terminating in a hole near the edge of the butterfly, picks up gasoline, which is measured out by a small hole at the top of the priming plug. The well over compensator I is open to the air through two holes, one of which is indicated below the priming plug in the illustration. These air openings are important.

The hot air sleeve is provided with an air strangler actuated by a lever and having a coiled spring to bring it back to the open position. The flexible hot air tubing is attached to this sleeve and feeds the carburetor with air that has been heated by contact with the exhaust pipe.

To start the engine open the throttle a little way. There will be a strong suction on the tube J which will raise the gasoline and thus prime the motor. The only adjustment that may be useful is the slow speed adjustment, which is obtained by the screw O. Tightening this screw restricts the air entrance to the slow speed nozzle, giving a richer mixture.

It is essential that none of the parts shall be tampered with, or the size of the jets altered by reaming or hammering. These jets are tested for actual flow of gasoline and brought to a standard. The nominal size of the hole in hundredths of a millimeter is stamped on the jet: the higher the number, the larger hole.

Variables that can be modified for the initial

setting of the carburetor: First, the choke tube X. This choke tube is held in place by set screws and can be removed after taking apart the throttle.

It is really an air nozzle, of such a stream line shape that there will be no eddies in the air drawn through it.

For a 4 cylinder engine whose maximum speed s 1,500 R. P. M., to obtain the choke number, nultiply the bore in inches by five and add one to the result.

For 6 cylinder, take a choke one size larger up to $4\frac{1}{2}$ " bore and two sizes larger above $4\frac{1}{2}$ " pore.

If the engine is so built that it can turn up to 1,800 R. P. M., increase these results 8%; up to 2,000 R. P. M., increase 16%; up to 2,500 R. P. M., increase 25%.

A choke tube too small will cause a loss of sharge at high speed, the car will not attain its proper speed.

A choke tube too large will lead to irregularities when slowing down and picking up.

Second—Main Jet C. The effect of this jet s most marked at high speed, 1,400 R. P. M.

Third—Compensating Jet I. This jet, which compounds with the main jet, exerts its maxinum influence at lower speeds, 600 R. P. M., and in picking up.

Fourth—Secondary Well P. This regulates he amount of gasoline used when idling.


Change Speed Gearing.

The means provided for securing different ratios of speed between the engine and road wheels of the car is oftentimes called the transmission. Strictly speaking, the transmission system includes all the parts between engine and wheels; the clutch, universals and rear axle parts, as well as the mechanism that allows various forward speeds and the reverse. The Change Speed Gear takes various forms: planetary, friction, sliding gear and magnetic, each being described.

Change Speed Gears. When a gasoline engine is loaded above a certain limit it slows down, and the intervals of time between explosions in each cylinder become so far apart that the engine begins to labor, and will finally stop altogether, unless some means is provided whereby the revolutions of the engine may be increased without increasing the number of revolutions of the driven shaft, or car axle. This is accomplished by means of the change speed gear, of which there are two classes, viz., those in which an infinite series of variations in speed ratio is possible, and those in which only a comparatively small number of step-bystep ratios can be utilized. In the first class are several styles of belt and friction disc drives, while in the second class are the change speed gears proper, namely, sliding gears, individual clutch gears, and planetary gears.

Talt and friction drives constitute the only

ich variation from the highest to the lowest ed may be possible. In other change speed ars the ratio is changed by passing from one another in a series of definite steps.



PRICTION DRIVE. One of the most simple thods of changing the speed ratio between motor and the driven shaft is the friction ve, which in its simplest form consists of discs at right angles to each other, see Fig.

Marie .


88, in which b is the fly wheel, the exterior surface of which is made a true plane, and usually covered with a special friction metal. A horizontal shaft located crosswise of the car body carries a friction pulley c, in close proximity to the surface of the fly wheel b.

Friction pulley c while secured from turning on shaft, may at the same time be shifted along at the will of the operator, and thus be brought in contact with any portion of the surface of the flywheel, from its center to its outer edge. The shaft also carries on its outer ends, the sprocket wheels which drive chains e and f, by means of which the power is transmitted to the drivers. In this device if the friction pulley c be brought in contact with the exact center of fly wheel b, no motion will be imparted to c, but if it be moved outward from the center of the flywheel it will revolve, the number of revolutions it makes being governed by its distance from the center. The maximum speed is attained by friction pulley c when it is brought into contact with the surface of the fly wheel near the periphery of the latter. All positions of friction pulley c upon one side of the center of fly wheel b impart a forward motion to the car, and all those on the other side of the center impart a reverse, or backing motion. The traversing movement of pulley c along its shaft is usually produced by a hand lever provided with a notched quadrant, whereby the pulley is held at all times in some one of the many positions giving graduations of speed. The method usually employed for making and breaking contact between the friction pulley, and flywheel face, consists in mounting the bearings of the cross, or countershaft in swinging brackets. Another method is to mount these bearings in eccentric housings, a slight rotation of which in the bearing brackets will cause the shaft and with it the pulley to approach, or recede from the face of flywheel b. The movement of the shaft toward, or away from the flywheel is produced by a ratchet retained pedal through a reducing linkage, which multiplies the foot pressure.

Double Disk Friction Drive. The limitation of the single disc and wheel to small power, and light loads, has led to the development of the double disc, double wheel type of friction gear illustrated in Fig. 89.

The engine shaft is extended, and carries two disc fly wheels A and B, while friction pulleys C and D are each carried upon one half of the cross shaft which is divided at its center. Friction pulleys C and D are made to slide along the shafts H and F, and are controlled by a common sliding mechanism, so that they always bear upon points of discs A and B, having the same velocities. Driving contact is effected by swinging shafts H and F in a horizontal plane, and it is obvious that if one of the pulleys, D for instance, is pressed against the face of A, it will revolve in one direction, while

if brought to bear on B it will revolve in to opposite direction, thus providing for a space, or a back-up motion being imparted either friction wheel at will, dependent up whether it is in contact with the forward, or to



rearward disc. It is also evident that if of the wheels, say D, is pressed against A, at the other wheel C is also pressed against hafts will rotate in opposite direction of the common angular velocity of t

wheels and their shafts to that of the discs is in proportion to their distance from the center of the discs. Sprockets upon the extremities of shaft H and F drive the road wheels by chains, and sometimes no differential is employed, power being shut off when turning corners, or, if not, the inevitable slip is divided between the frictional contacts, and the contacts of the tires with the road. A differential may be mounted in either shaft H or F at will.

Instead of the two shafts H and F being separate, they may be joined to form a continuous shaft and pivoted in the center. The shaft as a whole is capable of being slightly swung in a horizontal plane about its center, so as to bring friction wheel D in contact with one disc, and friction wheel C in contact with the other, thus producing either the forward or reverse drive. In this case a single sprocket is carried by the shaft and drives a live rear axle.

Friction Drives—Materials For. In friction drives, one of the surfaces in contact is generally a metal, while the other surface is composed of some kind of organic material, of a slightly yielding or conforming nature. Cast iron with cork inserts may be used for the metallic surface, the cork inserts serving to increase the co-efficient of friction, besides absorbing any oil that may accidently reach the surfaces. Aluminum is no doubt the best material for the metallic surface, on account of its plastic nature. Copper also possesses similar properties. For the non-metallic surface, leather is good so long as oil is kept from accumulating

on it, but its co-efficient drops rapidly as soon as oil gets between the contact surfaces.


Some kind of vegetable fibre, made into a paper or mill board, seems to be the preferred material, and it is comomn to treat such paper with a tarry composition, which tends to raise the co-efficient of friction, as well as to render its value more nearly constant under the influence of water and oil.

The non-metallic friction face is the one worn out in service, or at least it wears the more rapidly. This part of the combination, though of limited life, can be renewed at a comparatively small expense, and it fails only after giving due notice. It is the practice to make the disc face metallic, and the friction wheel rim non-metallic. Great care should be exercised in starting the car, as at such times the disc is liable to slip at speed upon the rim of the friction wheel which is then either stationary or revolving very slowly, and flat spots may very easily be worn upon its surface.

The Planetary Change Speed Gear. This system of transmitting the power at various speeds comprises a high-speed connection for the direct drive, and an arrangement of gears that reduces or reverses the motion when one or another drum on which these gears or pinions are mounted is held stationary. Most planetary systems give only two forward speeds and the reverse, but in some instances they are made to give three forward speeds. They are

used chiefly on small automobiles, or runabouts; but when cheapness of construction is an object they are sometimes employed on touring cars.

In Fig. 90 is shown one form of planetary system. The gear a is the only one keyed to



the engine shaft b. The gears c, d and e all mesh with the gear a, and are made long enough to extend beyond a and mesh with the gears f, g and h in pairs. The last three gears in turn extend beyond the gears c, d and e, and

mesh with the gear i, which is keyed to a sleeve connected to the drum j. The gears c, d, e, f, g and h turn on pins fastened to the drum k, but only the gears c, d and e mesh with a, and only f, g and h mesh with the gear i which turns loosely on the shaft b. The internal gear l meshes only with the gears c, d and e, and is rigidly connected to the sprocket m that drives the automobile. The cover n is attached to the face of the drum k by means of screws, thus forming an oil reservoir that keeps the gears well lubricated when the automobile is running. There are separate brake bands around the drums j and k, and a friction disc keyed to the shaft just outside of the drum j.

When the friction disc is pressed against the drum j, the gear is held so that it must turn with the shaft; consequently, the entire mechanism is locked together and the sprocket m turns at its highest forward speed. It now the friction disc is released and the brake band around the drum j is applied so as to hold it from turning, then the gear a turns the gears c, d and e, causing them to turn the gears f, g and h; but, as the gear i is held stationary with the drum j, the gears f, g and h, and also the drum k, to which they are attached, must revolve around the gear i in the same direction as the shaft turns, but more slowly. The gears c, d and e turn on pins that are fastened to the drum k; consequently, they revolve with it as they turn on their axes and thus cause the internal gear I and the sprocket m to turn in the same direction as the shaft. This gives the slow forward speed.



When the drum j is released, and the drum k is held by a brake band, the gears c, d and e are caused to turn on their pins, and consequently drive the internal gear l in a direction




Fig. 92
Combination Transmission and Differential Gear

opposite to that of the engine shaft, driving 1 automobile backwards. When the brake bar and friction disc are all free from the drum the gears turn idly, and if the engine is running no motion is transmitted to the sprocket a the automobile stands still.

A form of change speed gearing that is use on a large majority of cars is that kno as the sliding gear. All sliding gear tra

missions consist of two principal shafts lying parallel to each other and placed one above the other or side by side. Each shaft carries a series of gears, those on one shaft being permanently fastened against lengthwise movement, while those on the other shaft are capable of being moved along the shaft while turning with it. This latter set of gears is built with either a square or key-waved hub and the shaft on which the set slides is made square or with spline keys to correspond. The gears on the other shaft are made of such sizes that when the sliding members are moved they come into mesh with the gears on the other shaft so that when together they form pairs, that is to say, when a gear on one shaft is in mesh with one on the other shaft it is impossible to cause any other gears to mesh at the same time.

The gears are graduated in size so that the several pairs or combinations that may be formed vary in ratio, and in this way it is possible to obtain different degrees of speed reductions between the two shafts and therefore between the engine and road wheels.

In forms of construction that use the two shafts exactly as described in the previous paragraphs, and in which one shaft is connected through the clutch to the engine and the other one through the drive parts to the rear wheels, the series of sliding gears is made with all of the gears fastened together so that there can be no relative motion between them, and in this




Fig. 93 Selective Sliding Change Speed Gears

case the entire sliding member is moved bodily along the shaft. This particular form is known as a progressive sliding gear. It is necessary, with this type of construction, to pass from one ratio to another in the same order for each operation, and if it is desired to pass from the extreme low ratio to the highest ratio, it is nec-





Fig. 94
Selective Sliding Gear With Disc Clutch in a
Unit Power Plant. A, Clutch Shaft. B, Clutch
Shaft Gear. C, Countershaft Gear. D, Second
Speed Gear. E, Low Speed Countershaft Gear.
F, Second Speed Sliding Gear. G, Low and Reverse Sliding Gear. H, Sliding Gear Shaft.

essary to pass through all intermediate ratios. The progressive form of transmission is no longer fitted to cars and an extended description is not considered necessary.

The type of sliding gear transmission that is most popular is called the selective sliding gear and with the exception of some important modifications is similar in operation and construction to the progressive type already described. Selective sliding gears are shown in Figs. 92 to 97 and the following description will apply more or less to all of them although the form shown in Fig. 94 is specifically covered. It will be noted that the clutch is at the left hand end of the illustration, and through this clutch the power of the engine is transmitted to the shaft marked A. At the right hand end of the shaft A is carried a gear B, and this gear is in mesh with the gear C on the lower shaft of the transmission, it will therefore be seen that whenever the clutch causes shaft A to revolve, gears B and C will also turn, and inasmuch as C is fastened solidly to the lower shaft of the transmission, this lower shaft will turn whenever the engine is running and the clutch engaged. The upper shaft in the transmission marked H is not made in one piece with shaft A, but its left hand end is made of a diameter sufficiently small to fit into a recess in the shaft A and in the hub of the gear B. This construction simply provides a bearing for one end of the shaft H so that it may revolve independently of shaft A. Shaft H is formed with four longitudinal keys integral, and on this shaft are mounted the gears F and G with their hubs formed with keyways to engage the keys on shaft H. This construction allows the gears F and G to be moved lengthwise while turning with the shaft. Gears D and F are made of such diameter that when F is moved to the right it meshes with D and gears E and G will mesh when G is moved to the left. The right hand end of shaft H is fastened to the universal joint that leads to the rear axle.



Sliding Gear Set for Separate Mounting
The operation is as follows: With the engine running and the clutch engaged, power is transmitted through gears B and C to the lower shaft of the transmission, and inasmuch as gear C is larger than B, the lower shaft will run at a lower rate of speed than the clutch shaft. If now the gear G be caused to mesh with E, the shaft H will be revolved but at a still lower rate of speed than the bottom shaft,

and inasmuch as H drives the rear axle it will be seen that the mechanism has given a positive drive at a speed much below that of the engine.




Fig. 96

Heavy Duty Selective Sliding Gear for Rear Axle Mounting

When it is desired to secure a higher speed of the car relative to that of the engine, gears

G and E are withdrawn from each other and gear F is moved into engagement with D. It will be noted that gears D and F are approximately the same size, and the upper shaft will then turn at a speed very nearly the same as that of the bottom shaft, but still less than the speed of the engine. This position is known as second speed or intermediate speed.

When it is desired to secure a still higher ration of speed it is done by moving gears D and F out of engagement and then moving F to the left. Gear F carries one-half of a jaw, or toothed clutch, and gear B carries the other half of this same clutch. It will thus be seen that when F and B are together the clutch will be engaged and shaft A will drive shaft H at the same speed at which A is revolving. This provides high speed or direct drive.

When it is desired to reverse the direction of motion of the car, gear G is moved into engagement with an idler gear that is not shown, and this idler gear is driven through another one on the bottom shaft of the transmission. The idler gear being interposed between the upper and lower transmission shaft gears causes the upper shaft to reverse its previous direction of motion.

Certain variations of selective sliding gears are in use, one of which is shown in Fig. 97. In this particular form the spur gears remain in mesh at all times, but neither set is keyed to its shaft. Between the gears are

mounted jaw clutches, and these clutches are keyed to the shaft. In place of moving the gears into or out of engagement, the jaw clutches are moved, and depending on which clutch is moved and which way it is moved,




Fig. 97
Individual Jaw Clutch Sliding Gear Set
the several sets of gears may be successively
used, providing speed ratios similar to those
in other forms of selective sliding gears.

Magnetic Transmission.

The difference between a car with magnetic transmission and other gasoline cars lies only in this transmission. There is no change in the engine or its operation. There is no change in the driving parts, save as regards their connection with the power. The parts omitted are the clutch and the clutch pedal, gears and shifting lever, flywheel, starter and lighting system, this one transmission unit taking the place of all. There is no mechanical connection between the engine and the driving shaft. This




Fig. 98

The Owen Magnetic Transmission

control also embodies an electric brake, and an automatic electric sprag, which absolutely prevents the car backing down hill, even though the motor is stalled. Should the engine be stalled on a hill, the car can be held without use of the brakes by simply moving this control lever into high speed position.

The power is never disconnected from the driving wheels of the car from the moment of starting up to the highest speed.


The electrical apparatus consists of two units, Fig. 98, contained in a one-piece construction: the one nearest to the engine has its magnetic field pieces keyed to the engine crankshaft and acts as a flywheel to the engine. armature is mounted on the propeller or drive shaft, hence it will be seen that both these parts can revolve. The second unit of the apparatus has stationary magnetic fields and its armature, as in the first case, is mounted on the propeller The first unit becomes shaft. in dynamo, magnetic clutch and a motor, the second unit, a motor and dynamo.

A controller, with resistance coils internally contained, is bolted to the chassis frame forward of the dash, alongside of the engine, and is operated by a lever on the steering wheel through a small gearing at the bottom end of the steering column.

By placing the control lever in the position "cranking," a battery is connected through the first unit, which in this instance becomes

a motor, and once the engine is cranked, the lever can be placed in the "neutral" position until ready to start the car.

On moving the control lever to the first position, turning effort is produced by weakening, with a shunt resistance, the field of the first unit, which becomes a dynamo, and



Principle of the Magnetic Transmission: A, Engine Crankshaft. B, Revolving Field. C, Stationary Field. D, Front Armature. E, Rear Armature. F, Propellor Shaft.

slip between the magnetic fields and the armature, is fed to the second unit, which, acting as a motor, produces a powerful starting torque. At the same time the pull of the magnetic fields of the first unit acts as a magnetic drag on its armature, and thus two forces assist in rotating the propeller shaft, which, through the bevel drive, communicates power to the road wheels.

The second position of the control lever cuts the resistance out of the first unit (dynamo) field and shunts through a high resistance some of the field current in the second unit (motor), thereby increasing the speed of the car.

In the third, fourth and fifth control lever positions, the second unit (motor) field is successively weakened until in the sixth control lever position, the field current is almost entirely shunted, so that previous to placing the control lever in the seventh (and last) position, the second unit is practically of itself not doing any work, apart from the fact that there is very little slippage between the first unit (dynamo) field and armature, resulting in generating of but small current. In other words, the drive shaft is being carried around almost entirely by the magnetic drag of the first unit's field on its armature. It will hence be seen that there is an electrical balance in effect throughout the entire sequence of operations.

On placing the control lever in the seventh position, the first unit becomes what may be termed a "magnetic clutch," the armature and field are closed-circuited, and an almost negligible slip only is required to generate sufficient current to enable the field to drag its armature around with it.

The second unit with the control lever in high speed position becomes a generator, and when the car is running, charges the lighting and starting battery with a predetermined charge.

From this point on the entire control is brought about by accelerating or decelerating the gas engine, the armature of the first unit follows its magnetic field promptly, generating of its own accord whenever necessary more current and hence getting more magnetic drag to bring it up to the same speed as the magnetic fields. Thus, so long as the control lever is in any position other than neutral on accelerating, an increase of speed is obtained, but on decelerating, the car coasts just like an ordinary car with the clutch released. This is brought about by the armature of the first unit traveling faster than the fields, and thus not generating any current until such a time as the car comes back to the speed, where the armature of the first unit is traveling at the same or slightly lower speed than the field pieces or the engine, when again current is generated and the drive taken up as before.

Should excessive grades be encountered where extra torque may be desired, the placing of the control lever in a lower position will give the desired result, and naturally by increasing the engine speed with the control lever in a lower position than high, more current will be generated, due to the extra electrical slip, and thus give added torque.

At neutral position the maximum electrical braking effect is obtained. Here the first unit is open-circuited and the second unit closed-circuited and the magnetic braking reaction brakes the car to 10 miles per hour, below which speed the armature does not revolve within the motor field fast enough to create the braking effect, thus automatically holding the car on a grade at about the above speed.

Chassis. The word chassis since its adoption into the English language, is taken to mean the frame, springs; wheels, transmission and in fact all mechanism except the automobile body. In its original French it does not mean all this, but is strictly restricted to mean the frame, or the frame and springs.

Chauffeur. This term when literally translated means the stoker or fireman of a boiler. The use of the word has been extended to the operator of a motor car, but does not usually refer to the paid driver, who is generally known as the mechanician or mechanic.

Clutches may be classified as follows: a, cone; b, disc; c, band; cone clutches may, in turn, be subdivided as follows: a, metal to metal; b, leather faced; c, cork insert; while disc type may be classed as: a, leather faced; b, multiple disc; c, cork insert; and band clutches may be put down as of the a, constricting, b, spiral, or c, expanding types. Clutches, of whatever type or class, have but one prime object, i.e., to enable the operator to start and stop the car without having to stop the motor. There is a secondary consideration, if we take into account the fact that it is convenient to be able to slip the clutch, on occasion. Some types lend themselves to this secondary purpose with greater facility than others, and it is also true that some clutches are most easy of application, all things considered.


As clutches are at present designed, the question is, can slipping be tolerated? or, can

clutches be slipped to control the speed of a car? It is believed not. The average clutch has very little of the character of the average braking system, and when it comes to brakes they do not last so long that it is desirable to wear them out sooner than they will naturally need replacement. In other words, it seems quite out of the question to consider the clutches of today as suitable for the double purpose of clutching and speed controlling, by way of slipping the clutch at will. It is not uncommon to hear autoists talking of the multiple disc clutch as one that undergoes little or no deterioration as a result of continuous slipping under variations of load.

They seem to think that the large surface exposed, especially in view of the fact that the discs are submerged in oil, will prevent damage if the clutch is caused to slip. They forget that the discs are thin, and also that they are loose on the splines, keys, or feathers that prevent the discs from rotating. No member keyed onto a shaft will stand much abuse. This is especially so, if the member has but little bearing surface on the key. Even a considerable number of such members working in unison will fail to stand up under the work because the joint is not firm. Lost motion is bound to result in more lost motion in a short while, and in a multiple disc clutch the discs soon fray out and interfere with each other, and with the clutching functions, within a space of time so

short as to surprise even those most experienced in the use of this type.

Band Clutch. A band, or friction ring, clutch, is shown in Fig. 100. The wheel which is connected to one of the shafts is shown at a, and the band, or ring which is connected to the other shaft and which is made in two parts, is shown at b and c. At d and e are curved arms



pivoted at f and g. The links h and i connect these curved arms to the parts b and c of the band. By means of a fork, and tapered sleeve, not shown, the ends j and k of the arms are forced apart when the clutch is brought into use. This throws toward the shaft the ends l and m of the levers d and e, and brings the two parts b and c of the clutch ring in contact with

the friction or driving surface of the wheel a, which is thereby forced to turn with the driving shaft. The band clutch has had many exponents in the motor car art, but is open to centrifugal effects to such an extent that it requires considerable ingenuity to overcome troubles arising therefrom. At high engine speeds the operating levers have been so arranged as to lower the normal expanding pressure.





Fig. 101

CONE CLUTCH. There are a number of modifications of this type of clutch, the general principles of which are illustrated in Fig. 101. The flywheel a is secured to the shaft b by means of bolts through the web of the wheel. At c is an expansion ring into which the friction cone d fits. The helical spring e holds the cone against the expansion ring with the required

amount of force. At f is a ball bearing that takes the end thrust when the cone is pulled away from the expansion ring.


The arms g are coupled to the shaft that turns with the friction cone. Ordinarily the two parts of the clutch are held together by the pressure of the spring, and when it is desired to disconnect the cone, a foot pedal is forced down so as to act on a fork and sleeve and pull the cone



away from the expansion ring. When the pedal is released, spring e forces the clutch into action again.

Fig. 102 is a sectional view of a form of leather faced cone clutch in which the male part of the cone moves axially toward the engine. Fig. 103 shows a clutch constructed on the same principle, but in place of having one strong actuating spring surrounding the axis, it has three weaker spiral springs near the pe-


riphery of the male member. Fig. 104 is a vertical section of a clutch suitable for a 50 H. P. car. The cone angle is 13 degrees, and the diameter 16 inches, with a total frictional area of 128 square inches, the axial pressure resulting from the spring being 375 lbs. A small spiral plunger spring A under the leather face B causes it to pick up the load more quietly and smoothly. Fig. 105 illustrates an early form of clutch intended for a car of about 20 H. P. One form of toggle joint is also shown at A.



This clutch also has multi-springs for creating the proper frictional contact, and a peculiar form of spring application simple in the extreme. A multi-cone clutch is shown in section in Fig. 106. Its action is as follows: When the clutch engages, the smallest cone seizes first, commences to revolve and subjects the spiral springs between the next two clutches to torsional movement, which draws them together and brings the two outer cones into action; the idea being that the small clutch shall slip, tend

to accelerate the car, that the medium clutch shall behave in a similar manner and that when the large clutch comes into play the three combined pick up the load and move the car.


The so-called inverted cone is well illustrated



in figure 107. The reversed cone is contained in an extension A, built onto the flywheel B. When the cone is disengaged it moves toward the engine, exactly reversing the action of the foregoing type. This clutch has its adherents.

and it is a good one, differing very slightly, if properly assembled, in its efficiency from the direct-acting cone. It may be kept free from dirt and oil much more perfectly than in the other form.

DISK CLUTCH. A clutch of the multiple-disc type is shown in Fig. 108. A two-arm spider a, keyed to the shaft b, serves to hold in place a number of metal discs c, between which are other metal plates d held on the sleeve e by means of a key f. The sleeve e is in turn keyed



to the shaft g, and to it is screwed a ring h having three pairs of lugs carrying three levers i, with rollers j at their outer ends, as shown. The other ends of the three levers press against the plate k when the clutch is engaged by an inward movement of the collar l, plate k being free to move along the key f. Discs c are free to move longitudinally on the arms of the spider a, and also on sleeve e, around which they rotate when the clutch is out of engagement; but the arms of the spider, fitting into slots in the discs, cause them to rotate with the shaft b.

The plates d are free to move longitudinally on the key f in the sleeve e; and since the sleeve is keyed to the shaft g, it is evident that, when in engagement with the discs c, the plates d must cause the shaft g to turn with the shaft b. The discs c and plates d run in an oil bath,




Fig. 107

obviating wear of the plates and discs. These are brought together forcibly by throwing the cone faced end of the collar I against the rollers j, thereby causing the ends of the three levers i to press the plates and discs together with sufficient force to cause the shafts b and g to rotate as one shaft.

FIVE-PLATE CLUTCH. In the matter of the number of plates in the disc clutch there is no agreement between designers. Some use a very large number of thin plates, as many as fifty or sixty, and others use a very small number, as few as six or eight; in fact, it may be said that the single disc clutch, which has only two frictional




Fig. 108 Five-Plate Clutch

surfaces, is the lower limit. One arrangement which uses five plates is shown in Fig. 108. The diameter of the clutch is somewhat smaller than that of the single or three-plate types, but its diameter must be quite large in order to transmit considerable horse power.

Clutches are made with various numbers of plates, from three to more than sixty, depending on the work required and the size and material of which the plates are made. Plate materials include hardened steel for both members, steel and bronze, steel with cork inserts, and steel covered with some friction material similar to brake lining.

Disc clutches using steel to steel are operated in a bath of oil. Those using bronze and steel may or may not operate in oil. As a general rule, clutches that are not enclosed are fitted with cork or an asbestos composition as the friction material. However, either of the forms just mentioned operate satisfactorily in an oil bath, and it is, therefore, simply a question of choice with the designer. Unenclosed clutches are called "dry-plate clutches."

CLUTCH TROUBLES. One of the greatest sources of trouble for the novice lies in the clutch. This may be just right, it may be slipping, or it may be what is called fierce. The second manifests itself in such pleasant situations as climbing a hill when, with the engine running at its highest speed and the proper gear engaged, the car starts to run backward instead of forward. Or on the level, with the engine racing and the high gear in, no speed results.

The last condition shows itself in the sudden jumping forward of the car when the clutch has been let in, or it may even be so severe as to shear off the bevel driving gear when used with studded non-skid tires or any form that will not slip easily.

To repair the first, look at the leather, if this

is all in good shape with an apparently good surface, but has lubricating oil on it, wash the surface well with gasoline. It is not a bad idea to roughen the surface of the leather a little with a coarse file.

The harsh or fierce clutch is remedied by the application of a proper oil for this purpose. Castor oil is universally used and a good way is to soak the complete clutch in it over night. This will cure a case of harsh leather, but it may be that the trouble is only a lack of adjustment of spring tension. Usually there is an adjusting nut and a locking nut. Back off the latter and make an adjustment. Then tighten the lock nut to retain it. For the beginner, it is better to adjust a little at a time and make several successive jobs of it than to try to do it all at once. But always adjust it as soon as possible.

The leather of the ordinary cone clutch by degrees acquires a sort of coarse surface glaze, which may or may not represent actual charring of the leather, but is certainly due to the slipping it experiences. A leather with its surface so glazed has a very harsh action, since the surface is so hard that it grips all at once. The glazed surface will not absorb oil to any appreciable extent, a fact which is easily seen on attempting to dent the surface with a thumb nail after giving the oil time to soak in. In this condition the best thing to do is to put on a new leather. Unless the angle of the cone is too

abrupt, a piece of ordinary belting will serve the purpose, provided it is of uniform thickness throughout. The belting may be soaked in neatsfoot oil over night before applying, and this will render it pliable enough to take the shape of the cone. If the old leather is retained in service it becomes almost essential to squirt a little oil on it every day or two, as otherwise it may take hold with such a jerk as to endanger the transmission shafts. If the cone releases by drawing backward, there are probably openings in the web of the cone through which the spout of a squirt can may enter. Oil squirted into the flywheel interior will then quickly find its way to the clutch surface. Sooner or later, however, the leather will become glazed so smooth that it will not hold at all, and it is then liable to slip and burn up without warning. There are few things more exasperating than a clutch which cannot be made to hold properly, particularly when the car happens to be covering a bad stretch on which every available bit of power that can be transmitted to the rear wheels is necessary. The use of emergency remedies under such circumstances most often leads to the necessity for clutch repairs, as road dirt and grit are not the best things possible for the leather facing, and frequently no other friction producing compound is to be had at the time.

RENEWAL OF LEATHER ON CONE CLUTCH. Remove the old leather by cutting off the rivets

on the underside, and driving the rivets through to the outside. Keep the old leather and use it as a pattern by which to cut the new piece. It will be much better, however, to purchase from the factory a new leather of the proper width and thickness. As a new leather will have considerable "give," it must be stretched tightly over the cone. First cut one end of the leather square and fasten it to the cone with two rivets. The other end should not be cut at this stage of the work, but brought around to meet the fastened end, and, after tightly stretching it over the small end of the cone, fasten it with a single rivet. Then force the leather up onto the cone, drill out and countersink the holes and rivet up securely. The only knack in the operation is to keep the leather tight that it may be a snug fit on the cone. A loose leather will, naturally, be a dead failure. After the leather has been forced into its place the uncut end should be trimmed to make a good joint. Any unevenness may be trued up with a file. The new leather will readily absorb several applications of castor oil before it becomes smooth and pliable.

Care should be taken that the rivet heads are countersunk below the surface of the leather. In case they work flush, owing to the wearing down of the leather face, they should be riveted. The "biting" or jerky action of a cone clutch may often be traced to the rivets working out, and this will frequently prevent the

clutch from being readily disengaged. Reriveting will prove an effective remedy in this case, and considerable additional service may be had from the leather before it wears down to the rivet heads.

Combustion Chamber. That part of an explosive motor in which the gases are compressed, and then fired, usually by an electric spark, is known as the combustion chamber. The interior of the combustion chamber should be as smooth as possible and kept free from soot, or hard carbon deposits such as are induced by excessive lubrication, or the use of too rich an explosive mixture.

It will be found to be no small task in designing an explosive motor with the usual form of valve construction and operation, to keep the combustion chamber down to the required dimensions and at the same time have it free from bends or contracted passages between the combustion space and the valve chamber.

Many attempts have been made to obviate this difficulty by making the combustion chamber simply a straight extension, or continuation of the cylinder. In this manner both the admission and exhaust-valves can be placed in the cylinder itself and an ideal combustion space secured. This plan has, however, certain disadvantages, from the fact that it not only lengthens the motor, but requires a more complicated form of valve operating mechanism

than if the valve chamber were at the side of the cylinder as is usual.

Commutators, Ignition. The commutator of the ignition system of a multi-cylinder gasoline motor has a three-fold use: To switch the battery current in and out of the electrical circuit at the proper time—To transfer the battery current successively from one coil to another—To vary the point or time of ignition of the explosive charge in the motor cylinder.




Fig. 109

The commutator shown in Figure 109 is for a four-cylinder motor and is designed for use with induction coils without vibrators, which are known as single-jump spark coils. The studs of the screws A and springs B are carried by insulated bushings located in the back of the commutator case. The nose of the cam C successively engages with the springs, causing them in turn to make contact with their respective screws. The battery and coil circuit is completed through the screws A, and a

ground to the cam C, by means of the springs B, when in contact with their respective screws and the cam.

This device is said to cause a good spark at the plug on account of the quick break between the spring and the screw, the electrical circuit being broken the instant the spring leaves the screw and before the cam has allowed the spring to resume its normal position. This form of commutator cannot be short-circuted by oil




Fig. 110

or dirt getting between the spring and the screw, as the spring B only forms a part of the electrical circuit when in contact with both the cam C and the screw A.

Another form of commutator for a four-cylinder motor is illustrated in Figure 110, which has a rotary spring contact-maker A, which engages successively with the heads B of the screws C. The screws are spaced equidistant around the fiber ring D, which also forms the case of the commutator, and are held in position

A is attached to a hub F on the cam shaft of the motor. The time or point of ignition may be varied by moving the commutator case about its axis by means of a rod attached to the arm G.

Figure 111 shows two commutators of very similar construction. The one at the left in the drawing is for a two-cylinder motor, and has flat spring-steel contact-makers. The commu-




Fig. 111

tator shown at the right of the drawing is for a four-cylinder motor and instead of having flat spring contact-makers, it has either carbon or copper contact-brushes, which are held against the commutator by short coil springs in the insulated bushings located around the periphery of the commutator case. The commutator is made of vulcanized fiber with a short brass or or copper segment, which is grounded to the cam shaft as shown.

The forms of commutators illustrated in the drawings may be constructed for use with a motor of any number of cylinders, by increasing or decreasing the number of contact-makers located around the commutator.

Compression. Normal compression in any given design of motor would be the compression (cold) fixed by the designer by the relation of the sweep of the piston to the clearance space. Normal compression is not the same, as measured in pounds per square inch, in all motors. The normal compression as against loss of compression would be evident to a motorist in the act of cranking. Were the compression to become abnormal, as a result of carbon deposit, it would be rendered manifest by knocking on a gradient, or by way of pre-ignition.

LIMITS OF COMPRESSION. With gasoline vapor and air, the compression cannot be raised much above 85 pounds per square inch, but with the heavier fuels, such as kerosene, a compression as high as 250 pounds per square inch has been used economically. It has been the advantages of high compression that has turned the designer of automobiles toward the heavier fuels; but, with the increase of compression, there are many troubles in regard to loss of power and increased fuel consumption, owing to the wear of the valves, pistons and cylinders, which produces a loss in compression and explosive pressure, and a waste of fuel by leakage.

COMPRESSION, How to CALCULATE. The com-

pression in atmospheres of a motor may be readily found by dividing the cubic contents of the piston displacement by the cubic contents of the combustion chamber in cubic inches, and then adding one to the result.

To ascertain the compression in atmospheres of a motor, when the cubic contents of the combustion chamber are known: Let S be the stroke of the piston in inches and A the area of the cylinder in square inches. If C be the contents of the combustion chamber in cubic inches and N the required compression in atmospheres, then

$$N = \frac{S \times A}{C} + 1$$

Example: Find the compression in atmospheres of a motor of 4-inch bore and 6-inch stroke, whose combustion chamber has a capacity of 18 cubic inches.

Answer: Six multiplied by 12.56 equals 75.36, which divided by 18 gives 4.19, and 4.19 plus 1 equals 5.19, or the compression in atmospheres required. One atmosphere = 14.75.

If it is desired to ascertain the compression in atmospheres of a motor, the combustion chamber of which is of such shape that its dimensions cannot be accurately calculated, its cubic contents may be found by filling the combustion chamber with water, and after removing the water, ascertaining its weight in ounces, and then multiplying the result by 1.72. This gives the capacity of the combustion chamber in cubic inches. The compression of the motor can then be readily calculated from the formula given herewith.

Compression, How to Test for Leaks in. To discover if there are any leaks in the compression of a gasoline motor, a small pressure gauge reading up to 75 pounds should be fitted into the spark plug opening in the combustion chamber by means of a reducing bushing. When turning the starting crank of the motor slowly the gauge should indicate at least 60 pounds per square inch if the compression is in good condition.

To test for leaks, fill a small oil can with soapy water and squirt round every joint where there may be a possible chance for leakage. Get an assistant to turn the crank and watch for bubbles at the joints.

If the joints are all tight, next examine the condition of the admission and exhaust-valves and if either of them needs regrinding, it should be done, first with fine emery powder and oil, then finished with tripoli and water.

When the valves have been ground to a perfect fit, if the compression still leaks, the piston rings should be examined, as the trouble will be found to be with them.

Condenser, Use of. A condenser is used in connection with a Rumkorff, or jump-spark form of induction coil to take up or absorb the

tic charge of electricity, occasioned by the f-induction, or electrical reaction in the priry winding of the coil upon the breaking of battery circuit by the interrupter or vibra-. This static charge is given up or dis-




Fig. 112 Condenser

arged into the primary winding of the coil ng with the battery current upon the closing the circuit, thus intensifying the action of secondary winding of the coil in a great dee.

By absorbing the static charge of electricity

the condenser helps to decrease the spark or arc between the platinum contact points of the interrupter or vibrator, thereby lengthening the life of the platinum contacts by reducing the erosive action of the induced current spark. A jump-spark coil very often refuses to work properly on account of the condenser connections having become loose.

The capacity of a condenser is directly proportional to the area of the tinfoil sheets composing it, to the distance between the sheets, and to the inductive capacity of the dielectric, or separating medium.

In condenser work it is the custom to cut the tin-foil sheets to some convenient rectangular shape, as shown in Fig. 112, each one with a neck so that all the + sheets can be soldered together, on one side, and all the - sheets on the other. The dielectric paper is cut without necks, so that the necks of the tin-foil sheets can be readily contacted with each other, in such a way, however, that the + sheets will not contact with the — sheets at any point. The paper is 1 inch wider than the tin-foil, so that the paper extends out for ½ inch all around, and beyond the tin-foil. In the illustration the top sheet of paper is removed to show the shape of the tin-foil sheets, and it will be observed that all the tin-foil sheets are of the same size, but they are so turned that the + sheets have their necks all to one side, while the - sheets have all their necks to the other

side. Any number of sheets can be used, with the understanding that a sheet of oil-paper will be placed between adjacent tin-foil sheets, so that the + and — sheets will not contact with each other at any point.

If the paper is pierced, or if the + and - tinfoil sheets contact with each other, the condenser will fail to perform its functions, and it sometimes happens that the sheets are punctured in service, thus rendering the condenser valueless for the intended purpose until the puncture is repaired, to do which requires that the fault be found, and a new sheet of paper substituted.

Condensers are made to fit into housings that allow of ready application on the instrument with which they are used. In many cases it is desirable to use a cylindrical form, while in others a rectangular outline may be permissible. Condensers of unusual form are often made from two long strips of tin foil, laid one upon the other, and separated by waxed paper or other insulating material. The long strip is then rolled or folded into the shape that is desired and the ends of the foil are attached to the condenser terminals.

A punctured or faulty condenser will cause the spark to be very weak and will also cause quite violent arcing at the breaker contacts, this arcing burning and pitting the contacts until they can no longer carry the current. The condenser connections must always be secure. Cooling Systems. The cooling of a gasoline, or other automobile engine may seem a simple thing to the uninitiated, but in reality it is far from that and it is a fact that the deeper one goes into it, the more complex the situation becomes.


The cooling of internal combustion engines, in which category automobile engines come, is divided into two classes, viz., air cooled and liquid cooled. There are two reasons for cooling the cylinder walls. One is to permit of proper lubrication, and the other is to prevent pre-ignition. But it is advisable to allow the cylinder to work at as high a temperature as the lubricating oil will stand without carbonizing. The nearer the cylinder temperature can be kept to 350 degrees the more efficient will the motor be, speaking from the thermal standpoint, while on the other hand, mechanical efficiency may be sacrificed by too high temperatures. Therefore, a balance between the two should be established, and this course is usually pursued in practice.

AIR-COOLED AUTOMOBILE ENGINES. The successful air cooling of an engine cylinder depends chiefly on an abundant flow of cool air over it. Some cylinders, however, are arranged to utilize a more rapid flow than others. Generally speaking, the designer can take his choice between a comparatively plain cylinder surface over which a current of air can flow almost unchecked, and a cylinder with its heat-radiating

surface greatly multiplied by numerous pins, deep ribs, or other projections. These projections increase greatly the radiating surface, but tend to obstruct the flow of air, although they aid in carrying away the heat. In the latter case, the velocity of the air stream does not need to be high, provided it is continuous; while in the former case, a constant and abundant supply of air is essential.

AIR-COOLING SYSTEMS. In modern automobile practice two systems of cooling are used—the air system and the water system, each of which has its adherents. As its name indicates, the air cooling system allows the air to strike the exterior of the engine cylinder, and thus carry off the excess of heat generated within it. give the radiating surface, required for air cooling, the exteriors of the cylinders are either grooved or corrugated, or the surface of the cylinder is studded with metal pins or fins, so as to present as much surface to the outside air as possible. The object in the construction of all air-cooled motors is to make their external surfaces offer as great a surface to the air as possible, and to furnish these surfaces with as large a supply as possible. A fan is therefore used, driven by the engine itself, which constantly directs a current of fresh, unheated air upon the surface of the cylinder.

Fig. 113 is a sectional view of a vertical aircooled gasoline motor. The radiating ribs cast



AIR-COOLED MOTOR

Fig. 113

around the cylinder and valve chamber are plainly discernible. This motor has a detachable atmospherically operated admission-valve, without packing. The valve and cage may be removed by simply removing two nuts.

Modern forms of air cooling give excellent satisfaction regardless of the temperature of the outside air. Individual air leads for each cylinder insure even cooling.

WATER CIRCULATION. There are two systems of water circulation in use for cooling the cylinders of explosive motors: The natural or thermo-siphon system and the forced water circulation.

In natural or thermo-siphon water circulation the fact that cold water is heavier than hot water is taken advantage of. A head of water is obtained by placing the tank above the level of the cylinder water-jacket, and as the water in the jacket is heated by the combustion, the cooler water from the tank flows in, forcing the heated water in the tank to take its place, and in this manner an automatic circulation of water is set up. The pipes must be so arranged that they offer every facility for the free circulation of the water, the cold water leaving through a pipe at the bottom of the tank and entering at the lowest point of the cylinder, while the hot water leaves the top of the cylinder and enters the tank at the side near the top. The water circulation, though automatic, is very slow, and for this reason requires a




Fig. 114

larger body of water to produce as good a cooling effect as a forced circulation.

In forced circulation a rotary pump is used,

the direction of the flow being such that the water passes from the pump to the cylinder, thence to the radiator, on to the tank, and then through the pump again, thus completing its circuit. The water in this way gets the maximum cooling effect from the radiator, and the body of water in the tank is kept cool. On account of the high speed of a gasoline automobile motor, and the comparatively small amount of power required to circulate the water, rotary pumps are much used. As there are no valves to get out of order, and high speed is obtainable, this type of pump is very suitable for automobile use.

In order that a thermo-syphon system may operate successfully, it is absolutely essential that the water passages around the cylinders, as well as the connections to the radiator, be of large capacity and perfectly free from obstructions. Sharp bends should be avoided in every case.

Overheating—Causes of. Overheating of the engine, when not traced to poor circulation, is almost always caused by too much gasoline. There are, however, many possible causes of over rich mixture, some of which on the face of them might seem to be causes of lean mixture rather than rich. Prominent among these latter is too low a gasoline level in the float chamber due to the float valve closing too soon. The immediate effect of this is to make the mixture too lean at starting, and at low

speeds. Starting is therefore difficult, and if the auxiliary air valve begins to open at the usual motor speed, the mixture will again be much too lean. These symptoms, however, unless properly interpreted will probably lead the owner to increase the gasoline supply, or to adjust the spring tension of the auxiliary valve so that the latter will not open until quite high speed is attained. In other words, he adjusts to give a suitable mixture at one speed, and at other speeds the mixture is extravagantly over rich. It is well not to be too easily satisfied with the carbureter's performance, as it may be found that one fault such as the above has been imperfectly offset by another fault in the other direction instead of the correct adjustment being made where the fault really lies. A good carbureter will give a sensibly correct mixture at all speeds within the ordinary range of the engine. If it fails to do this the thing to do is to investigate until the trouble is found.

Insufficient lubrication increases the friction between the piston and cylinder, and so generates extra heat. Bad or unsuitable oil may have the same effect.

Wear of the cams, tappets and valve stems may be the cause of overheating, as it would not require much loss from the faces of the various moving parts that come in contact to cause a more or less appreciable difference in the operation of the valves, and as this wear tends to bring about a later action, it may be

sufficient in the case of the exhaust valve to retain the burnt charge considerably beyond the time at which it should be allowed to escape. Where a motor runs at a speed of 800 revolutions per minute or over, it will be evident that it is a matter of very small fractions of a second.

Another cause of overheating may be the deposit of a fine film of scale on the inside of the circulating pipes and radiator. This scale is of a mineral nature, and, in addition to being an excellent nonconductor of heat, it is deposited in such intimate contact with the metal that the latter is practically insulated and its radiating power entirely lost.

Overheating—Effects of. The immediate effect of overheating is to burn up the oil in the cylinders, or crank case. This causes a smell of burning, and an order of hot metal. There is sometimes a slight smoke and the motor will make a knocking sound. The cooling water begins to steam, and the car will gradually slow down and finally stop.

The most serious cause of a stoppage on the road is overheating, which causes the lubricating oil to burn up and the piston to expand and grip or seize in the cylinder.

OVERHEATING—REMEDIES FOR. As soon as any of the above symptoms are noticed:

The motor should be stopped at once.

Kerosene should be copiously injected into

the cylinders and the motor turned by hand to free the piston-rings.

The parts should then be allowed to cool.

Do not pour cold water on the cylinder jackets, for fear of cracking them, but pour the water into the tank so as to warm the water before it reaches the cylinder jackets.

A simple test in the case of an overheated motor is to let a few drops of water fall on the head of the cylinder. If it sizzles for a few moments the overheating is not bad, but if the water at once turns into steam, the case is serious.

Detach the spark plug or plugs, and turn the starting-crank slowly. This draws in cold air and cools the inside of the cylinder and the piston.

After the parts are cool, it will be advisable to put some oil in each cylinder.

Dalton's Laws. The relation between the vapor tension and the quality of vapor is expressed by two laws known as Dalton's laws, as follows:

- I. The pressure, and consequently the quantity, of vapor that will saturate a given space are the same for the same temperature, whether the space contains a gas, or is a vacuum.
- II. The pressure of the mixture of a gas and a vapor is equal to the sum of the pressures that each would exert if it occupied the same space alone.

If a volatile liquid is added to a gas, and the

resulting mixture of gas and vapor is allowed to expand so that the pressure remains unchanged, the volume of the mixture will exceed the original volume of the gas. The ratio of this new volume to the original volume of the gas is equal to the ratio between the combined pressure of the gas and vapor, and the pressure of the gas alone, had the volume remained constant.

Deposits in Water Jacket. If the cooling water contains lime or alkali, the heating of the water in the jacket will cause these solid substances to be deposited in the cooling spaces. This will soon choke any narrow ports and prevent proper circulation, resulting in overheating, rapid wearing of the valves, and loss of power and efficiency. A simple remedy consists of the application, at regular intervals, of a dilute solution of hydrochloric, or muriatic, acid, made as follows: Dilute one part of muriatic acid with nineteen parts of water, and, after draining the jacket completely, pour in enough of the solution to fill the entire cooling space. Allow the mixture to remain in the jacket for not more than 8 to 12 hours, after which wash the cooling space thoroughly by running clear water through it. If the solution is permitted to remain in the jacket longer than the period stated, there is danger that the metal may be damaged by the action of the acid. The acid will soften and dissolve the lime or alkali, and the clean water will remove it from the jacket.

It is generally sufficient to apply this method of removing the deposits once every two weeks. If neglected too long, the acid will not dissolve the deposit.

Differential Gears. So long as an automobile moves in a perfectly straight path, its two driving wheels turn at equal speed, since they must cover equal distances in equal periods of time, and it would be perfectly allowable that the two wheels should be locked together, as there would be no relative motion between them. The power could be transmitted to either one, or to both of them with perfectly satisfactory results under these circumstances. When, however, a car is to be moved in a curved path, as in turning a corner, the driving wheels must move at different speeds, since the outside one has to cover a longer distance in the same time than does the wheel which is on the inside of the curve. If the two wheels were locked together under these conditions, one or both of them would be forced to slip, as the speeds transmitted to them would be equal, while the distances they are to travel are unequal. This difficulty is successfully overcome by the use of the differential gear which transmits the power from the change-speed gear to the rear axle, or driving wheels of the car. Differential gears consist of a set of four or more gears attached to the ends of two shafts that meet, and are usually in line, so that both are rotated in the same direction. But, if either meets with extra resistance it may rotate more slowly than the other, or may stop altogether.

These gears are used on the driving axles of automobiles. The axle is made in two parts, with a gear on the end of each, where the parts come together. Other gears mesh with both these axle gears, and are driven from the engine by a sprocket and chain, or by bevel gears and shaft. These gears turn the axle, but permit




Fig. 115

Bevel Gear Differential With Bevel Driving Gear and Pinion

its two parts to turn in respect to each other so as to allow the automobile to go around a corner without causing the wheels to slide, or skid. The rear wheels are each fixed to a half of the rear axle, and both receive power, hence it is necessary to allow one wheel to turn at a different speed from the other, and this is accomplished y means of the differential gear.

BEVEL GEAR DIFFERENTIAL. Fig. 117 shows a bevel gear differential in which A and B are the two halves of the rear axle, which is divided at its center. One of the driving wheels is carried on A, and the other one on B, while the inner ends of the two half axles are each fitted with bevel gear wheels C and D. Meshing with these two bevel gears are two, three or four bevel gears, two of which are shown at E and F. These pinions are supported on radial studs which project inwardly from the casing. Upon this casing are sprocket or bevel gear teeth which are driven from the engine. The teeth of each pinion, E and F are at all times in mesh with the teeth of both the bevel gears C and D on the axle. When the car is in operation, the chain or bevel drive revolves the case containing the pinions, and the power is transmitted through the teeth of the pinions E and F to the teeth of the gears C and D and thence to the axle and wheels. So long as the vehicle travels in a straight line, the pinions act as stationary driving members, and have no occasion to revolve, as the two halves of the axle and their gears are moving at equal speeds. They merely revolve with the frame. The same teeth of the bevel pinions and gears are in contact so long as a straight path is traversed. When, however, the car is steered in a curve and different velocities are required in the drivers and the bevel gears with which they are connected, the pinions no longer act as fixed driving members, but each turns upon its stud and allows the necessary relative motion between the two bevel gears, and at the same time they continually transmit power to the two ends of the axle because they are always in mesh with each other. This compensating action may continue indefinitely through any amount of variation between the driving wheel rotation, because one




Fig. 116
Bevel Gear Differential Connected to Sprocket

tooth of the pinions comes into play as fast as the preceding one disengages with the bevel wheels on the shaft. Fig. 116 presents a larger view of the bevel gear differential, the two gears on the rear axle being shown as secured to the shaft, and to a sleeve on the shaft. The differential employed here has three bevel pinions turning on radial studs, which are secured to the arms of a spider at their inner end. A differential bevel gear, although most extensively used, is open to the objection that the bevel gears impose an end thrust upon the two halves of the mainshaft on rear axle. This has led to the design of differentials in which only spur gears are used.




Fig. 117.
Bevel Gear Differential.

Bevel Gear Differential. Fig. 118 shows a semi-sectional view of the bevel differential gear. The engine shaft carries a bevel gear wheel shown in section at a. This gear meshes with the large bevel gear b, on the differential gear case c. On the inside of this gear case are carried a number of small bevel gears, one of which is shown in section at d. These are free to turn on the study that hold them to the gear case. These gears in turn mesh with bevel gears e and f, on the ends of the half axles.

The principle governing the action of the bevel gear differential is similar to that of the

spur gear differential. When the two bevel gears e and f on the half axles meet with the same resistance, the small bevel gears d do not turn on their bearings; but when the movement of one of the gears e or f is resisted more than





Fig. 118

that of the other it lags behind, causing the small bevel gears d to turn on their axles sufficiently to equalize the resistance.

SPUR GEAR DIFFERENTIAL. In the spur differential, bevel gears are replaced by gears of the spur type, as shown in Fig. 119, a large spur gear being secured to each half axle, as shown at A and B, exactly as are the bevel gears. A double set of spur pinions, E and F, having their bearings in the frame, revolve



upon axes parallel with the axle. For each bevel pinion is substituted a pair of spur gears, E and F, which mesh with each other, and at the same time each one of them is in mesh with one of the large gears. The combination of the

motion of each pinion of the pair upon its gear, and the motion of the pair upon each other produces the same effect as the use of a bevel pinion. When the vehicle is rounding a curve, one rear wheel moves less rapidly, causing the pinions with which it is geared to revolve upon their bearings, and thus compensate for the increased resistance.




Fig. 120
Sectioned and Side View of Bevel Gear Differential

TESTING DIFFERENTIAL GEARS. The differential gear should be tested with a view to locating any wear or side play. This may be done by jacking up the rear axle and shaking one

wheel forward and backward while the other is held stationary, and noting how far the wheel must be turned before the movement is taken up by the flywheel of the engine. noticeable play will generally be found either in the center pinions of studs of the differential gear, in the large and small bevel gears, in the clutch sleeve, or in the universal joints. The differential gear, and live axle of modern cars seldom give trouble if kept properly lubricated, and the car's mileage should run up into many thousands before any considerable amount of play is evident. The joint pins of the propeller shaft may become loose through wear, in which case a knocking noise in the transmission gear will indicate the cause and location of the trouble. These pins may be readily replaced with new ones at small cost. If the play is found in the bevel gears, the small gear should be adjusted to mesh deeper with its larger mate. This may be done by means of the adjustable locking ring or by inserting a washer of the proper thickness. It may be found, however, that no adjustment is necessary, and a thorough cleaning with gasoline to remove all oil and grease will be all that is required. The case should then be refilled with the quantity of oil and grease recommended by the manufacturers.

Distributers. Instead of employing a separate spark coil for each cylinder of a multicylinder engine, the primary circuits of which

are made and interrupted in rotation, a device known as the distributer may be used, which permits of any number of cylinders being sparked from a single coil. In magnetos designed for jump spark ignition of multi-cylinder engines the distributer forms part of the magneto and is rotated by it. The distributer is nothing more than a timer of secondary current, and generally consists of a cylindrical shell of insulating material, upon the inside of the cylindrical surface of which equidistant metallic segments in number equal to the motor cylinders are inserted. A conducting arm rotating upon a shaft concentric with the insulated shell carries a brush, which successively makes contact with the segments. The arm is in permanent electrical connection with the free secondary terminal of the coil, and each one of the segments is wired to the spark plug of a cylinder.

In the case of four-cylinder motors the moving arm is geared at one-half the speed of the motor, thus making contact for each cylinder once in each two revolutions or complete cycle

Dynamometer. A dynamometer is a form of equalizing gear which is attached between a source of power and a piece of machinery when it is desired to ascertain the power necessary to operate the machinery with a given rate of speed.

Electricity, Forms of. Electricity or electrical energy may be generated in several ways—mechanically, chemically and statically or by friction. By whatever means it is produced, there are many properties which are common to all. There are also distinctive properties. The current supplied by the storage battery will flow continuously until the battery is practically exhausted, while the current from a dry battery can only be used intermittently; that is, it must have slight periods of rest, no matter how short they may be.

The dynamo or magneto current is primarily of an alternating nature, or one which reverses its direction of flow rapidly. In use, this alternating current is changed into a direct or continuous current flowing in one direction only, by means of a commutator. Any of the forms described are capable of igniting an explosive charge in a motor cylinder, but the static or frictional form of electricity is not used for this purpose on account of its erratic nature.

Electric Apparatus—Care of. The following instructions apply particularly to electric apparatus in connection with the operation of automobiles. Look over the electrical plant and replace worn wires with new. Clean out the

timer with gasoline and lubricate with light oil. The magneto need not be taken apart, as it will probably only need a little surface cleaning, a few drops of oil, and the amateur had better not meddle with its internal mechanism. The storage battery should be examined, and if the brown deposit collects in any quantity at the bottom, the electrolyte should be poured out into a glass bottle, and the battery washed out with clear water (rain water preferred). Clean the top of the battery and make it a point to keep it clean and free from acid. Clean the terminals of any corrosion, and see that the air vents are not clogged up. If the accumulator has been neglected, either in the electrolyte having been allowed to get below the proper level or in not giving it the regular monthly "charge," it may get a bad case of sulphating.

To get the battery into its normal condition, empty out the electrolyte and wash the case thoroughly with soft water. Pour in only about seven-eighths of the acid solution and fill up with distilled water to cover the top of the plates. The battery should then be charged with a low current until the plates are restored to their normal condition. If very badly sulphated, the white coating should be washed off with a rag, and in case this fails to remove it, scraping must be resorted to. If the electrolyte is not sufficient to cover the top of the plates, fill up with distilled water so that the liquid will just cover them. The specific grav-

ity of the electrolyte should not be less than 1.150, and, although varying somewhat, a hydrometer reading of 1.250 is recommended. This is approximately 1 part of sulphuric acid to $4\frac{1}{2}$ parts of water, which will be found sufficiently accurate if no hydrometer is at hand. If the electrolyte should test lower than the first figure, add pure sulphuric acid until the 1.250 mark is reached.

In case the plates are broken down or "buckled," or if the paste has dropped out of the pockets of the grids, the accumulator should be sent to the manufacturers for repair. In some accumulators the liquid is not used, but a jelly made of silicate of sodium and dilute sulphuric acid takes its place. If your battery is of this type, it is well to remember that the jelly must be kept moist on the top, and as the emulsion becomes dry a little water should be added to replace that which is lost through evaporation.

The contact points of the coil will probably require adjusting. This is very easily accomplished by trimming up the points with emery paper. Do not rub away the metal unnecessarily, only removing enough to true the points so that they make a good contact. In adjusting the vibrator, remember that a light tension is much better than a stiff tension. A light flexible vibration with a moderately high-pitched buzzing note will not only give a better spark, but will keep the points in better shape.

A heavy tension will make the coil less responsive and will pit the contact points and exhaust the battery more quickly. As a coil will render the most efficient service only when the vibrators are adjusted as nearly alike as possible, a special ammeter is often used to determine the current consumption of each unit. The ammeter should show a reading of 6-10 amperes.

Electric Horsepower. See Horsepower.

Electric Ignition. See Ignition.

Electric Lighting and Starting. See Starting and Lighting Systems.

Electric Lighting and Starting. See last part of this volume.

Electromotive Force, Definition of. The cause of a manifestation of energy is force; if it be electric energy in current form it is called electromotive force. An electromotive force or pressure of one volt will force one ampere through one ohm of resistance.

Engines, Internal Combustion.

Engine—Construction of. An automobile engine should answer the following requirements in order to meet the demands of the motor user: It must be of light weight in proportion to its horse power, so that as large a proportion of its power as possible may be available for propelling the useful load, and but little demanded to move its own weight; it must be compact, in order that it shall not occupy too large a proportion of the available room of the car; it must operate without undue noise and vibration; it must be fully enclosed as a protection against the weather, and still it must be so located as to be easily accessible for inspection, oiling and repairs; its operation must be automatic for considerable periods of time, as regards cooling and lubrication; it must be capable of running very slowly, or very fast at will, and of developing little, or much power; it must be supported upon the car in such a manner that its power may be most readily and efficiently transmitted to the driving wheels, and it must further be carried upon springs so that the jar and shock from the road shall not be transmitted to it.

EXPLOSIVE MOTORS. Explosive motors are of three forms, known as stationary, marine and automobile. Their general characteristics are

implied by their various designations. The stationary motor may be either vertical or horizontal. Marine motors, designed for application to boats, are almost invariably vertical. Automobile motors are of comparatively recent introduction and of great variety, the aim of the designers being to secure the maximum of power and minimum of weight. They also may be vertical or horizontal.

These three forms may be again divided into two-cycle and four-cycle types. In the former an explosion occurs at every revolution. In the latter there is an explosion at every alternate revolution.

Explosive motors are dependent for successful operation on two things: First, a charge of gas or vapor, mixed with sufficient air to produce an explosive mixture, and second, a method of firing the charge after it has been taken into the combustion chamber of the motor.

When coal gas is used the supply is taken from the main and mixed directly with the necessary proportion of air. When gasoline is used, air is mixed with it in the correct proportion by carbureting devices.

After the charge of gas and air has been taken into the cylinder it is compressed, as will be shown later, by the action of the motor itself and then fired, usually by an electric spark actuated by the motor, but sometimes by the use of a tube screwed into the cylinder and




Fig. 121

Internal Combustion Automobile Engine. 1, 3il Valve Lever. 2, Oil Valve Adjustment. 3, Oil Valve Lifter. 4, Oil Valve Slot. 5, Oil Tank Cover. 6, Water Jacket. 7, Oil Tank. 8, Oil Valve Spring. 9, Oil Valve Plunger. 10, Oil. 11, Oil Gauge Glass. 12, Oil Valve. 13, Oil Feed Window. 14, Water Inlet. 15, Cylinder Joint. 16, Cylinder Wall. 17, Crank Case Breather. 18, Oil Feed Pipe. 19, Connecting Rod Bearing. 20, Crank Pin. 21, Rod Bearing Bolt. 22, Oil Scoop. 23, Crank Shaft Timing Gear. 24, Crank Case. 25, Oil Lever Overflow. 26, Crankcase Oil. 27, Oil Drain Cock. 28, Cam Shaft Timing Gear. 29, Cam Shaft Plate. 30, Cam Shaft. 31, Cam Shaft Housing. 32, Exhaust Outlet. 33, Gasoline Pipe to Carburetor. 34, Carburetor Priming Lever. 35, Carburetor. 36, Throttle Lever Rod. 37, Gasoline Adjustment. 38, Valve Lifter Rod. 39, Valve Stem Adjustment. 40, Fibre in Valve Plunger. 41, Cylinder Space. 42, Valve Spring. 43, Exhaust Pipe. 44, Connecting Rod. 45, Piston. 46, Wrist Pin Set Screw. 47, Oil Groove in Piston. 48, Wrist Pin. 49, Exhaust Manifold. 50, Manifold Clamp Nut. 51, Intake Manifold. 52, Intake Passage in Cylinder. 53, Valve Stem. 54, Valve Head. 55, Valve Opening, Seat and Face. 56, Piston Rings. 57, Combustion Space. 58, Valve Pocket. 59, Priming Cup. 60, Valve Cap. 61, Water Outlet Header. 63, Valve Cap.




Fig. 122 Front and Side View of Section Through Four Cylinder Automobile Engine

heated from the outside, the heat, of course, being communicated to the gas. The resulting explosion operates the motor.

The principal parts of a four-cycle explosive motor are the cylinder, the piston, the piston rings which fit into grooves in the piston: two sets of valves, one to admit the charge and the other to permit it to escape after the explosion; a crank shaft and connecting rod which connect it with the piston head, and a flywheel, whose presence insures steady running of the motor, and whose further functions will be better understood as the description proceeds. In the two-cycle form of motor there is really but one valve, the exhaust and admission-ports being covered and uncovered by the piston itself.

All of the parts referred to are of the motor proper. Other parts, which are separate from the motor but on which its operation depends, are the carbureter, which supplies the charge of gasoline vapor and air for a gasoline motor, or a mixing chamber for mixing air and gas in the case of a gas motor, and the batteries and other parts of the electrical ignition device.

A part which has no connection with the actual running of the motor but with which practically all are fitted is the muffler, whose purpose is to deaden the sound of the explosion.

The cylinders of all except very small motors are as a rule partly encased in a chamber

through which water is circulated, the object of this being to keep the cylinder cool.




Fig. 123
Section Through Six Cylinder Long Stroke Engine

OFFSET CRANKSHAFTS. The practice of offsetting the crankshaft in automobile motors is rapidly gaining converts, and there are numerous examples of offsetting to be seen at the present time. In this scheme, it will be remembered, the crankshaft is not set in the plane of the middle of the cylinders. In other words, the crankshaft is set slightly to one side. The exact amount of this offset seems to be variable




Fig. 124
Section Through Engine with Offset Crank

with different designers, but the object is always the same. When the piston is in the position of maximum compression involving the ignition and flame propagation, it is the idea to have the connecting rod in the vertical position. The force of the explosion will then come on the connecting rod endwise and the piston will not be pressed unduly against the cylinder walls.

OFFSET CRANK SHAFT ENGINE—TIMING THE VALVES. To time the valves of an engine having an offset crankshaft, the inclination of the axis of the connecting rod must be taken into account. As Figure 124 shows, the connecting rod is vertical, and if the shaft center were not




Fig. 125
Diagrams Showing the Four Positions of the Offset
Crankshaft

to one side, the flywheel would be marked at the exact center of the upper face, namely, at C. In the case where the center is set over, the rod, when in a vertical position as at G is not at the end of the stroke. If the flywheel were marked at C it would not indicate correctly the lower dead center. This does not appear until the three centers, piston pin, crank pin, and crankshaft are in line, as shown by the line D E F. The flywheel should be marked at this

point, and the mark may be on a vertical line through the crankshaft center or on a diagonal as the line just indicated. In the latter instance, the mark for the lower center would be at H.

Similarly, the upper dead center, if marked, would be at a vertical point above the shaft center as C, but would assume a different position, located on a diagonal, as at A, on the center line A B E.

Of course, in actual timing, the upper and lower centers are not used, as good practice decrees an overlap for the valve action, but they have been used as an illustration in this case because their use simplifies the matter.

In Fig. 125, the actual marking of a fly-wheel is shown for a complete cycle. In this the angles selected follow the best modern practice, being as follows: Inlet opens at 8 degrees past the upper center, and closes at 26 past the lower center, giving an inlet opening, total, of 198 degrees. Exhaust opens at 46 degrees before the lower center and closes at 5 past the upper. This gives the whole angle for the exhaust, 231 degrees on the crankshaft.

As shown, the markings are put on the flywheel directly above the center of the crankshaft, but the offset is taken into account.

PISTONS. The piston used in a gasoline motor cylinder is of the single-acting or trunk type. It is made of an iron casting which is a good working fit in the cylinder. Around the upper

end of the piston three or four grooves are and in these grooves the piston-rings fit. 'rings are made of cast iron, and the bore of ring being eccentric to its outer diameter, this a certain amount of spring in them, and pressure is caused against the cylinder we preventing any of the expanding gases pass the piston.

PISTON MATERIALS. Until recently it has b the universal practice to make internal coml tion engine pistons of cast iron for the rea that this material does not warp under heasuch an extent as does steel. The princi objection to cast iron has been its comparative high weight, this weight being necessary beca of the lack of great strength in the metal. a well known fact that cast iron is very brit With the advent of the modern high speed gine, experiments were conducted with steel tons because of the fact that they allowed lighter construction with equal strength. S pistons have done satisfactory work, but are v high in production cost, and this has prever their general introduction.

The necessity for reducing the weight of reciprocating parts has more recently led to introduction and use of pistons made from all of aluminum, which, of course, gives the desireduction in weight. The fit of the piston in cylinder cannot be so tight when cold as ver cast iron or steel, but as soon as the engine run a few moments, the expansion due to the state of the piston in the cold as very cast iron or steel, but as soon as the engine run a few moments, the expansion due to the state of the piston in the state of the piston in the cold as very cast iron or steel, but as soon as the engine run a few moments, the expansion due to the state of the piston in the pi


allows the piston to fit close enough for all practical purposes. These pistons are now fitted in many makes and models of stock cars and may be fitted to cars already in use.

PISTON DISPLACEMENT. The piston displacement of a motor is the volume swept out by the piston, and is equal to the area of the cylinder multiplied by the stroke of the piston. The expression, cylinder volume, is sometimes confounded with the term piston displacement. This is erroneous, as the cylinder volume is equal to the piston displacement, plus the combustion space in the cylinder head.

PISTONS, LENGTH OF. For vertical cylinder motors the length of the piston should not on any account be less than its diameter, while a length equal to one and one-quarter or even one and one-third diameters is better. For motors with horizontal cylinders the length of the piston, in any case, should not be less than one and one-third diameters, and if possible one and one-half diameters or over.

PISTON POSITION. There is nothing more confusing to many motorists—not only to the beginner, but to many who are proficient in the general care and operation of their motor cars —than the relative various positions, in a fourcycle engine, of the four pistons on any of their four cycles of compression, work, explosion, and exhaust, this being the order of the cycles.

In the following illustrations the pistons are shown as they are usually placed in relation to






Fig. 127




Fig. 138




Fig. 129

one another. That is, pistons 1 and 4 are at the top of their strokes when pistons 2 and 3 are at the bottom, and, obviously, vice versa. The figures over the pistons in each diagram represent their order of number, counting from either end of the engine.

In Fig. 126, cylinder I is ready to descend on its intake stroke-having finished its exhaust stroke—and cylinder 4 is ready to descend on its working stroke—having finished its compression stroke. Cylinders 2 and 3 are ready to move on their up strokes, No. 2 on its compression, having finished its intake, and No. 3 on its exhaust, having finished its working stroke. The results are that the pistons are brought into the positions shown in Fig. 127. This means that cylinder No. 1, having completed its intake downward stroke, is ready for its compression up stroke; No. 2 has moved up on compression and is ready to go down on work; No. 3 has finished exhausting and is ready for intake and No. 4 has finished the work stroke and is ready to move up on exhaust. Piston No. 2, having completed its work stroke, the pistons are brought back to the positions shown in Fig. 126, but with an altered condition of the cycle represented by each, as shown in Fig. 128. The pistons are now ready to move to the positions shown in diagram 2, with an altered cycle condition. Cylinder No. 1 moves down on work; No. 2 up on exhaust;

No. 3 up on compression and No. 4 down on intake, see Fig. 129.

When the cycle of each has been completed, from the above starting points of No. 1, exhaust; No. 2, intake; No. 3, work, and No. 4, compression, the pistons are then back not only in the position of Fig. 126, but with the same condition of cycles.

This explanation has been in the order of the cylinder numbers, but the effect of each cycle of each cylinder will be easier traced if it be remembered that the order in which the cylinders work is: Cylinder 1, then cylinder 3, then cylinder 4, and then cylinder 2, and then repeat indefinitely. From this and the above illustrations it will be easily understood that as piston No. 1 goes down on its work stroke, No. 3 comes up on compression stroke, and is then ready for the work, which is a down stroke bringing No. 4 up on compression. No. 4 then goes down on work and brings No. 2 up on compression, then it goes down on work and brings No. 1 up on compression for the repeating of cycles. This shows that each synchronized pair, 1-4 and 2-3, always have one cycle between them as they move together, either up or down.

PISTON-RINGS. To ensure proper compression, it is absolutely essential that the piston-rings should be kept lubricated; consequently when the motor has been idle for some time, the compression at the start is often poor. Any failure in the lubrication while running will, of

course, have the same effect, such, for example, as in the case of overheating, or when the supintermittent. Sometimes the pistonis rings get stuck in their grooves with burnt oil, through overheating, and the compression escapes past them. Thorough cleaning with kerosene, and fresh lubricating oil will settle the matter. In motors where the rings are not pinned in position, the slots may work round so as to coincide. In this case they will have to be moved around. Sometimes burnt oil may, apparently, have the opposite effect on pistonrings, for by causing the piston to grip in the cylinder, it will produce considerable resistance, and the operator might erroneously think in consequence that his compression is good. In every case, after a long run, a little kerosene should be injected into the cylinders to clean the rings.

PISTON-RINGS—METHOD OF TURNING. A pattern should be made from which to cast a blank cylinder or sleeve with two projecting slotted lugs on one end to bolt same to face plate of lathe. This blank should first be turned off outside to the required diameter, making it, of course, sufficiently larger to allow for the cut in the rings, after cutting from the blank. The blank should then be set over eccentric sufficiently to allow the thick side of the rings to be twice the thickness of the thin side after turning. The inside of the blank can then be bored out, and the rings cut off to the exact thick-

ness required with a good sharp cutting off tool. A mandrel or arbor should be made with two cast iron washers or collars to fit it, one fastened to the mandrel and the other loose, with lock nut on mandrel with which to tighten up the loose collar. After the rings have been sawed open and a piece cut out the required length, they can be placed on a collar or ring




Fig. 130.

about 1-32 to 3-64 of an inch larger than the cylinder bore, and slipped on to the mandrel one at a time, of course, with the loose collar and nut off the same. The loose collar and nut can then be put on the mandrel, the ring clamped tightly between the two collars, the mandrel put in the lathe and the ring turned off, without leaving any fins or having to cut the ring off afterward as is done in many cases. This is the only way in which a perfectly true ring can be

FOUR-CYCLE MOTOR. Fig. 130 furnishes two sectional views of a four-cycle type of motor with some of the parts removed, as in Fig. 121. It shows a cylinder C, admission-valve A, a piston P, and exhaust-valve E.

The left-hand view shows the piston P about to suck in a charge of vapor, by the same method as previously described, through the admission-valve A into the cylinder C. The suction continues until the piston P reaches the position shown in the right-hand view. Then the piston returns until it again arrives at the position shown in the left-hand view, compressing the charge of mixture during this operation. Just before the piston arrives at the end of its travel in this direction, the charge of vapor, now under compression, is ignited by the method previously explained and its expansion forces the piston back to the position shown in the right-hand view. When the piston has, for the second time, reached the position shown in the right-hand drawing, a mechanical device opens the exhaust-valve. The exhaust-valve remains open until the piston has again arrived at the position in the left-hand view. Then it closes, the piston again commences to draw in a charge of vapor and the cycle of operation of the motor is repeated.

FOUR-CYCLE MOTOR, OPERATION OF. A four-cycle motor has only one working stroke or impulse for each two revolutions. During these

two revolutions which complete the cycle of the motor, six operations are performed:

- 1. Admission of an explosive charge of gas, or gasoline vapor and air to the motor-cylinder.
 - 2. Compression of the explosive charge.
- 3. Ignition of the compressed charge by a hot tube, or an electric spark.




Fig. 131
Four-Cylinder Engine

- 4. Explosion or extremely sudden rise in the pressure of the compressed charge, from the increase in temperature after ignition.
- 5. Expansion of the burning charge during the working stroke of the motor-piston.
- 6. Exhaust or expulsion of the burned gases from the motor-cylinder.

TWO-CYCLE MOTOR. The foregoing outline of the functions of the parts of the motor prepares us for a description of the two-cycle form of motor. This particular form of motor draws in a charge of gas or vapor, compresses it, fires it and discharges the product of combustion or burned gases while the crank makes but a sin-




Fig. 132

gle revolution, and while the piston makes one complete travel backward and forward.

Fig. 132 shows two sectional views—that is to say, views of the motor cut in two, longitudinally—of the principal parts of a two-cycle motor. Other parts, such as the crankshaft, connecting rod and flywheel, are omitted to avoid confusion. C is the crankcase and A the admission valve, through which the vapor

passes to the 'crank case. B is the inlet passage, through which it passes from the crank chamber to the cylinder. P is the piston. The igniter, which makes the electric spark when the lower point comes in contact with the upper, is shown immediately below the cylinder cover. This causes the explosion of the vapor. E is the exhaust port, through which the burned charge escapes after the piston has been driven outward by the explosion and has reached the end of its stroke.

Let it be supposed that the motor is still and the crank chamber C is full of gas or vapor. To start the motor the piston is started by means of a crank on the flywheel shaft, and as it passes to the position shown in the left-hand drawing it forces the charge of vapor through the port B into the cylinder. The piston then returns to the position shown in the right-hand view, moving away from the crank chamber C, and in doing so closes the port B and the exhaust opening E and compresses the charge of vapor. The points of the igniter come together, a spark occurs and the resulting explosion forces the piston outward again. When the piston reaches a point near the end of the stroke, as shown in the left-hand drawing, it uncovers the port E and the burned charge passes out, the new charge coming through the port B immediately afterwards.

The admission of the new charge to the crank chamber is controlled by the action of the piston. As the latter travels outward it has a tendency to create a vacuum in the crank chamber. This draws the valve inward and admits the charge of vapor.


It will be observed that there is a projection on the head of the piston. This is generally known as a baffle-plate. Its object is to prevent the incoming charge from passing directly across the cylinder and out at the exhaust port E, which, it will be observed, is directly opposite it. The baffle-plate directs the incoming charge toward the combustion chamber end of the cylinder, providing as nearly as may be, a pure charge of vapor and assisting in the expulsion of the remainder of the burned gases remaining in the cylinder as a result of the last explosion.

Motors—Two and Three Port. In the twoport motor, as illustrated in Fig. 133, the functions are as follows:

The first stroke of the piston produces a vacuum in the crankcase and the mixture rushes in (as a consequence) through the check valve in the motor case. The second stroke compresses the mixture, and when the communicating port is uncovered the mixture surges into the cylinder. The next (third) stroke compresses the mixture entrapped in the cylinder, since the ports are then covered by the piston, and at the proper instant the mixture is ignited.

From this point on it is a normal repetition of functions, and once the motor gets under

way it two cycles. The three-port motor, Fig. 134, differs in that the mixture is taken in through a third port uncovered by the piston, instead of through a check valve in the case, and the details in practice change accordingly.



Two port Motor

Fig. 134
Three port Motor

Engine, Gasoline, Fuel Consumption of. The fuel consumption of a motor is always a serious question, and one of importance to the purchaser as well as to the manufacturer.

Ordinarily about one and two-tenths pints of gasoline per horsepower hour under full load will cover the fuel consumption. That is, when

the mixture is of the proper explosive quality and the water comes from the jacket at a temperature of about 160 degrees Fahrenheit.

The temperature of the water in the jacket around the cylinder has a great deal to do with the fuel consumption.

If the water is forced around the cylinder so as to keep it cold, the heat from the combustion is cooled down so quickly by radiation that the expansive force of the burning gases is materially reduced, and consequently less power is given up by the motor.

The object of the water is not to keep the cylinder cold, but simply cool enough to prevent the lubricating oil from burning. The hotter the cylinder with effective lubrication the more power the motor will develop.

Engine, Two-Cycle, Fuel Consumption of. The two-cycle engine uses more fuel than the four-cycle. The greatest consumption is not so much due to the fact that the two-cycle motor makes an explosion for every revolution, in contrast with the missed stroke of the four-cycle, as it is to the fact that there is a considerable retention in the cylinder of the exhaust charge, and that, despite the deflector, more or less of the fresh charge escapes at the exhaust. The two-cycle is also harder on a battery owing to the greater frequency of the demands upon it, but with improved methods of ignition, even dry batteries have been found to give very satisfactory service.

Engine, Sliding Sleeve Type. The Knight sleeve valve engine, Fig. 135, is a four cycle gasoline engine in which the usual poppett valves have been replaced by two concentric sleeves sliding up and down between the cylinder walls and the piston. Certain slots in these sleeves register with one another at proper intervals, producing openings between the combustion chamber and the inlet and exhaust





Fig. 135
Knight Sliding Sleeve Engine
manifolds for the passage of fresh gas into the
cylinder and burned gas from it

It will be noted that the two sleeves are independently operated by small connecting rods working from a shaft made with eccentrics. This eccentric shaft is driven at one-half crankshaft speed, usually by silent chains. This shaft takes the place of, and performs the same




Inlet Opening on Knight Engine

Inlet Open on Knight Engine

functions as the camshaft in the poppett valve engine. The eccentric pins that operate the inner sleeves are given a certain advance or lead over those operating the outer sleeves. This lead, about 90 degrees, together with the

half-speed rotation of the shaft, gives the following valve action:

In Figs. 136 to 142 the relative positions of the pistons, sleeves and ports are shown in



various positions during the two revolutions of the crankshaft that make up one working cycle of inlet, compression, power and exhaust strokes. Fig. 136 shows the inlet just opening. The port, or slot in the inner sleeve is coming up, the port in the outer sleeve is going down and the passage for the incoming gas is formed by the rapidly increasing opening between the upper edge of the slot in the inner sleeve and the lower edge of the slot in the outer sleeve.




Fig. 140 Fig. 141 Fig. 142 Exhaust Opening Exhaust Open Exhaust Closing

Fig. 137 shows the inlet fully open. The inner and outer slots are exactly opposite each other and the inlet opening in the cylinder wall. Fig. 138 shows the closing of the inlet. The cylinder has been filled with fresh

mixture and is ready for the compression stroke. Fig. 139 shows the position of the sleeves at the top of the compression stroke; the combustion space having been completely sealed by the expansion rings in the cylinder head above and in the piston below. The firing of the mixture takes place at this point.

Fig. 140 shows the exhaust port just starting to open. The slot in the outer sleeve is coming up and the slot in the inner sleeve is going down. Fig. 141 shows the exhaust ports fully open. The inner and outer slots are opposite each other and at the same time opposite the cylinder opening that leads to the exhaust piping. Fig. 142 shows the closing of the exhaust opening and is practically identical with the position shown in Fig. 136. The four strokes of the cycle (inlet, compression, power and exhaust) have now been completed, the crankshaft has made two complete revolutions and each sleeve has moved up and down once.

The timing of inlet and exhaust opening and closing is not different from that ordinarily used in poppett-valve engines, but the opening secured with this construction is greater than that ordinarily found in the poppett type. Some advantage is also gained because of the more direct path of the incoming and outgoing gases. The timing of the valve openings is not affected by spring pressure or engine speed.

Engines, Eight and Twelve Cylinder Types. The development of the automobile engine has been along the lines of increase in number of cylinders and decrease in the size of the individual cylinders, without any considerable increase in the total horsepower delivered by the engine. This development has resulted in the power being delivered more evenly, inasmuch as an impulse is delivered to the crankshaft each time a cylinder fires. With the single cylinder engine, one impulse was given for each two revolutions and with the increase to four, six and eight cylinders, the crankshaft has received two, three and four impulses for each single revolution. The twelve cylinder secures a power stroke for each sixty degrees revolution of the crankshaft and consequently gives six impulses for each revolution.

The most radical change between former types of engine and the eight and twelve cylinder types is that of placing the cylinders in two equal divisions, and, in place of standing vertically, they are placed at an angle of ninety degrees in the eight and sixty degrees in the twelve. This design does not materially increase the length of the engine over one having four or six cylinders of equal size and, of course, makes the height somewhat less, due to the inclination. While these engines naturally require additional cylinders, valves, connecting rods and pistons, they make use of only one




Fig. 143 Eight Cylinder Chassis

crankshaft and generally of but one camshaft. No other increase in number of parts or accessories is necessary, one carburetor, one ignition device and one of each of the other power-plant units doing the work for both sets of cylinders.

The mounting and construction of the generally accepted type of eight cylinder engine is shown in Figs. 143 to 145. As will be noted from the top view shown in Fig. 143, a space is left between the cylinder blocks which provides suitable location for such fittings as the carburetor, the ignition unit and usually the lighting dynamo. The valves are located on the inside of their respective castings and the resulting position of the caps allows easy removal, inspection and grinding.

The center lines of the two cylinder blocks intersect at the center of the crankshaft, and, as will be noted from the side elevation in Fig. 144, the crankshaft itself does not differ from the usual four-throw type used with four cylinder engines. Depending on the type of connecting rod construction used, the cylinders in the blocks are set so that corresponding ones on opposite sides are exactly opposite or slightly offset from each other in a lengthwise direction. In any case the connecting rods from the two front cylinders fasten to one crankpin, while those from the second cylinders are on the next crankpin, and so on for those remaining.




Fig. 144 te View of Eight Cylinder "V" Type Engine

Three types of construction are in use for the lower end of the connecting rods; the most commonly used method being shown in Figs. 144 and 145, in which one rod is straight and of




Fig. 145 End View of Eight Cylinder Engine

the usual pattern while the corresponding one is forked and has the two sides of the fork so placed that they are on either side of the straight member. With this construction, the crankpin is surrounded with a sleeve or liner of bearing metal and the forked rod is clamped




Fig. 146
Packard Twelve Cylinder Engine

around this liner so that the liner is held tightly by the rod, and the shaft turns inside the liner. The end of the straight connecting rod has its bearing on the outside of the liner just mentioned and therefore has only a reciprocating motion on the liner in place of turning all the way around. The bearing of the straight rod on the liner is adjustable, but the liner is not adjustable on the crankshaft.

Another form of connecting-rod construction forms one of the rods in the usual way with an adjustable bearing on the crankpin. On the big end of the rod just mentioned is a boss that carries a pin similar to a wristpin, and on this pin is mounted the bearing of the second connecting rod. The end of the second rod does not surround the crankshaft but is mounted on the end of the one with the bearing.

The third form of rod construction is little used on eight cylinder types, but is quite common on twelves. This method uses a complete rod end and bearing on each rod, the ends and liners being placed side by side so that each connecting rod has a bearing on one-half of the length of the crankpin. The rods are not in the same plane and therefore the cylinders are offset, the set on one side of the engine being a little forward or back of the opposite set. This method allows individual adjustment of each bearing.

In engines with either eight or twelve cylinders, the camshaft is mounted directly above

the crankshaft and therefore between the cylinder blocks. Two designs are in common use, one making use of separate cams for each of the sixteen or twenty-four valves, and the other using but one cam for the inlet valves of opposite cylinders and another cam for the corresponding exhaust valves. With but one cam for two valves, the valve plunger rollers do not rest directly on the cam, but the plungers are operated from rocker arms, hinged at one end to the crankcase and having a roller at the end that rests on the cam. When individual cams are used for each valve, the cams are of necessity placed side by side, but the slight distance between each pair makes it necessary to offset the valves or offset the cylinder blocks in a lengthwise direction.

As mentioned, it is customary to use one carburetor with a manifold that divides near the instrument with one branch for each cylinder block. Some difficulty was met with in providing suitable ignition for engines with eight or twelve cylinders, but this has been overcome by improved forms of ignition breakers, by the use of two distributors and two breakers in some cases and by the adoption of new principles of magneto construction in others. When it is realized that a twelve cylinder engine running at 1,800 revolutions a minute (a moderate speed) requires 10,800 accurately timed and powerful sparks every minute, the reason for the difficulty will be seen.

In considering the firing order of these engines, it should be borne in mind that an eight is similar to two four cylinder engines, side by side, while a twelve is similar to two sixes. All four cylinder engines fire in one of two orders, either 1-3-4-2 or else 1-2-4-3, considering the front cylinder as number one. Each set of four cylinders in an eight, that is, the left hand set and the right hand set fires in one of these orders, the only difference with the eight being that one of the cylinders of the left hand set fires just half way between two on the right, while each cylinder on the right fires midway between two on the left. The cylinders on the left, from front to back are usually designated as No. 1 Left, No. 2 Left, and so on; while those in the right are No. 1 Right, No. 2 Right, etc. The firing order of a number of eight cylinder engines is therefore as follows: 1L, 4R, 3L, 2R, 4L, 1R, 2L, 3R; in which it will be seen that, looking at either the "Ls" or "Rs," they fire 1-3-4-2.

The principles explained above apply equally to the twelve, in which the engine may be considered as two sixes, each set of cylinders firing in one of the orders possible for a six. It is possible to number all the cylinders in either an eight or twelve cylinder engine consecutively from 1 up and in this case the front right hand cylinder is usually called number one. The numbering may then continue from front to back on the right hand side, in which case

these cylinders will be numbered from 1 to 6, or may pass to the left side, calling the left




Fig. 147 Section Through Twelve Cylinder Engine

front cylinder No. 2, the second one on the right No. 3, etc. This last method would bring

all the odd numbers on the left and all the even numbers on the right.

Designating the cylinders of a twelve by the numbers 1 to 6 and showing their position by letters, a common firing order would be as follows: 1R, 6L, 5R, 2L, 3R, 4L, 6R, 1L, 2R, 5L, 4R, 3L. This fires each set in the common order: 1-5-3-6-2-4.

A twelve cylinder engine is shown in Figs. 146 and 147, and most of the data given in the foregoing pages applies equally to the twelve and the eight. The principal difference between the two types is that the angle included between the cylinder blocks of the twelve is less than that of the eight, thus leaving less space between the blocks in the location often called the "valve alley." Because of the smaller space between the cylinders, a larger one is left outside of the cylinders before the sides of the hood are reached. This fact has led to the practice on twelves of locating the accessories, with the exception of the carburetor, outside of the cylinder blocks and in the same place that they usually occupy on four and six cylinder types.

Exhaust—Cause of Smoky. Smoke coming from the exhaust of a gasoline motor is due to one of two conditions: Over-lubrication—too much lubricating oil being fed to the cylinder of the motor— or too rich a mixture, that is, too much gasoline and an insufficient supply of air.

The first condition may be readily detected by the smell of burned oil and a yellowish smoke. The second, by a dense black smoke accompanied by a pungent odor.

Expansion—Best Conditions for. The efficiency of the expansion in an engine cylinder lepends upon the initial volume of the charge, the condition of the mixture, the compression pressure, the point of ignition, the speed of expansion and the losses due to radiation.

The losses due to improper expansion may therefore be decreased by making large valves and valve passages, but these often mean greater heat losses. The losses due to radiation may be reduced by increasing the temperature of the jacket water, and decreasing the area of the cylinder. But if the cylinder wall temperature is increased, there are considerable difficulties with lubrication, and the increased gain in thermal efficiency will be more than offset by the increased friction.

In order to obtain the highest efficiency the difference in the temperature of the water entering and leaving the cylinder jacket should be a maximum. In practical tests it has been found that the best results are obtained when the jacket water is near the boiling point.

Flywheels. One of the first and most important considerations in connection with the construction of a gasoline automobile motor is the proper diameter and weight of the flywheel. If the diameter and weight of the flywheel be known, the speed of the motor or its degree of compression will become a variable quantity. On the other hand, if the speed of the motor and the degree of compression be fixed, the diameter or weight of the flywheel rim must be varied to suit the other conditions. If the speed of the motor and its degree of compression be known, the diameter of the flywheel or the weight of the flywheel rim may be readily ascertained from the following formulas.

WEIGHT OF RIMS OF FLYWHEELS. The weight of the rim of the flywheel is the only portion which enters into the following calculations, the weight of the web, or spokes and hub being neglected.

Let M.P be the mean pressure of the compression, and A the area of the cylinder in square inches. If S be the stroke of the piston in inches, and N the number of revolutions per minute of the motor, let D be the outside diameter of the flywheel in inches and W its required weight in pounds, then

$$W = \frac{M.P \times A \times S \times N}{2560 \times D}$$

DIAMETER OF RIMS OF FLYWHEELS. A motor

that is intended to operate at a slow rate of speed, and consequently with a high degree of compression, will require a flywheel of much greater diameter and weight than a high speed motor of the same bore and stroke. It may be well to remember that within certain limitations the diameter and weight of a flywheel should be as small as is possible, as an increase in either means a reduction in motor speed, and a consequent loss of power.

To ascertain the diameter of a flywheel when all other conditions are known, if D be the required diameter of the flywheel in inches, then

$$D = \frac{M.P \times A \times S \times N}{2560 \times W}$$

WEIGHT OF RIMS OF FLYWHEELS WITH A GIVEN FLUCTUATION IN SPEED. If it be desired to run a motor at a practically uniform speed and with only a slight fluctuation or variation in the velocity of the flywheel, if W be the required weight of the flywheel and x be the allowable fluctuation of the flywheel in revolutions per minute above and below its normal speed, then

$$\mathbf{W} = \frac{\mathbf{M.P \times A \times S \times N}}{365 \times \mathbf{x}}$$

Horsepower Stored in Rims of Flywheels. It is sometimes desirable to know the amount of energy or horsepower which may be stored in the rim of a flywheel of known diameter and weight, with a given speed. If H.P be the horsepower stored in the rim of the flywheel then

$$H.P = \frac{D^2 \times W \times N}{792,000}$$

SAFE SPEED FOR RIMS OF FLYWHEELS. The salvelocity for the rim of a cast iron wheel taken at 80 feet per second. Let N be salspeed of the flywheel in revolutions per minute then

$$N = \frac{18,335}{D}$$

The mean pressures corresponding to varying degrees of compression may be found be reference to Table 2.

M.P = Mean pressure.

 $\Lambda =$ Area of cylinder in square inches.

S = Stroke of piston in inches.

N = Number of revolutions per minute.

D = Diameter of flywheel in inches.

W = Weight of flywheel in pounds.

BALANCING WITH THE RECIPROCATING PARTS 0
THE MOTOR. The flywheel should be balance
as accurately as is possible before mountin
on the crank shaft. In the first place set th
crank shaft on two perfectly straight paralle
bars, one bar under each end. Then attach th

connecting rod and piston to the crank and turn the shaft until the crank jaws are parallel with the floor, or in other words, at right angles to a perpendicular line drawn through the center of the shaft. Place a scale under the crank pin, or use a hanging scale attached to some rigid support above the pin and connect it to the crank pin by a wire or cord sufficiently strong to carry the weight. Then find the weight of the parts according to the scale and attach the same amount to the flywheel at the same distance from the shaft on the side opposite the crank, and the result will be a fairly balanced motor. It is impossible to obtain a perfect balance, but the above method will assist greatly in reducing the vibration of the motor.

While it is true that the weight of the flywheel may be reduced as the number of cylinders is increased, there is a practical limit below which it is inadvisable to reduce the weight at the rim. Even should the number of cylinders be sufficient to cause a balance between the working strokes, it would still be desirable to add a rotating weight to compensate in some measure for the several reciprocating masses, such as pistons, connecting rods, crankshaft webs, etc. Engines have been built for racing purposes without flywheels, but they were unsuccessful.

Friction. Friction, being the resistance to motion of two bodies in contact, depends upon

the following laws: It will vary in proportion to the pressure on the surfaces; friction of rest is greater than friction of motion; the total friction is independent of the area of the contact surfaces when the pressure and speed remain constant; and friction is greater between soft bodies than hard ones.

The behavior of lubricated surfaces is quite different from dry ones, the laws of fluid friction being independent of the pressure between the surfaces in contact, but it is proportional to the density of the fluid and in some manner to the viscosity. When a bearing is thoroughly lubricated it does not seem to make much difference what the metals are, because there is a layer of oil running around with the journal and sliding over another layer adhering to the bearing. If, however, the feed fails, or the pressure gets too heavy for the nature of the lubricant, and so squeezes it out, or the temperature has risen so high as to affect the body of the oil, then the surfaces come into contact and the peculiar nature of the contact asserts itself, some combinations abrading and seizing more readily than others. When the lubrication is thorough, the condition of the fluid friction being realized, the intensity of the load makes less difference than would be expected.

Fuels for Automobiles. Apart from the possibility of an increase in the fuel resources of the world due to some revolutionary discovery, the ingredients in any mixed fuel for automo-

bile use must be confined to the following list, in which, for completeness, gasoline is included:

Gasoline. Average composition, C=84, H=16.

Source, petroleum.

Boiling point, 50° to 150° Cent.

Specific gravity, .680 to .720.

Calorific value, 19,000 B. T. U.

Latent heat, small.

Benzine. Average composition, C=92, H=8.

Source, coal tar.

Boiling point, 80° Cent.

Freezing point, 5° Cent.

Specific gravity, .899.

Calorific value, 19,000 B. T. U.

Latent heat, small.

Alcohol. Average composition, C=32, H=8, O=35.

Source, vegetable matter, principally corn, beets, potatoes, sugar cane.

Boiling point, 70° Cent.

Specific gravity, .806.

Calorific value, 12,600 B. T. U.

Latent heat, considerable.

Tar Benzol. Average composition, C=92, H=8.

Source, a by-product in the manufacture of coke.

Boiling point, 80° to 120° Cent.

Specific gravity, .895.

Calorific value, 19,000 B. T. U.

Latent heat, small.

Kerosene. Average composition, C=85, H=15.

Source, petroleum.

Boiling point, 150° to 300° Cent.

Specific gravity, .800 to .825.

Calorific value, 19,000 B. T. U.

Latent heat, considerable.

Motor Spirit, Naphtha, Benzoline, Benzine.

Average compositnon, C=85, H=15.

Source, petroleum and shale.

Boiling point, 60° to 160° Cent.

Specific gravity, .750.

Calorific value, 19,000 B. T. U.

Latent heat, appreciable.

Methyl Alcohol, Wood Spirit, Naphtha. Average composition, C=38, H=12, O=50.

Source, the distillation of wood.

Boiling point, 66° Cent.

Specific gravity, .812.

Calorific value, 9,600 B. T. U.

Latent heat, appreciable.

Acetylene Ethene. Average composition, C=92, H=8.

Calorific value, 25,000 B. T. U.

Fuel Feed, Vacuum.

The Stewart vacuum gasoline tank, Figs. 148 to 152, consists of two chambers. The upper one is the float or filling chamber, and the lower one is the reservoir or empty chamber. upper chamber is connected with the intake manifold of the motor, and also with the main gasoline supply tank. The lower or emptying chamber is connected with the carburetor. Between these two chambers is a valve. suction of the piston on the intake stroke creates a vacuum in the upper chamber. This closes the valve between the two chambers, and in turn draws gasoline from the main supply tank. The gasoline, being sucked or pumped up into this upper chamber, operates a float valve. When this valve has risen to a certain mark it automatically shuts off the suction valve and opens an air valve. This open air valve creates an atmospheric condition in the upper chamber and opens the valve into the lower chamber, and the gasoline immediately commences to flow to the lower or emptying chamber. The lower chamber is always open to outside atmospheric so conditions, so that the filling of the upper chamber in no way interferes with an even, uninterrupted flow of gasoline from this lower chamber to the carburetor.

A is the suction valve for opening and closing the connection to the manifold and through which a vacuum is extended from the engine manifold to the gasoline tank.





Fig. 148 Stewart Vacuum Fuel Feed Tank

B is the atmospheric valve, and permits or prevents an atmospheric condition in the upper chamber. See Fig. 149. When the suc-



Float and Levers of Vacuum Tank tion valve A is open and the suction is drawing gasoline from the main reservoir, this atmospheric valve B is closed. When the suction

330 The Automobile Handbook




Fig. 150

Arrangement of Parts of Vacuum Fuel Fe

valve A is closed, then the atmospheric valve B must be open, as an atmospheric condition is necessary in the upper tank in order to allow the fuel to flow through the flapper valve H into the lower chamber.

C is a pipe connecting tank to manifold of engine.

D is a pipe connecting vacuum tank to the main gasoline supply tank.

E is a lever to which the two coil springs S are attached. This lever is operated by the movement of the float G.

F is a short lever, which is operated by the lever E and which in turn operates the valves A and B.

G is the float.

H is flapper valve in the outlet T. This flapper valve is held closed by the action of the suction whenever the valve A is open, but it opens when the float valve has closed the vacuum valve A and opened the atmospheric valve B.


J is a pet cock for drawing water or sediment out of the reservoir. This may also be used for drawing gasoline for priming or cleaning purposes.

K is a line to the carburetor extended on inside of the tank to form a pocket for trapping water and sediment which may be drawn out through pet cock J.

L is a channel space between inner and outer shells, and connects with air vent R, thus maintaining an atmospheric condition in the lower chamber at all times, and thereby permitting an uninterrupted flow of gasoline to the carburetor.

M is the guide for float.

R is an air vent over the atmospheric valve. See Fig. 151. The effect of this is the same as if the whole tank were elevated and is for the purpose of preventing an overflow of gasoline should the position of the car ever be such



Upper Connections of Vacuum Tank
as would raise the gasoline supply tank higher
than the vacuum tank. Through this tube also
the lower, or reservoir chamber, is continually
open to atmospheric pressure, so that the flow
of gasoline from this lower chamber to the carburetor is always allowed.

T is the outlet located at the bottom of the float reservoir in which is the flapper valve H.

The flapper valve is ground on its seat and should be trouble-proof. A small particle of dirt getting under the flapper valve might pre-

vent it from seating absolutely air-tight and thereby render the tank inoperative: In order to determine whether or not the flapper valve is out of commission, first plug up air vent; then detach tubing from bottom of tank to carburetor. Start motor and apply finger to this opening. If suction is felt continuously, then it is evident that there is a leak in the connection between the tank and the main gasoline supply or else the flapper valve is being held off its seat and is letting air into the tank instead of drawing gasoline.

Any troublesome condition of the flapper valve can be remedied by removing tank cover, then lift out the inner tank. Fig. 152. The flapper valve will be found screwed into the bottom of this inner tank.

Coupling and elbow connections should be kept screwed down tight. Care should be taken that tubing contains no sharp flat bends that might retard the gasoline flow.

Gasoline for priming or cleaning purposes can be obtained by opening pet cock.

To make certain that the tank is not at fault in case of trouble, take out the inner tank entirely. This will leave only the outer shell, which will then be nothing more than an ordinary gravity tank. Fill this tank with gasoline and start to run. If you still have trouble it will be apparent that the fault lies elsewhere and not in the tank.

Carburetor pops and spits are due to improper carburetor adjustments. Running the engine at low speed with an open throttle for any length of time might not produce sufficient suction to fill the tank when empty. But this condition might take place because of dirt or foreign matter getting in and clogging the gasoline feed tube.

If you have any doubt as to the tank being full of gasoline, it is only necessary to close the throttle and the suction of the motor will then fill the tank almost instantly.

To fill the tank, should it ever become entirely empty, close the engine throttle and turn the engine over a few revolutions. This will create sufficient vacuum in the tank to fill it. If the tank has been allowed to stand empty for a considerable time and does not easily fill when the engine is turned over, look for dirt or sediment under the flapper valve H, or the valve may be dry. Removing the plug W in the top and squirting a little gasoline into the tank will wash the dirt from this valve; also wet the valve and cause the tank to work immediately. This flapper valve sometimes gets a black carbon pitting on it, which may tend to hold it from being sucked tight on its seat. In this case the valve should be scraped with a knife.

If the motor speeds up when the vacuum tank is drawing gasoline from the main supply it shows that either the carburetor mixture is too

ich, or the connections are so loose that it is trawing air into the manifold. There should




Fig. 152 Shell of Vacuum Tank

no perceptible change of engine speed when tank is operating.

Gases, Expansion of. All gases expand equally, 1/273 part of their volume for each degree of temperature, Centigrade, of 1/491 part of their volume for each degree of temperature, Fahrenheit.

Gasoline, How Obtained. Benzine, Gasoline, Kerosene and the kindred hydro-carbons are products of crude petroleum.

They are separated from the crude oil by a process of distillation. The process is very similar to that of generating steam from water.

Crude petroleum subjected to heat will give off in the form of vapor such products as Benzine, Gasoline and Kerosene, etc. The degrees of heat at which these products are separated are comparatively low. Various degrees of heat will separate the distinct products. As a means of illustration, it may be said that the crude oil when raised to certain temperatures gives off vapors which when cooled liquefy into oils.

VISCOSITY OF GASOLINE. It is a mistake to assume that because gasoline does not thicken up, it is retarded in its flow through the nozzle of the carbureter. Taking gasoline having a specific gravity of 0.71 the quantity that will pass through the nozzle of a carbureter under a given pressure will increase as the temperature is increased, as shown in the following table:

Temp. degrees F.

Relative Flow.

| 5000 | | _ | | , , | | | | | | | | | • | | | | • | | | • | | , , | | 1 |
|------|---|---|--|-----|--|--|---|--|--|--|--|--|---|---|--|--|---|-----|---|---|--|-----|---|-------|
| 59° | | | | | | | | | | | | | | | | | | | | | | | | 1.073 |
| 68° | | | | | | | , | | | | | | | | | | | , | • | | | , , | • | 1.145 |
| 770 | | | | , | | | | | | | | | | | | | | | | | | , , | • | 1.212 |
| 860 | • | | | | | | | | | | | | | _ | | | | , , | | | | | | 1.27 |
| 95° | | | | | | | | | | | | | | | | | | | | | | | | |

Since carbureter nozzles are not readily adjustable, nor with any degree of certainty, it follows from the above that the influence of temperature upon the weight of fuel ejected will most certainly affect the efficiency of the carbureter. This source of trouble goes to indicate that some means of maintaining a constant temperature is of the greatest advantage, and in a measure it argues for the adaptation of water (hot) jacketing, not around the depression chamber, as is usually the practice, but around the gasoline (float) bowl, in order to maintain a constant temperature of the liquid gasoline as it flows through the nozzle.

Gasoline Explosions. There are two entirely different kinds of explosion, which would undoubtedly both be referred to as gasoline explosions. The real gasoline explosion is the kind taking place in the cylinder of a gasoline motor, in which heat and pressure are suddenly produced by the combustion of gasoline vapor in air. The other kind of explosion referred to may be explained as follows:

If a tank of gasoline be placed on a woodpile and the latter set on fire, the heat would raise a pressure in the tank, which would rapidly increase and the tank would finally explode from the pressure. The gasoline would then be thrown in all directions, and, owing to its superheated condition, the greater part of it at least would instantly vaporize, mix with the air of the atmosphere and be ignited by the flame which caused the explosion.

Gasoline Fires, Extinguishing. A number of fires have been caused by leaky gasoline pipes on automobiles, and many persons would like to know of chemicals which can be used to put out such fires. Water is exceedingly dangerous to use, and it is not always possible to get at the fire to smother it with wet rags or waste.

In case of fire due to gasoline, use fine earth, flour or sand on top of the burning liquid.

A dry powder can be used for this purpose which will extinguish the fire in a few seconds. It is made as follows: Common salt, 15 parts—sal-ammoniac, 15 parts—bicarbonate of soda, 20 parts. The ingredients should be thoroughly mixed together and passed through a fine mesh sieve to secure a homogeneous mixture.

If by any chance a tank of gasoline takes fire at a small outlet or leak, run to the tank and not away from it, and either blow or pat the flame out. Never put water on burning gasoline or oil, the gasoline or oil will float on top of the water and the flames spread much more rapidly.

Several gallons of ammonia, thrown in the room with such force as to break the bottles which contain it, will soon smother the strongest fire if the room be kept closed.

It is not advisable to operate a pleasure car, and certainly not a truck, without having a portable extinguisher on the car. Such extinguish-

ers are made in sizes suitable for carrying in an easily accessible place and should be so mounted. A fire starting in the under-pan or under the hood may be smothered in the beginning, while delay would mean the car's destruction.

Gasoline, Thermo-dynamic Properties of Gasoline and Air. The following table, 8, gives the thermo-dynamic properties of gasoline and air, and may be of interest, in view of the fact that information on this subject is sparse, and most of that only theoretical, or empirical deductions.

This table gives the explosive force in pounds per square inch of mixtures of gasoline vapor and air, varying from 1 to 13 down to 1 to 4, also the lapse of time between the point of ignition and the highest pressure in pounds per square inch attained by the expanding charge of mixture. The tests from which the results given were obtained, were made with a charge of mixture at atmospheric pressure, so as to more accurately note the results, as the mixture takes much longer after ignition to attain its highest pressure, and is slower also in expanding.

It may be well to remember that there are no more heat-units, and consequently no more foot-pounds of work in a mixture of gasoline and air, under 5 atmospheres compression, than under 1 atmosphere compression.

Flanged or ribbed air-cooled motors will approach the figures given in the table for the

initial explosive force for the varying con sions, very closely, while thermal-siphor ter-cooled motors will come within abo per cent of these results, and pump and ra ing coil cooled motors will come within 30 per cent. While it appears at the first g that the proper thing to do to get the gre efficiency from a motor would be to let i as hot as possible, experience has shown the repair bill of a hot motor will more offset its efficiency over the cooler watereted motor, with pump and radiating coils last two columns in the table give the tem ture of the burning gases, the first of the columns the actual temperature with th companying mixture of gasoline and air the second the theoretical temperatures, or perature to which the burning mixture sl attain, if there were no heat losses.

TABLE 8.

THERMO-DYNAMIC PROPERTIES OF GASOLINE AND A

| | Time in Seconds | | osive Fo ads per (| | Temper of Comb |
|--|---|-----------------------------------|--|--|--|
| Gasoline, Vapor and Air. | between Ignition and Highest Pre- | Co in . | rmp ress Atmosph | ion eres. | in Deg Fahren |
| | sure." | 3 | 4 | 5 | Actual. |
| 1 to 13 1 to 11 1 to 9 1 to 7 1 to 5 1 to 4 | 0.28 0.18 0.13 0.07 0.05 0.07 | 156 183 234 261 270 1 | 208 244 312 348 360 320 | 260 305 390 435 450 400 | 1857 2196 2803 3119 3226 2965 |

^{*}At atm

Gearless Transmission. This name has been applied to a wide variety of transmission, or change speed devices. It is quite customary to refer to the friction drive as a gearless system, and this is true to the extent of not using toothed gearing of any form.

A car using this name was built several years ago, and its construction embodied a novel method of change speed mechanism. The transmission system of the gearless car made use of a central cone, long in proportion to its diameter, and faced with friction material. Placed so that they might engage with this driving member, were several sets of rollers, which were, in turn, brought into contact with driven members or clutches. The principle of operation was that of the planetary, or internal epicyclic, gear. In place of using toothed gears, this car secured its drive by bringing one or the other sets of rollers into play and thereby secured three forward speeds and one reverse. Large power was transmitted and little trouble found.

Gears, Diametrical Pitch System of. Table 9 gives the necessary dimensions for laying out and cutting involute tooth spur gears from No. 16 to No. 1 diametral pitch. Formulas are also given so that if the number of teeth and the diametral pitch are known, the pitch diameter can be ascertained—also, the diametral pitch, outside diameter, number of teeth, working depth, and clearance at bottom of tooth:

P = Pitch diameter in inches.

D = Diametral pitch.

W = Working depth of tooth in inches.

T = Thickness of tooth in inches.

O = Outside diameter in inches.

C = Circular pitch in inches.

(6) Number of teeth=
$$P \times D$$

(7) Thickness of tooth=
$$1.571 \times I$$

For example: Required, the pitch diameter of a gear with 20 teeth and No. 5 diameter

pitch. From Formula No. 1, as the pitch diameter is equal to the number of teeth divided by the diametral pitch, then 20 divided by 5 equals 4, as the required pitch diameter in inches.

What is the outside diameter of the same gear? From Formla No. 2, as the pitch diameter is 4 inches, and the diametral pitch No. 5, then 4 plus 2/5 equals 4 2/5 as the proper outside diameter for the gear.

What would be the diametral pitch of a gear with 30 teeth and 5 inches pitch diameter? From Formula No. 3, 30 divided by 5 equals 6, as the diametral pitch to be used for the gear. In this manner by the use of the proper formula any desired dimension may be obtained.

TABLE 9.

DIMENSIONS OF INVOLUTE TOOTH SPUR GEARS.

| Diametral Pitch. | Circular Pitch. | Width of Tooth on Pitch Line. | Working Depth of Tooth, | Actual Depth of Tooth, | Clearance at Bottom of Tooth |
|---------------------|--------------------|--|-------------------------------|------------------------------|------------------------------------|
| 1 | 3.142 | 1.571 | 2.000 | 2.157 | 0.157 |
| $ar{f 2}$ | 1.571 | 0.785 | 1.000 | 1.078 | 0 078 |
| 3 | 1.047 | 0.524 | 0.667 | 0.719 | 0.052 |
| 4 | 0.785 | 0.393 | 0.500 | 0.539 | 0.039 |
| 5 | 0.628 | 0.314 | 0.400 | 0.431 | 0.031 |
| • 6 | 0.524 | 0.262 | 0.333 | 0.360 | 0.026 |
| 7 | 0.447 | 0.224 | 0.286 | 0.308 | 0.022 |
| 8 | 0.393 | 0.196 | 0.250 | 0.270 | 0.019 |
| 10 | 0.314 | 0.157 | 0.200 | 0.216 | 0.016 |
| 12 | 0.262 | 0.131 | 0.167 | 0.180 | 0.013 |
| 14 | 0.224 | 0.112 | 0.143 | 0.154 | 0 011 |
| 16 | 0.196 | 0.098 | 0.125 | 0.135 | 0.009 |

Gears, Horsepower Transmitted by. The following formulas will give the horsepower that

may be transmitted by gears with cut teet involute form and of various metals.

H.P = Horsepower.

P = Pitch diameter in inches.

C = Circular pitch in inches.*

F = Width of face in inches.

R = Revolutions per minute.

$$H.P = \frac{P \times C \times F \times R}{90}$$
 (Annealed tool steel.)

H.P=
$$\frac{P\times C\times F\times R}{140}$$
 (Mach. steel or Phosphor Bronze.)

$$P \times C \times F \times R$$
H.P=

410

(Cast Brass.)

$$P \times C \times F \times R$$
H.P=

(Cast Iron.)

Example: Required, the horsepower wla tool steel pinion, 2 inches pitch diameter inch face and No. 10 diametral pitch, transmit at 900 revolutions per minute.

Answer: From the table the circular p corresponding to No. 10 diametral pitch

Example: What is the circular pitch in inches correspon to No. 6 diametral pitch.

Answer: The result of dividing 3.1416 by 6 gives 0.524 in as the required circular pitch.

^{*}The circular pitch corresponding to any diametral pitch: ber, may be found by dividing the constant 3.1416 by the cetral pitch.

0.314. Then by Formula No. 1, $2\times0.314\times1\times$ 900 equals 565.2. This, divided by 90, gives 5.29 horsepower.

Gear, Internal-Epicyclic. It is often desired to ascertain the speed of rotation of the different members of this form of gearing. To calculate their speeds, the following formulas are given, which, by reference to the letters desig-




Fig. 153

nating the different parts in Figure 153, may be readily solved.

Let R be the revolutions per minute of the disk or spider carrying the pinions D.

Let N be revolutions per minute of the gear E.

Let G be the revolutions per minute of the internal gear F.

When the internal gear F is locked and gear E rotating, the speed in revolutions per minute of the disk or spider carrying the pinions D is

$$\mathbf{R} = \mathbf{N} \quad \frac{\mathbf{E}}{\mathbf{E} + \mathbf{F}}$$

If the internal gear be locked and the spider carrying the pinions D be rotated, then the speed in revolutions per minute for the gear E will be

$$N = R \quad \frac{E + F}{E}$$

If the spider carrying the pinions D be held rigid and the gear E be rotated, the speed in revolutions per minute for the internal gear F is

$$G = \frac{N \times E}{F}$$

If the pitch diameter of the gears is not readily obtainable, the number of teeth in each gear may be used instead, as the result will be exactly the same.

It will be recognized that this is the form of gearing employed in the older forms of planetary transmission devices. Newer types use no internal toothed gears.

Heat of Combustion. The quantity of heat generated by the complete combustion of various gases and petroleum products is known as the heat value of the fuel, and represents the maximum amount of heat that can be obtained from a given quantity of the fuel. No accurate

rule has yet been devised by which to compute the heat value of any chemical compound from its formula and the heat values of the elements of which it is composed. Hence, the heat values of compounds must be found by a separate determination for each one in the laboratory. The heat developed by the combustion of some of the commoner fuels and gases is given in Table 14. In the case of carbon, the heat developed by its complete combustion, forming CO_2 , and the heat of its partial combustion to CO_2 , are given; also the heat of combustion of CO_2 .

HEAT VALUE OF A MIXTURE. The heat value of a mixture may be found from the heat values of the substances of which it is composed and the percentage of each substance. If h_1 , h_2 , h_3 , etc., represent the heat values of the substances forming the mixture, and p_1 , p_2 , p_3 , etc. represent the percentage of each substance, the heat value of the mixture will be represented by the following formula:

$$hm = p_1h_1 + p_2h_2 + p_3h_3 + etc.$$

Example.—A certain gas has the following composition:

| Constituents of Gas | Per | Cent. |
|----------------------------|-----|-----------|
| Hydrogen, H | | 20 |
| Marsh gas, CH ₄ | | 70 |
| Acetylene, C_2H_2 | | 10 |

What is the heat value per cubic foot of the mixture?

Solution.—Referring to Table 10, the heat

TABLE 10. MIXTURES OF AIR AND GASES, AND RESULTING HEAT OF COMBUSTION.

| | | Weight of Gas | Volume of 1 Pound of Gas | ne of of Gas | Volume Required | ume uired | Weight Required Burn 1 | Weight Required to Burn 1 | و | Heat of Combusti | Heat of Combustion |
|-----------------------------------|--|---------------------------------|--|-------------------------|------------------------------------|----------------------|------------------------------|---------------------------------|---|--------------------------|-----------------------|
| Fuel | Chemical Proportions | at 30°, per Cubic Foot | at Atmospheric Pressure Cubic Feet | spheric sure Feet | Cubic Foot of Gas Cubic Feet | Cubic Foot of Gas | Pound of Gas Pounds | nd of | Specific Heat of Gas at Constant Pressure | B. T. U. per Pound | B. T. U. per Cubic |
| | | Pound | 32° | 62° | 0 | Air | 0 | Air | | of Fuel | Gas st 62° |
| Oxygen, O. | 23 lb.0 + 77 lb.N = 100 lb. air | .08927 | 11.20 | 11.88 | : | | | | .21751 | • | : |
| Nitrogen, N Hydrogen, H. | $\sin \phi = 1.3 \text{ Vol.N} = 100 \text{ Vol.}$ $\sin \phi = 1.0 \text{ Vol.}$ $2H + O = H_2O$ | .07847 | 12.77 178.80 | 13.55 189.80 | : 10 | 2.38 | 8. 8. | 34.80 | . 24 380 3.40900 | 62,000 | 327 |
| Carbon, C. | 02 = 0 + 2 | : | : | : | : | : | : | : | | 4.400 14.600 | : |
| Carbon monoxide, CO. | Carbon monoxide, CO : $CO + O = CO$? | .0770 | 12.77 | 13.55 | ; r. ë | 2.38 | .57 | 2.48 | 24790 | 4,385 | 324 |
| Mathema CH. | 1 10.C + 2.80 10.O = 3.00 10. CO ₂ CH, + 40 = 2H ₂ O + CO ₂ | 12323 | 8.12 | | 2.0 | 9.52 | 9 | 17.40 | .21700 | 23.976 | 1.010 |
| Ethylene, Call | + 60 = 2H ₂ O | .07830 | | | 0.4 | 14.28 | 3.43 | 14.90 | 40400 | 21,476 | 1,585 |
| Ethane, CattaBensol vapors, Catta | Call + 70 = 3H20 + 2003 | . 22363 . 22363 | 4.47 | 4.74 | | 35.7 | : : | | .37540 | 18,183 | 3,836 3,836 |
| Acetylene, Calis | + 2 + | .07251 | 13.79 | | 2.5 | 6. 1. 0. | : | | : | 21,421 | 1,464 |

values per cubic foot of these gases are seen to be 327, 1,010 and 1,464 B. T. U., respectively. Apply the formula just given. $p_1 = .20$, $p_2 = .70$, and $p_3 = .10$. Also, $h_1 = 327$, $h_2 = 1,010$, and $h_3 = 1,464$. Substituting, $hm = .20 \times 327 + .70 \times 1,010 + .10 \times 1,464 = 65.4 + 707 + 146.4 = 918.8 B. T. U. Ans.$

Temperature of Combustion. The theoretical temperature of the combustion of a given fuel can easily be calculated. Making no allowance for losses of heat, and supposing that just enough air is furnished for the combustion, burning carbon should have a temperature about 4,940° above zero; while burning hydrogen should have a temperature about 5,800° above zero. In practice, these temperatures are never attained, on account of heat losses.

Loss of Heat. The loss of heat from any hot object is accomplished in three ways: by convection, by conduction and by radiation. In all practical cases a body loses heat by a combination of these processes.

When heat is produced in the cylinder by the combustion of the gases, the piston is at or near the upper dead center; that is, it remains nearly stationary when the heat is greatest and when the heat loss per unit area of inclosing walls is most rapid.

Under the usual conditions of ignition, the gas contained in the cylinder must be set into violent motion by the spread of the flame through it, and this motion will aid the dissipa-

tion of the heat in the gas to the containing walls. So convection will be an important factor in the process and perhaps the principal factor. Perhaps a part of the gain in power which has resulted, in some instances, from the use of multiple ignition may be due to violent motion of the gas. Practically all air cooled motors have their valves in the head, so the charge is contained between the cylinder walls and the piston head.

The heat absorbed by the water-jacket is equal to the weight of water passed through the jacket multiplied by the temperature range; or, in other words, it is the difference between the temperature of the water when it enters the water-jacket and that of the water when it leaves the jacket. For instance, if the temperature of the entering water is 50° and that of escaping water is 180° , the temperature range is $180^{\circ} - 50^{\circ} = 130^{\circ}$. Then, if the weight of the water passing through the jacket in 1 hour is 100 pounds, the heat carried away is $100 \times 130 = 13.000$ British thermal units.

Horsepower. The actual horsepower of an engine can only be determined by making a test with suitable brakes or dynamometers. This method would give the actual brake horsepower. In order to allow ready calculation, the Society of Automobile Engineers' formula is used and is generally recognized. The bore or diameter of the cylinder is first squared; that is, the size in inches is multiplied by itself. This

number is then multiplied by the number of cylinders and the result divided by $2\frac{1}{2}$. Thus, for an engine with 5-inch bore: 5x5=25. If of 4 cylinders, 25x4=100, and 100 divided by $2\frac{1}{2}$ gives the result as 40 horsepower. In order to secure approximately correct results, the engine is supposed to be operating at 1,000 feet per minute piston speed.

Horsepower of Explosive Motors. The first requisite is to find the number of power strokes made per minute by the motor. In a single cylinder motor of the four-cycle type there is one power stroke for every two revolutions, and if the motor has four cylinders there is one power stroke for every revolution of the crank shaft. The number of power strokes then may be found by the following formula (referring to a four-cycle motor):

$$N = \frac{C}{4} \times S$$

in which N = Number of power strokes per minute.

C = Number of cylinders.

S = Angular velocity of crank shaft in revolutions per minute.

Having ascertained the number of power strokes per minute, the horsepower is found by the formula,

$$H.P = \frac{P L A N}{33,000}$$

P = Mean effective pressure (M. E. P.).

L = Length of stroke in feet.

A = Area of piston in sq. in.

N = Number of power strokes per minute. This formula does not discriminate between mechanical friction and losses in "fluid" fration. A formula that is more arbitrary at that fits the majority of cases, requiring or the use of a few facts, such as diameter of cannot inder, length of stroke, and revolutions per mute, is presented as follows:

$$H.P = \frac{V \times N}{10,000}$$

in which

V = volume of cylinder in cu. inches.

N = number of power strokes per min.

The constant used varies from 9,000 to 14.0 depending upon certain types of engines; 10,0 being an average figure for four cycle engine. The brake horsepower will be from 65 to 85 p cent of the result obtained; 80 per cent may taken as an average. As an example we may take a four-cycle, four-cylinder motor 4½ bore and 4½-in. stroke making 1,200 pow strokes per minute. Volume (V) of cylind equals area of piston 15.9 sq. in. × length stroke 4½=71.55 cu. in., and multiplying the by 1,200 (N) and dividing the product by 1 000 gives 8.05 H.P. Taking 80 per cent of the as the brake horsepower the result is 6.44 H.

From a theoretical standpoint a two-cycle explosive motor should not only have as great a speed, but also be capable of developing almost twice the power that a four-cycle motor does. It is a fact nevertheless that its actual performance is far different.

The horsepower of a two-cycle motor may be calculated from the following formula,

$$H.P = \frac{D^2 \times S \times N}{21,000}$$

in which

D=diameter of cylinder in inches.

S-stroke of piston in inches.

N=number of revs. per minute.

Example: Required, the horsepower of a two-cycle motor of $4\frac{1}{2}$ inches bore and stroke, with a speed of 900 revolutions per minute.

Answer: The square of the bore multiplied by the stroke is equal to 91.125, which multiplied by 900, and divided by 21,000, gives 3.91 as the required horsepower. The results given by the above examples agree very closely with those obtained from actual practice.

Horsepower, Electrical. One electrical horsepower is equal to the current in amperes multiplied by the electro-motive force or voltage of the circuit and divided by 746.

Let C be the current in amperes and E the voltage of the circuit. If E. H. P. be the required electrical horsepower, then

$$E.H.P = \frac{E \times C}{746}$$

In practice with motors of small power, 1,000 watts are necessary to deliver one mechanical or brake horsepower at the driving shaft of the motor.

If the actual or brake horsepower of an electric motor be known, the efficiency of the motor may be readily found by the following formula:

If E be the voltage of the circuit and C the current in amperes consumed by the motor, let B. H. P be the brake horsepower of the motor and e the efficiency of the motor, then

$$\mathbf{e} = \frac{\text{B.H.P} \times 746}{\text{E} \times \text{C}}$$

Table 10 gives the electrical horsepower of motors with voltage from 20 to 100 volts, and current strengths from 10 to 80 amperes.

The mechanical efficiency of a motor may be found by use of the table as follows

Example: Required the mechanical efficiency of a 40-volt, 60-ampere motor, which is rated by its maker as of 3.25 horsepower—the motor when under full load using 80 amperes.

Answer: Reference to the column in the table corresponding to 40 volts and 60 amperes gives 3.22, while the 80 ampere column gives 4.29. Then 3.22 divided by 4.29 gives 0.75, or 75 per cent, as the mechanical efficiency of the motor.

Ignition Systems.

Ignition. In order that an explosive motor ay operate economically, and with the highest ercentage of efficiency, it is absolutely necestry that two objects shall be attained, viz.: A





Fig. 154

Coil and Timer Ignition With Storage Battery

rect mixture of the gasoline and air, and that is mixture be correctly ignited at the proper me.



Coll and Timer With Dry Cells. A, Switch. B, Dry Cells. C, Condenser. D, Timer. E, Contacts. F, Armature. G, Core of Coll. H, Primary Winding. I, High Tension Winding. J, Spark Plug.




Fig. 156

Coll Vibrator Principle. A, Core of Coil. B, Armature of Coil Magnet. C, Adjusting Screw. D, Trembler Blade. E, Contacts.





Fig. 157

Coil Vibrator Details. A, Adjustment. B, Tension Spring. C, Trembler Blade. D, Holding Screw. E, Contact Bridge. F, Contact Blade. G, Locking Screw.



Connecticut Storage Battery Ignition Wiring




Fig. 159 Circuits Through Remy Battery Ignition System

INDUCTION COIL. Induction is the process by which a body having electrical or magnetic properties calls forth similar properties in a neighboring body without direct contact. This property is known as self-induction, and is caused by the reaction of different parts of the same circuit upon one another, due to variations in distance or current strength. The current produced by an induction coil has a very high electro-motive force, and hence great power of overcoming resistance.




Fig. 160.

If a current of electricity be caused to flow through a straight conductor forming a part of a closed electric circuit, lines of force, commonly called magnetic whirls or waves, are induced in the air and rotate around the conductor.

If the current of electricity be flowing in the circuit and through the straight conductor from

right to left, as shown in the upper view in Fig. 160, the lines of force or magnetic whirls will rotate around the conductor from left to right, or in the direction of the hands of a clock. On the other hand, if the conditions be reversed and the current flows from left to right the lines of force or magnetic whirls will rotate from right to left, as shown in the lower view in Fig. 160. The direction of rotation of these lines of force or magnetic whirls may be positively determined by the use of a galvanometer, an electric testing instrument having a needle similar in appearance to that of an ordinary com-Upon placing this instrument in the path of the lines of force and making and breaking the battery circuit by means of the switch, the needle of the galvanometer will be deflected from its zero point in the direction of the rotation of the lines of force. If the direction of the flow of the electric current through the circuit be changed by reversing the poles of the battery, the needle of the galvanometer will be deflected from its zero point in the opposite direction. Whether these lines of force or magnetic whirls rotate continuously around the wire has not been demonstrated. They rotate with sufficient force to be tested by the galvanometer only until the electric current in the closed circuit has reached its maximum value after closing the circuit; that is to say, only during the infinitesimal space of time required by the current to reach its full value or power.

If, instead of a straight conductor, a loop of insulated wire, in the form of a circle, be untilized for the passage of the current, as at A and B in Fig. 161, the lines of force will still rotate around the wire as shown, their direction being dependent on the direction of the electric current. If the electrical circuit be provided with




Fig. 161

a current reverser, or device for changing the battery connections in the circuit from positive to negative and vice versa, the lines of force can be made to rotate rapidly first in one direction and then in the other, as indicated in Fig. 160.

Suppose this loop of insulated wire be composed of a great number of turns, it then be-

comes a coil or closed helix, and as all the lines of force cannot pass between the turns of the electrical conductor forming this helix they must pass completely through the helix instead of rotating around a single loop, as at A and B, Fig. 161. If the current flows through the conductor in the direction indicated by the arrows, at C in Fig. 161, and over and around the coil in the direction shown, the lines of force will flow through the coil towards the observer, and complete their path or circuit through the air, returning into the coil at the opposite end. If the current be reversed and flow around the coil in the direction of the hands of a clock, the lines of force will flow through the coil in the opposite direction, that is, away from the observer, as at D, Fig. 161.

This form of coil or closed helix may be designated as the primitive form of an electromagnet. When forming part of a closed electric circuit it possesses the property of magnetizing a bar of wrought iron placed within it. If a short round bar of wrought iron be placed a short distance within the coil, and the battery circuit be closed, the iron bar will, if the current is sufficiently strong, be sucked or drawn into the center of the coil, and a considerable effort will be required to withdraw it.

The object of the bundle of soft iron wires, which form the core of any form of spark coil, is to increase the magnetic effect of the lines of

force or magnetic flux, or rather to reduce the resistance to their passage through the coil.

As has been previously stated, when a current of electricity flows through a conductor of wire forming a coil or closed helix, lines of force are induced and flow through, and also around the exterior of the coil. In a like manner, when the electric circuit is broken, the lines of force suddenly reverse their direction, and travel through the coil with a tremendous velocity until they





Fig. 162
Principle of Atwater Kent Battery Ignition

reach a state of neutralization. During this reverse travel of the lines of force through the coil, a current of electricity is induced in the winding of the coil, but in the opposite direction to that in which the battery current was flowing. The effect of this induced current, which is of far greater intensity or pressure than the bat-



tery current which induced it, is to form an arc or spark at the breaking point in the circuit.

SECONDARY SPARK COIL. Fig. 163 shows the secondary or jump-spark form of coil. It is composed of an iron core and a primary winding similar to that described in conjunction with Fig. 162, with the addition of an outer winding of many turns of fine wire. This wire, of very small size, is known as the secondary winding, varying in diameter from No. 36 to No. 40 B. & S. Gauge, and in length from 5,000 to 10,000 feet. In the drawing the induction coil is shown equipped with an electro-magnet make and break, or vibrator device, which is the form mostly used for ignition purposes. The other form, known as the plain jump-spark coil, has a mechanically operated make and break device attached to the motor to operate the coil.

The arc or spark produced at the breaking point of the electrical circuit in which the primary winding of the coil is connected is not utilized for ignition purposes in this type of coil. When the circuit is broken the sudden reaction or backward flow of the lines of force or magnetic flux in the iron core produce an induced current in the secondary winding, but in the opposite direction to that of the battery current. This induced current is of so much greater intensity and velocity than that induced in the primary winding by this same reaction, that the arc or spark induced in the secondary winding of the coil will jump across a space

from one end of the wire to the other, vary from ½ inch to as much as 8 or 10 inche length, dependent upon the length of wire the secondary circuit, the electro-motive for the battery and the frequency of the in ruptions or number of times per minute electric circuit is made and broken.

Referring to Fig. 163 A is the core, B the mary winding and C the secondary. The coils are held in place upon the core by washers D. The primary wire B is wound a paper tube E, and the secondary wire C is sulated from the primary wire by a mica is lating tube F. The coil proper is enclosed wood case G.

The terminals or binding posts on top of case G are connected with the ends of the ondary wire 1 and 2. The secondary termi are plainly indicated by the letter S. In base H of the coil case is the condenser J essential feature of this form of coil, wl utilizes the induced primary current to prod a greater reactive energy in the second winding.

At the right-hand end of the coil and outs the casing G is located the electro-magnetic brator or trembling device, which automatics makes and breaks the primary circuit. I end 3 of the primary wire is connected with contact screw K through the bracket L. I spring M, carried by the bracket N, with scr O, is connected with the terminal or bindi

post P, immediately beneath it, by the wire 6 through the bracket N. The end 4 of the primary wire is connected with another terminal or binding post P, at the other end of the base of the coil. The condenser J is connected across the contact points of the screw K and the spring M, by the wires 5 and 6 and screws Q and X. The condenser is composed of a number of sheets of tinfoil V, laid between sheets of specially insulated paper I, with the opposite end of every alternate sheet of tinfoil projecting from the paper insulation, as shown. These projecting ends are connected together, and by the wires 5 and 6 to the contact screw K and spring M, respectively, as previously described.

When the coil is connected in, or forms part of a closed electric circuit by means of the terminal or binding posts P, on the base of the coil, the current flows through the primary winding B. This instantly produces a high degree of magnetism in the core A, and the polepiece T of the core extension R becomes strongly magnetic and attracts the iron button W of the spring M. This draws the spring M away from the end of the screw K, and in consequence breaks the electric circuit. This results in the demagnetizing of the pole-piece T and the consequent return of the spring M to its normal position in contact with the end of the screw K. So long as the electric circuit remains closed this operation is repeated at a very high rate of speed. The effect of this continuous operation of the coil is to produce an intermittent current in the secondary winding of high intensity and velocity. If wires are placed in the holes in the small terminals or binding posts on the top of the coil and brought within a short distance of each other, a stream of sparks will pass from one wire to the other in a peculiar zigzag manner and emit a loud, crackling noise, accompanied by a peculiar odor, caused by the formation of ozone through the electro-chemical action of the spark.

Under ordinary circumstances the arc or spark which occurs on the breaking of the contact between the platinum points of the screw K and spring M would not be utilized, but by means of the condenser in the base, which is connected to these parts, as before described, the static charge of electricity generated by this action is stored in the condenser. When the contact is again made this stored electric energy is given up or discharged by the condenser and flows through the primary winding of the coil in connection and in the same direction as the battery current and increases the magnetic effect of the core A enormously.

The construction and operation of the condenser is fully described under the heading Condenser. It should be understood that this is one of the most important elements of the ignition system, whether battery or magneto type, and its care should never be neglected if efficient ignition is desired.

IGNITION—TIMING. In timing the ignition of a motor one should base his operations on one particular cylinder, and this should be the most accessible one. Let it be assumed that a mechanic is required to test or correct the timing of a four-cycle vertical engine. He would have to know the order in which the cylinders fired, and how to find the firing center of No. 1 cylinder. As the operation of the valves on most motors may be readily seen, the firing center and the order in which the cylinders fire can be easily learned from the action of either set. For instance, if on turning the motor over slowly the intake valve of No. 1 cylinder opens and closes, then that of No. 3 cylinder, and following No. 3 that of No. 4 operates, the mechanic need go no further, for he knows that the engine fires 1-3-4-2. The exhaust valves, of course, may be used in the same way. However, if the valves are entirely enclosed, as on the Winton cars, open the priming or relief cocks, and beginning with cylinder No. 1 note the order in which the air is forced out through the cocks. There are two rules for finding which cylinder is on its firing center, that are based on the action of the valves; these are as follows: When an exhaust valve is open the following cylinder is about to fire. When an intake valve is open the previous cylinder is about to fire. One very simple method of finding the firing center of a cylinder is to open the priming cocks of all the cylinders but one,

turn the motor over slowly till compression is encountered, open the cock, insert a stiff wire till it rests on the piston head, then carefully bring the piston to the top of its stroke. The cylinder will then be on its firing center. When the firing center, and the order in which the cylinders fire are known, all that remains to be done in timing an engine is to set the revolving segment of the commutator or distributer so that a spark will occur in the proper cylinder when the spark control lever is advanced about one-third or, with the spark control lever fully retarded, and the piston about ½ to 1 inch down on the explosion stroke, set the segment so that it just begins to make contact.

Many troubles arise from faulty or defective insulation.

A wire placed too close to an exhaust-pipe invariably fails after a time, owing to the insulation becoming burnt by the heat of the pipe.

A loose wire hanging against a sharp edge will invariably chafe through in course of time.

If the insulation of the coil breaks down it cannot be repaired on the road, it should be returned to the makers. A slight ticking is usually audible inside the coil when this occurs.

All wires where joined together should be carefully soldered, the joints being afterwards insulated with rubber or prepared tape. Never make a joint in the secondary wires. See that all terminals are tightly screwed up. When connecting insulated wire, the insulation must

be removed, so that only the bare wire is attached. Wires sometimes become broken, and being loose make only a partial contact.

Battery terminals frequently become corroded; they should be covered with vaseline, and require periodical cleaning. See that all connections at the battery are clean and bright.

The porcelain of the spark plug may be cracked and the current jumping across the fracture. The points may be sooty and require cleaning. They may be touching and require separating, or they may be too far apart. The usual distance between the points is about one thirty-second of an inch, which is approximately the thickness of a heavy business card.

Clean all oil and dirt from the commutator. Most commutators are so placed as to give the maximum possible opportunity to collect oil and dirt. They should always be provided with a cover.

In course of time dry or storage batteries will become weak or discharged. Always carry an extra set.

Spanners, oil-cans, tire-pumps, etc., have been known to get on the top of the batteries, thereby connecting the terminals together and causing a short-circuit.


The platinum contacts of the coil may become corroded. They should be cleaned with a small piece of emery cloth or sandpaper.

Ignition, Atwater Kent. This device is designed to draw from a battery, as nearly as possible, only the electrical energy necessary to ignite the charge, and to keep the batteries until the energy remaining in them is too small to produce an effective spark. Its principal constituent parts are, a jump-spark coil and condenser, a primary contact maker, the time of which may be advanced or retarded, and a high tension distributer. Its distinguishing features are—

- a. But one spark is made for each ignition.
- b. The primary contact, rupture of which produces the spark, is exceedingly brief, no longer in fact than is actually required to build up the magnetism in the core of the spark coil.
- c. The duration of this contact is independent of the engine speed in the same way that the contact of the ordinary coil vibrator is.
- d. Contact is made and broken mechanically through a shaft driven by the engine, consequently a spark may be obtained from a battery that is too weak to operate a vibrator. The mechanism by which the instantaneous primary contact is produced is similar to a snap contact produced by a small spring-controlled hammer pulled out of position by a ratchet on the shaft. The ratchet has as many teeth as there are cylinders, and runs at the camshaft speed. When used with a two-cycle engine, it runs at the crankshaft speed if there are four cylinders. If there are two cylinders, it runs at half the en-

gine speed and the ratchet has four teeth. The ordinary commutator is not used in connection with it, but a driving connection must be made from the crankshaft or camshaft to the vertical shaft of the spark generator itself, which is mounted on the back of the dashboard.

The Atwater-Kent system consists of three parts: 1, The unisparker, which combines the special form of contact-maker, which is the basic principle of this system, and a high tension distributor.



Atwater Kent Timer Before Moving Lever

2, The coil, which consists of a simple primary and secondary winding, with condenser—all imbedded in a special insulating compound. The coil has no vibrators or other moving parts.

3, The ignition switch.

The operation of the unisparker is shown in Figs. 164 to 167. This consists of a notched shaft, one notch for each cylinder, which ro-

tates at one-half the engine speed, a lifter or trigger which is pulled forward by the rotation of the shaft and a spring which pulls the lifter back to its original position. A hardened steel latch and a pair of contact points complete the device.




Fig. 165
Atwater Kent Timer Before Lever Escapes

The figures show the operation of the contact-maker very clearly. It will be noted that in Fig. 164 the lifter is being pulled forward by the notched shaft. When pulled forward as far as the shaft will carry it, Fig. 165, the lifter is suddenly pulled back by the recoil of the lifter spring. In returning it strikes against the latch, throwing this against the contact spring and closing the contact for a very brief instant—far too quickly for the eye to follow the movement, Fig. 166.

Fig. 167 shows the lifter ready to be pulled forward by the next notch.

Note that the circuit is closed only during the instant of the spark. No current can flow at any other time, even if the switch is left "on" when the motor is not running.

By means of the distributor, which forms the upper part of the unisparker, the high-tension current from the coil is conveyed by the rotating distributor block, which seats on the end of the unisparker, to each of the spark plug terminals in the order of firing.





Fig. 166

Atwater Kent Timer With Contacts Closed

Where the lighting and starting battery is used for ignition, two wires from the ignition system should run directly to the battery terminals. They should not be connected in on any other branch circuit.

The automatic type is cylindrical in shape and consists of a pressed steel casing with a hard rubber cap, the latter forming the base of the high-tension distributor. The device is mounted on a shaft which is driven at half the speed of the crankshaft. Within the casing is located the mechanism, consisting of the governor which automatically controls the advance, the circuit breaker and high-tension distributor.



Atwater Kent Timer With Contacts Re-opened

At the bottom of the casing is the prevernor, a modification of the centrifugal type which consists of two pairs of weights, each pair being pivoted together at their centers, and two double arm brackets. When the shaft starts to revolve, the weights extend away from the center and the arms change their angular relation in direct proportion to the speed of the driving shaft.

In order that the weights will not move away from the center too easily and give too great an advance to low speeds, the brackets carrying the springs are so arranged that the weights have to act against them when obeying the impulse of centrifugal force, and moving away from the axis of rotation. Virtually each weight is a bell-crank lever with one point of connection pivoted to the arm and the other point of connection pivoted to the weight. The four weights thus give four bell-crank levers working in the same direction at the same time against the four respective springs.

In timing with automatic advance the piston in No. 1 cylinder should be raised to high dead center, between compression and power strokes, then, with the clamp which holds the unisparker loose, the unisparker should be slowly and carefully turned backwards, or counter clockwise (contrary to the direction of rotation of the timer-shaft), until a click is heard. This click happens at the exact instant of the spark. Now clamp the unisparker tight, being careful not to change its position.

Now remove the distributor cap, which fits only in one position, and note the position of the distributor block on the end of the shaft. The terminal to which it points is connected to No. 1 cylinder. The other cylinders in their proper order of order of firing are connected to the other terminals in turn, keeping in mind the direction of rotation of the timer shaft.

When timed in this manner the spark occurs exactly on "center" when the engine is turned over slowly. At cranking speeds the governor automatically retards the spark for safe starting, and as the speed increases, the spark is automatically advanced, thus requiring no attention on the part of the driver.

The first operation in timing the hand advance unisparker is to crank the engine until the piston of No. 1 cylinder is on high dead center between the compression and power strokes.

The unisparker is then placed on the shaft, the advance rod from the steering post being connected to the lug on the side of the unisparker, which is provided for that purpose.

The position of the spark advance lever on the steering wheel sector should be within ½ inch of full retard, and the connecting levers should be such as to give the unisparker a movement of at least 45 degrees to 60 degrees for the full range of spark advance.

After the spark lever is connected up and the unisparker is in position it should be left loose at the driving gear, and, with the motor on dead center as above directed, the shaft of the unisparker should then be turned forward or in the same direction as that in which the timer shaft normally rotates, until a click is heard, at which point it should be set by tightening the driving connection.

The contact points are the only adjustable

feature of the unisparker. These points should never touch when engine is at rest and the space between them should vary from 1/100 to 1/64 of an inch, depending upon the strength of the batteries, spark, heat required, etc. The spark can be made hotter by decreasing the distance, and current can be economized by increasing it. Once or twice a season these contacts should be examined and should be kept flat and bright by means of a small file or emery cloth on a stick. The proper adjustment when starting with new batteries is about 1/32 of an inch, if dry cells are used. If storage battery is used, it may be necessary to reduce this a little. At intervals of six or eight hundred miles of service as the batteries decrease in strength, these contacts should be closed from a quarter to a half turn, or until regular firing is obtained. Do not attempt under any circumstances to adjust the tension of the springs.

Frequently when high-tension wires are run from the distributor to the spark plugs through metal or fibre tubing, trouble is experienced with missing and back-firing, which is due to induction between the various wires in the tube. This trouble is especially likely to happen if the main secondary wire from the coil to the center of the distributor runs through this tube with the spark-plug wires.

Wherever possible, the distributor wires should be separated by at least ½ inch of space and should be supported by brackets or insu-

lators rather than run through a tube. In no case should the main distributor wire be run through a conduit with the other wires.

If irregular sparking is noted at all plugs, examine first the battery and connection therefrom. If the trouble commences suddenly, it




Fig. 168
Connecticut Igniter Head

is probably due to a loose connection in the wiring. If gradually, the batteries may be weakening or the contact points may require attention. See that the contacts are clean and bright, and also that the moving parts are not gummed with oil or rusted.

Ignition, Connecticut. The Connecticut automatic igniter system, Fig. 168, produces a single spark upon a break occurring in the primary circuit which, though being closed, has energized a coil. This break is effected in the igniter by means of a cam revolving against a breaker arm. The high tension spark is distributed in the same instrument. The igniter is mounted on a vertical shaft running at half engine speed irrespective of the number of





Fig. 169 Connecticut Breaker Mechanism

cylinders. The breaker arm is insulated from the base. This provides a metallic circuit; or in other words, no engine ground need be utilized in the primary or battery circuit, as the primary winding is insulated from the secondary ground in the coil. In this case there is no possibility of the ignition being affected through grounding or shorts in any other circuit of the car, such as disarrangement in liquing or starting systems.

The igniter may be taken apart and resembled without the aid of any tools. The tributor case can be removed by unsnapping two spring clips on the side, thus exposing distributor arm carrying the carbon brufig. 169, which can be slipped off the sh



Connecticut Distributor Rotor

Then remove cotter pin passing through s and the dust proof cover carrying the up bearing can be taken off and the breaker complete, Fig. 170, can be lifted from the sh As the shaft is not disturbed the timing i no way affected when the igniter is reassem on the shaft.

The system is not recommended for use on dry cells except as an emergency, but is designed to operate from a storage battery charged by a dynamo.

The automatic switch of the Connecticut automatic igniter system is a feature that is individual to this system and unique in ignition apparatus. Its function is to kick off the switch should the primary circuit be closed an unwarranted length of time, as in the case of a car being left with the switch on the engine stopped. This will prevent the draining of batteries.

Another purpose is to protect the ignition wiring should a disarrangement occur in the lighting or starting circuit and an excessive and destructive amount of current be introduced into the ignition circuit.

The circuit is closed in the automatic switch through contacts of the plunger type. These plungers are held in contact by a slotted locking plate. This plate is released by the "off" button on the switch; or in cases of prolonged or excessive flow of current, by a vibrating magnetic release thermostatically effected. The construction is such that no amount of outside vibration or jar can in any way affect the locking plate.

This automatic "kick off" is accomplished thermostatically and is a mechanism that has been employed for many years in telephone switches.

To time the igniter, turn the engine or with petcocks open, until the piston of the f cylinder has reached the top of the compa sion stroke. Now advance the spark lever the steering wheel about three-quarters of way. Remove distributor cap, then set igniter on driving shaft with set screws lo connect advance lever, turn hub of igniter shaft in direction of rotation until contact poi are just open, which is the point at which spark takes place, then tighten the hub screws. Replace the distributor cap, carefu noticing which segment of the distributor brush is opposite, for this is the connection the spark plug of No. 1 cylinder. Con: up the balance of the spark plugs in their ing order. After connecting all wires you then ready to try out the ignition. cranking, fully retard your spark lever. suit individual requirements, it may be ne sary to slightly advance the igniter hub greater speed is required, or slightly retard for very slow speed.

This igniter is completely housed and particle tested. Little care is required to keep it working condition. About every four or thousand miles the distributor cap should removed and wiped out. On the ball-bear igniter, the distributor arm should be we drawn and one or two drops and no more good oil injected into the hole in the end the shaft which carries the distributor a

This will lubricate the lower ball-bearing. No other parts need oiling. Care should be taken to see that oil does not reach the contact points. On the plain bearings or self-lubricating type, the bearings require no attention whatever.

The contact points will probably require no attention until run at least ten thousand miles and in some cases they may operate for over thirty thousand miles without attention.

The points do not require refiling or cleaning even though they may be very rough and irregular, but when they become so badly burned as to cause missing they should then be renewed, in which case proceed as follows:

Remove the distributor cap and arm, disconnect advance lever and wires, remove cotter pin in igniter shaft, then spring washer and fibre washer, and lift the housing from its shaft.

The contact adjustment screw will be noticed under the dust ring, it being locked from turning by a hexagon nut on the screw inside near the end. Care should be taken to see that this nut is tightened up snugly after making a replacement or adjustment. When it is necessary to adjust these points they should be set so that when the roller rests on the point of the cam, they open about the same as a magneto interrupter. It is not necessary, however, to make this adjustment as accurately as on a magneto. The adjustable contact screw can be removed by taking off the lock-nut and then screwing it back out of the housing.

The contact on the breaker arm is riveted into it and a complete new arm is necessary in making a replacement.

This arm can be readily removed by taking out the small cotter pin in the end of the stud on which it moves, remove small fibre washers and the arm can then be lifted out.

When replacing the arm on the stud before putting the cotter pin in place, be sure and replace the little fibre washers which rest on the top of the arm just under the little cotter pin and the fibre washer on the stud in the bottom of the cup.

Ignition, Delco. The Delco system of battery ignition makes use of a combined breaker and distributor usually mounted on, and driven from, the lighting dynamo or motor-dynamo. In some installations the ignition unit is placed by itself, but the construction and operation is the same in either case.

The distributor and timer are driven through a set of spiral gears attached to the armature shaft or its extension. The distributor consists of a cap or head of insulating material, carrying one high-tension contact in the center, with similar contacts spaced equi-distant about the center, and a rotor which maintains constant communication with the central contact.

The rotor carries a contact button which sends the secondary circuit to the spark plug in the proper cylinder.

Beneath the distributor head and rotor is the ner, Fig. 171, which is provided with a screw the center of the shaft, the loosening of which




Fig. 171

ico Ignition Head Breaker. A, Cam Holding B, Battery Current Contacts. Screw. Breaker Cam. D, Resistance Wire Spool. Cam Contact Levers. M, Dynamo Current Contacts.

ows the cam to be turned in either direction secure the proper timing, turning in a clockse direction to advance and counter-clockse to retard.

The spark occurs at the instant the timer contacts are opened.

The adjustment screw must always be set down tight after the cam is adjusted.

The same weight which operates the arm on the regulating resistance also operates the automatic spark control. In addition to the automatic spark control, a manual spark control is provided, which is operated by the lever on the steering column, and is connected to the lever at the bottom of the motor generator. The manual spark control is for the purpose of securing the proper ignition control for variable conditions, such as starting, differences in gasoline and weather conditions. The automatic control is for the purpose of securing the proper ignition control necessary for the variations due to speed alone.

The resistance unit is a coil of resistance wire wound on a porcelain spool. Under ordinary conditions it remains cool and offers little resistance to the passage of current. If for any reason the ignition circuit remains closed for any considerable length of time, the current passing through the coil heats the resistance wire, increasing its resistance to a point where very little current passes, and insuring against a waste of current from battery and damage to the ignition coil and timer contacts. When the arm that cuts the regulating resistance into the shunt field circuit is at the top position (that is, at high speeds), the resistance unit is cut

out of the ignition circuit. This increases the intensity of the spark at high speeds.

To time ignition: Fully retard the spark lever. Turn the engine so that upper dead center on flywheel is about one inch past dead center with No. 1 cylinder on the firing stroke. Loosen screw in center of timing mechanism and locate the proper lobe of the cam by turning until the button on the rotor comes under the high tension terminal for No. 1 cylinder. Set this lobe of the cam so that when the back lash in the distributor gears is rocked forward the timing contacts will be open, and when the back lash is rocked backward the contacts will just close. Tighten screw and replace rotor and distributor head.

If the motor fires properly on the "M" button, but not on the "B" button, the trouble must be in the wiring between the dry cells or the wires leading from the dry cells to the combination switch, or depleted dry cells.

If the ignition works on the "B" button and not on the "M" button, the trouble must be in the leads running from the storage battery to the motor-generator, or the lead running from the rear terminal on the generator to the combination switch, or in the storage battery itself, or its connection to the frame of the car.

If both systems of ignition fail and the supply of current from both the storage battery and dry cells is ample, the trouble must be in the coil, resistance unit, timer contacts or con-

denser. This is apparent from the fact that these work in the same capacity for each system of ignition.


The following directions for upkeep apply in a general way to the "M" or "Mag" ignition on all of the Delco systems, but do not apply to the dry battery ignition.

The contact points are of tungsten metal, which is very hard and requires a very high temperature to melt. These should be kept clean and smooth on the faces. This can be done by holding in a vice and using fine emery cloth held underneath a flat file. They should be so adjusted that when they are open they are apart ten-thousands of an inch and the contact arm should move about fifteen-thousands of an inch after the contacts close.

The most common causes of contact trouble are due to the following: (1) Resistance unit shorted out, resulting in excessive current through the contacts, especially at low speeds. (2) Abnormally high voltages due to running without the battery or with a loose connection in the battery circuit. (3) A broken down condenser.

The distributor head should be properly located, that is with the locating tongue of the hold-down clip in the notch on the distributor head. The head should be kept wiped clean from dust and dirt and in some cases it is advisable to lubricate this head with a small amount of vaseline.

The rotor should be kept free from dust and dirt and the rotor button polished bright. The rotor button should be fully depressed before putting on the distributor head to make sure



the spring will allow the button to go down to the proper level and not subject it to undue pressure on the distributor head. Remy Battery System. This make of ignition equipment is furnished in two principal types, one of which might be called "magneto type" and the other one a "vertical ignition head."

The magneto type equipment, Fig. 172, bears a very close resemblance to the breaker and distributor end of a separate unit magneto, being composed of a distributor having terminals for the spark plug leads and below the distributor a breaker exactly similar in construction to that with magnetos. In connection with this unit a two-way switch is used, giving either dry battery or generator as a source of ignition current. To transform the current to one of high-tension a separate coil is used.

This coil differs from ordinary coil construction inasmuch as both ends of the primary winding are insulated, so that, in the event of a ground occurring in the lighting or starting circuits, the ignition will be unaffected. The coil is provided with a safety gap as a further means of protection.

The coil is wound for six volts and is to be used in connection with a storage battery or with five dry cells. The coil is to be mounted on the crankcase within 6 or 8 inches of the breaker points as the condenser is incorporated in the coil and not on the generator. A special top plate is provided to securely hold coil in position.

The circuit breaker platinum points may be

inspected by removing the Bakelite housing cover. The points should have a smooth, clean, flat surface at all times. The break, or gap, of these points should be from 15 to 20 thousandths of an inch. The circuit breaker may, if desired, be removed without the aid of tools.

The high-tension current is distributed to the spark plug cables by means of a hard carbon brush making contact with distributor segments. Neither distributor nor brush will require any attention whatsoever.




Fig. 173
Remy Vertical Ignition Timer

An oiler is provided for the distributor shaft, —only a few drops of light oil every one thousand miles will suffice.

The use of spark plugs which permit of the points being adjusted to a definite gap is recommended. The gap between the points should be from 20 to 25 thousandths of an inch.

If the motor misses when running idle or pulling light, the plug gaps should be wider. If motor misses at high speed or when pulling heavy at low speed, the plug gaps should be made closer.

The vertical ignition head consists of a combined breaker and distributor mounted in one case, Fig. 173, and adapted to be driven from a vertical shaft usually on or near the lighting dynamo.

Some of these distributors have a manual advance for the spark, while some are built with a mechanism which automatically advances the spark to meet the requirements of the engine upon which it is installed.

The high-tension current is distributed to the spark plug leads by a segment which revolves close to, but does not touch, the pins in the distributor head.

Either iridium-platinum, tungsten or silver is used in the contact points, the choice depending upon which is best suited to the installation.

The coil furnished with this system has a special ventilating base which may be bolted securely to the engine frame. Its current consumption is limited by a resistance located on top of the coil and which is in series with the primary winding.

The metal base of the coil makes an electrical connection with the engine or car frame for one side of the secondary winding. Therefore, it is very important before mounting the coil to see

that all foreign matter, such as dirt, grease, paint, etc., is removed from the place where the coil is to be mounted. It is also very important that the base of the coil be fastened down securely at all times.

The switches furnished with this equipment are arranged to reverse the direction of current flow through the circuit breaker each time the ignition is used.

It is absolutely necessary that the ignition switch be placed in the "off" position when the engine is not running. If it is left in the "on" position, current from the storage battery will be dissipated in the ignition coil which, if continued, will exhaust the battery.

By an insulated system is meant one in which the circuit breaker is not grounded. By glancing at the wiring diagram it will be seen that the circuit from the switch around through the breaker box and back to the switch again is not grounded, and that the switch reverses the direction of the current flow through this circuit at each quarter turn.

If the insulation is worn off any one of the wires and the copper touches any of the metal parts of the car, a short circuit will result which will either render the system inoperative by burning out a fuse or will discharge the battery. A periodical inspection should be made of all wiring to see that it is not rubbing or chafing on any of the metal parts of the car and that all connections are tight and secure.

The contact screw should be adjusted with the wrench furnished with the system, so that the maximum opening of the points is .020 to .025 inch, or the thickness of the piece riveted upon the side of the wrench. The rebound spring should be at least .020 of an inch from the breaker arm when the points are at their maximum opening.

To obtain the best results the spark-plug gaps should be adjusted to .025 of an inch.


Ignition, Westinghouse. Dual ignition is obtained in the Westinghouse system; that is, the battery is an independent source of supply, as well as the generator operating with the battery, while the interrupter, ignition coil and distributer are common to both.

The interrupter is so constructed that the period of contact is practically the same at any speed. The spark voltage, therefore, does not fall off at high speeds, but is practically the same at all speeds.

Automatic spark advance is a feature of the Westinghouse generator. The automatic advance works over a range of 45°. Provision is made for manual operation also, and it is recommended that this be connected up, but the spark lever need not ordinarily be touched after the original adjustment, the automatic device taking care of all adjustments in running.

The interrupter is mounted on the generator shaft and contacts are operated by a centrifugal device that automatically adjusts the spark ad-


vance to the speed, keeps the period of contact nearly constant at all speeds and prevents any inequality between the two interruptions that occur in succession during each revolution.



Westinghouse Ignition and Lighting Dynamo

The ignition outfit consists, in addition to the lighting system and storage battery, of a distributer and an interrupter, which are made a part of the generator, Fig. 174, and an ignition coil and switch. The ignition coil transforms the six volts of the battery up to the high tension required for the spark plugs. The interrupter closes and then opens the ignition circuit at each half revolution of the generator shaft, and the distributer directs the high-tension current to each of the spark plugs in succession.

The operation of the ignition system, including the interrupter and distributer, ignition coil and switch, begins with the "making" of the primary circuit of the coil when the centrifugal weights push down the fibre bumper, allowing the interrupter contacts to close, Fig. 175. Then the weight moves off the fibre bumper, allowing the contacts to suddenly separate or open, when a high voltage is induced in the secondary of the ignition coil and directed by the distributer




Westinghouse Ignition Breaker, Low Speed Po-

to the proper spark plug, causing a spark. As the speed of the engine increases, the weights are thrown out from the center and automatically advance the time of closing or opening the interrupter contacts, and hence advance the spark, Fig. 176. At the same time, due to their shape, they keep the contacts closed during a greater part of the revolution when running at high speed; this makes the period of contact

practically the same at all speeds and prevents the spark voltage from falling off at high speeds.

To connect the ignition system to the circuit, insert the plug into the ignition switch and move the switch handle to the "on" position.



Westinghouse Ignition Breaker, High Speed Position

In inserting the ignition plug pay no attention to the position of the brass contact pieces on the plug. It is desirable that the contacts will average up as often in one as in the other of the two possible positions, as this reverses the direction of the current through the interrupter contacts and greatly increases their life.

The spark plug should be set with slightly less than 1/32 inch between tips for best operation. Oily or carbonized plugs will often cause missing, and if dirty, they should be well brushed inside and outside with gasoline and wiped per-

fectly dry. A crack in the insulating material will, of course, probably lead to failure of spark in the cylinder.

The interrupter stop is adjusted so as to give the proper pressure on the bumper. When the engine is not running and the weights are in a closed position, there should be a space of 3/64 inch between the bumper lever and the stop. After the stop is adjusted, the contact screw should be adjusted by means of a wrench, so that with the cam lever against the upper stop, the contacts are open .005 inch. After setting for this separation, tighten the clamping screw so that the contact screw is held firmly. Be sure that the contacts open up positively and that the moving element moves clear up against the upper stop when released, with some spring tension still remaining to hold it in this position. See that the contacts are kept free from all oil and grit.


Interrupter weights should turn freely on their supporting pins and should also clear the centrifugal weight spring support by approximately .01 inch. They should show no lost motion between the two interlocking weights. In making any readjustments, be careful that when the engine is turned over very slowly by hand, both weights depress the moving part of the interrupter enough to definitely close the contacts, otherwise there will be a tendency to miss fire in every second cylinder, especially at low speeds and if the contacts are worn more or less.

When the weights are in the inner position, the springs should just touch the fibre-covered pins on the weights without exerting any appreciable pressure over that required to just positively return the weights to the innermost position. If necessary to adjust these springs, always bend the supporting arms and not the springs themselves.

Distributer brushes should slide freely in their holders and the springs should push them out so as to extend from the holder about ¼ inch when the distributer plate is removed from the generator. These brushes should, however, be retained firmly by their springs so as to never tend to fall completely out of the tubes. Be sure that both these brushes are in place in the distributer.

Distributer plate should be kept clean and free from carbon dust between brushes and contact surfaces by an occasional wiping. Any pitting of the distributer which is in advance of the contacts, indicates that the distributer gear is set one tooth or so too far back against the direction of its rotation. This may cause intermittent firing of the cylinders at the higher speeds, with consequent loss of power. The gear is set correctly at the factory, and if this setting is not disturbed the above trouble will not be encountered.

The distributer gear is meshed with the pinion on the generator shaft so that the mark at the edge of the gear lines up with the tooth of the pinion that is slightly beveled. In coupling the generator to the engine, place the piston of cylinder No. 1 on dead center at the end of the compression stroke. Remove the distributer plate and turn the generator back so that the line of the distributer brushholder block corresponds with the line on the end bracket. Couple the engine and generator shafts while in this position.



Westinghouse Vertical Ignition Head

The Westinghouse vertical ignition unit can be used for ignition from storage batteries or plain lighting generators, Fig. 177. This set

contains interrupter, spark coil and condenser, and distributer, all in one unit. One wire from the battery or generator to the ignition unit and one wire to each spark plug are all that are required.




Fig. 178
Westinghouse Vertical Ignition Wiring

The interrupter, located at the lower end of the set, has the same type of circuit-breaker as that on the Westinghouse ignition and lighting generators, but no automatic spark advance feature. It can be used equally efficiently for either direction of rotation without charge. The interrupter is enclosed by a spring collar which can be readily removed for inspection or adjustment of the contacts. The collar makes a tight joint and is clamped by a screw which prevents it from slipping. See wiring diagram, Fig. 178.

The Westinghouse Ford vertical ignition unit is made up of four essential parts, namely, the interrupter, the condenser, the induction coil, and the distributer, all included in one case.

The operation of the interrupter can be observed by loosening the thumbscrew and sliding upward the loose section of the insulation case, which forms the interrupter cover.

With the ignition switch turned to the "on" position and the engine turning over, each segment of the interrupter cam in turn passes on and off the fibre bumper. As each cam passes off the bumper, the interrupter contacts close, closing the circuit from the battery to the primary winding of the induction coil. Then as they pass on the bumper, the contacts are opened, suddenly opening the circuit, thus inducing a high voltage in the secondary of the induction coil. This voltage is directed by the distributer on the top of the ignition unit to the proper spark plug, causing a spark at the spark gap of the plug inside the cylinder, and igniting the charge therein.

The contact screw should be adjusted with a

screwdriver so that, with the cam against the bumper, the contacts are open .008 inch.

If the contacts show pitted or irregular surfaces they should be smoothed up with a very fine file, making certain that the surfaces come together squarely after adjustment has been made.

Ignition, Magneto Type. Magneto ignition makes use of a separately mounted machine having its own armature and field magnets (permanent magnets) and being driven from the engine. A magneto always consists of a rotating member, this being a shuttle wound armature in most cases, or simply pieces of iron in inductor type. This rotating member, through the change in the path of the lines of force from the magnets, produces a current in a coil separate or on the armature in the shuttle wound form, or mounted separately in the inductor magneto. This current rises from zero to its maximum voltage twice for each revolution of the magneto shaft, one impulse flowing in one direction through the windings and the next one (on the other half revolution) flowing in the opposite direction. The current from a magneto always reverses its direction in this way and is, therefore, an alternating current. The current from a lighting dynamo does not reverse its direction and is a direct current. For this reason no magneto can ever be used for charging a storage battery, a battery requiring current that always flows in one direction through the circuit.

Combined with the armature and the permanent steel magnets that provide the field for the magneto is a breaker mechanism that interrupts the flow of current through the circuit whenever a spark is desired; and also a distributor that carries the contacts for delivering the high-tension current through the wires that lead to the spark plug in the cylinder that is ready to fire. While the details of construction of magnetos differ as described in the following pages, all types contain the parts described above. A shuttle wound armature with a breaker mounted on its shaft is shown in Fig. 179.




Fig. 179

Shuttle Type Magneto Armature With Breaker

The breaker may take any one of several forms, a commonly used construction being shown in Fig. 180. The circuit is completed through the contacts A, one of which is solidly mounted, and the other one attached to the movable arm B. The arm carries a fibre block that strikes a stationary cam when it is revolved on the armature shaft, and inasmuch as the arm is pivoted, the contacts are separated to interrupt the circuit and cause a spark to come from the winding of the high tension coil of the sys-

tem. The fine winding that forms the high tension coil may be wound around outside of the armature winding on the shuttle type, or may be mounted in a housing separate from the magneto. With the high tension coil on the armature, the magneto is self-contained and produces a spark without outside parts, being called a true high tension magneto. Those magnetos using outside coils generate the current in their




Fig. 180 Magneto Breaker

armature and send it through the heavy winding of the separate induction coil, or transformer coil. This separate coil has also a fine wire winding in which the high tension spark plug current is induced by the breaking of the circuit through the heavy wire when the breaker on the magneto opens.

The system known as "single ignition," when using a magneto, comprises a true high tension

machine from which wires lead to the spark plugs. The only other wire required is one to the switch that will allow the driver to stop the production of sparks by connecting the armature winding to the frame of the car, or grounding it. No other source of current is provided with single ignition.


"Double ignition" provides a true high-tension magneto, as described, and in addition, a complete, and entirely separate, battery, timer and coil system with a separate set of spark plugs and wiring.

"Dual ignition" uses a magneto similar to the single ignition high-tension type, but provides an additional breaker and induction coil through which current may be led from a set of dry cells or a storage battery, thus providing a source of current other than that of the magneto armature when desired for starting or emergency use.

"Transformer coil ignition" makes use of a magneto that produces in its armature, or by inductor action, a current of low voltage that is led to a separately mounted transformer, or induction coil. The coil is connected by wires to the breaker and distributor on the magneto.

How to Remove and Replace a Magneto. When about to replace or remove a magneto it is well to see that all separable parts are properly marked, and if not, mark them. This may be done with a center punch, cold chisel, letters or numerals. In Fig. 181 is shown the guide

ks generally used in connection with a highion magneto of a four-cylinder motor. The ter punch marks C, on the Oldham coupling 1 as is usually employed on the magneto it between the magneto and its driving gear, e as a guide in replacing the magneto. All ; is necessary in replacing a high-tension neto so marked on a four-cylinder, foure motor is to see that the marks are directly osite each other; but in two or six-cylinder ors, where the crankshaft and the armature the magneto do not run at the same speed, must be taken either not to move the ikshaft while the magneto is off or to check the timing before it is replaced. In the e illustration is shown the method of mark-



the timing gears. These marks are made a cold chisel and are generally present in to-date construction.





Fig. 182

Figs. 182 and 183

Bosch High Tension Magneto, Type "DU". Armature End Plate for Primary Winding Con-Breaker Fastening Screw. nection. 2, Breaker Contact Block. 4, Breaker Disc. Long Platinum Contact Screw. 6, Short Platinum Contact Screw. 7, Flat Spring for Breaker Lever. 8, Breaker Lever. 9, Condenser. Collector Ring for High Tension Current. High Tension Carbon Brush. 12, Carbon Brush Holder. 13, Conductor Bar Terminal. 14, Conductor Bar. 15, Distributor Brush Holder. Distributor Carbon Brush. 17, Distributor Plate. 18. Central Contact on Distributor. 19, Brass Segment 20, Terminal for Spark Plug Wire. 21. Steel Breaker Cam. 22, Dust Cover. 25, Distributor Block Grounding Terminal. Holding Spring 116, Breaker Timing Lever. 117. Breaker Cover. 118, Conducting Spring for Grounding Terminal. 119, Breaker Cover Holding Spring.

Bosch Magnetos. The Bosch high tension magneto, Fig. 182, generates its own high-tension current directly in the armature winding and without the use of a separate coil or other apparatus. Apart from the cables connecting the magneto to the plugs, the Bosch high-tension magneto requires no external connections.



The armature carries two windings. The primary consists of a few layers of heavy wire and the secondary of a great number of layers of fine wire. One end of the primary winding is grounded on the armature core, and the live end is brought out to a circuit-breaking device. The grounded end of the secondary winding is con-

nected to the live end of the primary winding so that one is a continuation of the other.

During certain portions of the rotation of the armature the primary circuit is closed, and the variations in magnetic flux have their effect in inducing an electric current in it. When the current reaches a maximum, which will occur twice during each rotation of the armature, the primary circuit is broken, and the resulting armature reactions produce a high-tension current of extreme intensity in the secondary winding. This current is transmitted to a distributer by means of which it passes to the spark plug of the cylinder that is in the firing position.

The magneto interrupter, Fig. 183, is fitted into the end of the armature shaft which is taper-bored and provided with a key-way. The interrupter is held in position by a fastening screw, and may easily be removed. In replacing it, care should be taken that the key fits into the key-way and that the fastening screw is well tightened.

Twice during each revolution of the armature the primary circuit closes and opens, this being effected by the interrupter lever coming in contact with a steel segment, which is supported on the interrupter housing. When the magneto interrupter lever is not being acted upon by the steel segment, the platinum points are in contact, thus closing the primary circuit. Then as the armature rotates farther and the interrupter lever again comes in contact with a seg-

ment, the platinum points (interrupter contacts) open and thus interrupt the primary circuit. At the opening of the contact the ignition spark occurs instantaneously.

The distance between the platinum points when the magneto interrupter lever is fully depressed by one of the steel segments must not exceed 1/32 inch. This distance may be adjusted by means of a long platinum screw, and should be in accordance with the steel gauge that is pivoted to the adjusting wrench.




Fig. 184

High and Low Tension Circuits of Bosch Magneto

The connections of the magneto, Fig. 184, consist of a high-tension cable from the distributor to each spark plug, and a low-tension cable leading to the switch.

In order to protect the insulation of the armature and of the current-carrying parts of the

apparatus against excessive voltage, a safety spark gap is arranged on the dust cover. It consists of a short pointed brass rod set on the dust cover, and a second pointed brass part supported a short distance from it in the center of the stealite cover of the housing. The insulated point is connected into the secondary circuit, and should there be any interference with the circuit normally provided through the spark plug the safety spark gap provides a point of discharge.

If a spark is observed passing in the safety spark gap it is an indication that there is an interruption in the regular secondary circuit, and the cause should be at once investigated.

A simple test for the magneto is to disconnect the grounding cable from grounding terminal and also to disconnect the spark plug cables. The motor should then be cranked briskly, and the safety spark gap closely observed. If sparks are seen at this point, it is an absolute indication that the magneto is in proper operating condition. If no sparks are observed it will be necessary to make sure that the primary circuit is properly interrupted by the magneto interrupter. Holding spring must be moved sideways, interrupter housing cover taken off, and it must be ascertained whether fastening screw is well tightened. After this it should be observed whether the platinum points are in contact when the steel cams are not acting on the magneto interrupter lever, also whether they

parate the correct distance, 1/25th inch, when e interrupter lever is resting on one of the eel cams. Otherwise the distance must be ljusted by means of the platinum screw. The atinum contacts must be examined and any l and dirt removed; in case the contacts are neven (but only then) they must be smoothed ith a fine flat file. If, after continued use, the atinum contacts are completely worn down, e two platinum screws must be renewed.

The Bosch dual magneto is of the standard osch type, and produces its own sparking curnt, which is timed by the revolving interpeter. The parts of this interrupter are cared on a disk that is attached to the armature of revolves with it, the segments that serve cams being supported on the interrupter ousing.

In addition, the magneto is provided with a eel cam having two projections, which is built to the interrupter disk. This cam acts on a ver that is supported on the interrupter housig, the lever being so connected in the battery reuit that it serves as a timer to control the ow of battery current through the coil.

It is obvious that the sparking current from the battery and from the magneto cannot be led the spark plugs at the same time, and a furter change from the magneto of the independent form is found in the removal of the conucting bar between the collecting ring and the istributer. The collecting ring brush is con-


nected to the switch and a second wire leads from the switch to the terminal that is centrally located on the distributer.

When running on the magneto the sparking current that is induced thus flows to the distributer by way of switch contact. When running on the battery the primary circuit of the magneto is grounded, and there is, therefore, no production of sparking current by the magneto; it is then the sparking current from the coil that flows to the distributer connection. It will thus be seen that of the magneto and battery circuits the only parts used in common are the distributer and the spark plugs.

The end plate of the coil housing carries a handle by which the switch may be operated. By means of this switch either the magneto or the battery may be employed as the source of ignition current, and in its operation the entire coil is rotated within the housing. The inner side of the stationary switch plate is provided with spring contacts that register with contact plates attached to the base of the coil.

For the purpose of starting on the spark, a vibrator may be cut into the coil circuit by pressing the button that is seen in the center of the end plate. Normally, this vibrator is out of circuit, but the pressing of the button brings together its platinum contacts and a vibrator spark of high frequency is produced. It will be found that the distributer on the magneto is then in such a position that this vibrator spark


is produced at the spark plug of the cylinder that is performing the power stroke; if mixture is present in this cylinder ignition will result and the engine will start.



Bosch Dual System Wiring Diagram

The dual system requires four connections between the magneto and the switch, Fig. 185; two of these are high tension and consist of wire No. 3 by which the high-tension current from the magneto is led to the switch contact, and wire No. 4 by which the high-tension current from either magneto or coil goes to the distributor. Wire No. 1 is low tension, and conducts the battery current from the primary winding of the coil to the battery interrupter. Low-tension wire No. 2 is the grounding wire by which the primary circuit of the magneto is grounded

when the switch is thrown to the "off" or to the battery position. Wire No. 5 leads from the negative terminal of the battery to the coil, and the positive terminal of the battery is grounded by wire No. 7; a second ground wire No. 6 is connected to the coil terminal.



Method of Setting Armature of Bosch Magneto

The timing of the Bosch Dual Magneto is identical with the standard type. The dual magneto is so arranged that the battery interrupter breaks its circuit approximately 10 degrees later than the magneto interrupter; this feature gives the full timing range of the magneto. With the timing lever fully retarded and the switch on the battery position, the battery spark will occur after the piston has passed

dead center and is moving on the power stroke. The possibility of a back kick is thus eliminated.

The magneto should be placed in position on the bed plate or pad provided for it, the bolts or straps being properly secured; the driving gear or coupling, however, should be loose on the armature shaft. The dust cover, which is an aluminum plate located under the arch of the magneto, should then be removed, and this is accomplished according to the design of the various types of magnetos.

The engine should now be cranked until one of the pistons, preferably that of cylinder No. 1, is at the top of the compression stroke. With the engine in this position, the armature should be rotated by hand in the direction in which it will be driven until it is approximately in the position illustrated in Fig. 186. The setting of the armature is determined by the dimension marked E, Fig. 186, as follows:

| "DU3" Model 4 | 11 to 14 mm. |
|---------------|----------------------|
| "DU4" Model 4 | 13 to 15 mm. |
| "DU6" Model 4 | 16 to 20 mm. |
| "DU3" Model 4 | 8 to 11 mm. |
| "DU4" Model 4 | 10 to 13 mm. |
| "DU6" Model 4 | \dots 12 to 16 mm. |

With the armature held in the proper position, the gear or coupling should be secured. The greatest care should be exercised to prevent the slipping of the armature during this operation.

In the fully enclosed magneto it is unneces-

sary to remove either the interrupter housing cover or the distributer plate in order to determine the setting of the instrument, or to locate the distributer terminal with which contact is made.

The magneto having been bolted into position, the crankshaft is to be turned to bring one of the pistons, preferably that of cylinder No. 1, to the firing position for full advance.

The armature is then rotated until the figure "1" can be seen through the window in the face of the distributer plate. The cover of the oilwell on the distributer end of the magneto is then to be raised, and the armature is to be turned a few degrees in one direction or the other until the red mark on one of the distributer gear teeth is brought to register with the red marks on the side of the window located between the two oil ducts.

The magneto is then in time for the full advance position, and the gear or coupling is to be secured to the armature shaft. Great care should be taken not to disturb the position either of the crankshaft or the armature shaft when fitting the driving member.

Bosch Enclosed Types. In the "DU" dual magneto, the current is led from the collector ring connection to the coil and back to the distributer terminal that is located in the center of the distributer plate. In the enclosed dual magneto, this central terminal is eliminated, and the current is led internally to the

distributer from a connection on the shaft end of the magneto. To expose this terminal, the shaft end bonnet should be removed, which is done by withdrawing the two screws in its lower flange, and sliding the bonnet backward. The terminal will then be seen to be a vulcanite post. with a boss that projects through a hole in the bonnet. In the top of this post are two vertical holes, in the bottom of each of which is a screw. These screws are to be withdrawn. The ends of the high-tension wires No. 3 and No. 4 leading to the coil are then to be cut off square, and after being led through the hole in the bonnet, are to be pressed to the bottoms of the slanting holes in the boss. The pointed screws are then to be replaced in the vertical holes, and n being driven home they will pierce the cables (and their insulation) and make the required connections. It is essential to use a screwdriver of the proper size, for a tool with too large a plade will inevitably crack the vulcanite. Great eare must be taken to apply the screwdriver to the screws vertically in order to avoid cracking the vulcanite by side pressure. When the connections are made the bonnet is to be replaced.

Bosch Upkeep and Care. It will be noted that the press button on the coil is arranged to set in either of two positions, which are indicated by an arrow engraved on its surface, or projecting from its edge. When this button is n such a position that the arrow is pointing on the word "run" a single contact spark will be

produced when the engine is cranked, or when the engine is running with the switch in the battery position. Under all ordinary conditions the button position should invariably be used.

When the engine is chilled, however, or under poor mixture conditions, starting can frequently be facilitated by pressing down the button and turning it slightly to the right so that the arrow is pointing to the word "start." This will lock the vibrator in circuit, and a shower of vibrator sparks will be produced in place of the single contact spark.

The platinum points of the magneto interrupter should be kept clean and smooth and so adjusted that they are open about 1/64 inch, or the thickness of the gauge attached to the adjusting wrench, when the magneto interrupter lever is wide open on one of the rollers or segments. It should not be necessary to clean or readjust these points oftener than once a season, and it is not advisable to readjust them until their condition and the missing of the engine show it to be absolutely necessary.

Each coil is stamped with the voltage of the battery current for which it is wound, and if this voltage is not exceeded the platinum contacts of the battery interrupter will not require attention for long periods. When this battery interrupter lever is being operated by the rollers or segments, the platinum points should be slightly wider open than the contact points of the magneto interrupter—the proper distance being about 1/50 inch.

If the magneto is at fault, all the cables and terminals should be examined for improper connections. The coil and battery system may then be disconnected by removing the wires from terminals Nos. 3 and 4 of the magneto, and with a short piece of wire magneto terminal No. 3 may be connected directly with magneto terminal No. 4. This will conduct the high-tension current induced in the magneto direct to the distributer. The grounding wire should then be disconnected from terminal No. 2 of the magneto. With this arrangement it should be possible to start the engine on the magneto, and it will be necessary to follow this plan should any accident happen to the coil.

To ascertain if the magneto is generating current, the grounding wire should be disconnected from terminal No. 2 on the magneto, and the high-tension wire should be disconnected from the collecting ring terminal No. 3. If the engine is then cranked briskly a spark should appear at the safety spark gap that is located under the arch of the magnets on the dust cover, provided the magneto is in proper condition. The grounding wire should then be reconnected to terminal No. 2, and the engine cranked. no spark appears at the safety spark gap, the trouble may be determined as a leakage of the primary magneto current to ground by chafed insulation, incorrect connections, or an injury to the switch parts.


The coil may be tested by disconnecting wire

No. 4 from the magneto and throwing the switch to the battery position, operating the press button with terminal No. 4 3/16 inch from the metal of the engine. If the coil is in good condition, a brilliant spark should be observed. If the spark does not appear the test should be repeated with wire No. 3 disconnected. If the fault persists the coil body may be removed from the housing by withdrawing the holding screw that is located close to the supporting flange; the switch should then be unlocked and the end plate given a quarter revolution. This will release the bayonet lock and the coil body may then be withdrawn to permit the inspection of the switch contacts both of the coil and of the stationary switch plate. It may be that the spring contacts are bent or otherwise in bad condition. The withdrawing of the coil body and its handling should be performed with extreme care. No work should be done on the coil in the way of withdrawing screws, etc., and if the inspection does not disclose the fault the coil should be returned to its housing and the whole returned to the makers or to one of their branches.

Bosch "NU" Magneto. Like other Bosch high-tension magnetos, the type "NU4," Fig. 187, generates its own high-tension current directly in the magneto armature (the rotating member of the magneto) without the aid of a separate step-up coil, and has its timer and distributer integral. The distinct gear-driven

distributor common to other types has been omitted in the "NU4" magneto, and in its stead is a double slipring combining the functions of current collector and distributor.

The armature winding is composed of two sections: one, primary, or low tension, consisting of a few layers of comparatively heavy wire, and the other, secondary, or high tension, consisting of many layers of fine wire.



Bosch High Tension Magneto, Model "NU"

The beginning of the primary winding is in metallic contact with the armature core, and the other, or live, end is connected by means of the interrupter fastening screw to the insulated contact block supporting the long platinum screw on the magneto interrupter. The interrupter lever, carrying a short platinum screw, is mounted on the interrupter disc which, in turn, is electrically connected to the armature core. The primary circuit is completed whenever the

two platinum interrupter screws are in contact and interrupted whenever these screws are separated. The separation of the platinum screws is controlled by the action of the interrupter lever as it bears against the two steel segments secured to the inner surface of the interrupter housing. The high-tension current is generated in the secondary winding only when there is an interruption of the primary circuit, the spark being produced at the instant the platinum interrupter screws separate.

The secondary winding is insulated from the primary, and the two ends of the secondary are connected to two metal segments in the slipring mounted on the armature, just inside the driving shaft end plate of the magneto. The slipring has two grooves, each containing one of the two metal segments. These segments are set diametrically opposite on the armature shaft, that is, 180 degrees apart, and insulated from each other, as well as from the armature core and magneto frame.


The four slipring brushes which are part of the secondary circuit are supported by two double brush holders, one on each side of the driving shaft end plate, each holder carrying two brushes so arranged that each brush bears against the slipring in a separate groove. Upon rotation of the armature, the metal segment in one slipring groove makes contact with a brush on one side of the magneto at the same instant that the metal segment in the other slipring groove comes into contact with a brush on the opposite side of the magneto. The marks 1 and 2 appearing in white on both brush holders indicate pairs of brushes receiving simultaneous contact, those marked 1 constituting one pair, and those marked 2 the other.

A spark is caused at two plugs simultaneously. It is important to note that as two of the four slipring brushes receive contact simultaneously and each is connected by cable to the spark plug in one of the cylinders, the secondary circuit always includes two plugs, and the spark occurs in two cylinders simultaneously.

After removing one of the brush holders to permit observation of the slipring, the armature shaft is rotated in the direction in which it is to be driven, until the beginning of the metal slipring segment is visible in the slipring groove corresponding to Fig. 1 of the brush holder which has been removed. With that done, the cover of the magneto interrupter housing is to be removed to expose the interrupter. The armature shaft should then be further rotated until the platinum interrupter screws are just about to separate, which occurs when the interrupter lever begins to bear against one of the steel segments of the interrupter housing.

The armature should be held in that position while the magneto drive is connected to the engine, due care being taken that the piston of No. 1 cylinder is still exactly on top dead center of the compression stroke.

After the brush holder and interrupter housing cover have been replaced the installation is completed by connecting the cable of one of the brushes, marked 1, with cylinder No. 1, Fig. 188, and the other with cylinder No. 4; the remaining two cables, leading from the brushes, marked 2, must be connected with cylinders Nos. 2 and 3.



Wiring Connections for Bosch Magneto, Model "NU"

DIXIE MAGNETO. The Mason principle on which the Dixie magneto operates is shown in Fig. 189. The magnet has two rotating polar extremities, N S, which are always of the same polarity, never reversing. These poles are in practical contact with the inner cheeks of the permanent magnet M, all air gaps being eliminated. Together with the U-shaped magnet, they form a magnet with rotating ends.

At right angles to the rotating poles is a field consisting of pole pieces F and G, Fig. 190, carrying across their top the core C and the windings W. When N is opposite G, the magnetism flows from pole N on the magnet to G and through the core C to F.




Fig. 189
Dixie Magneto Principle

In Fig. 191 the pole N has moved over to F and the direction of the flow of magnetism is reversed; it now flowing from F through C to G. The rotating poles do not reverse their polarity at any time, consequently the lag due to the magnetic reluctance in this part is eliminated.

The magneto has a rotating element consisting of two pieces of cast iron with a piece of brass between them, but no armature of the usual form, the revolving generating element being shown in Fig. 192. The pieces N S are separated by the brass block B and correspond to the pieces N S in Figs. 189, 190 and 191. The generating windings are carried on a small coil placed across the upwardly projecting ends of two pole pieces.

The core of the coil A, Fig. 193, is stationary, and the inner end G of the primary winding P is grounded on the core. Q indicates the metal frame of the machine, which is put to-




Fig. 190





Fig. 191 Dixie Magneto Action Reversal of Magnetism Through Dixie Magneto

gether with screws. The condenser R is located immediately above the coil and is readily re-



Rotating Element in Dixie Magneto The terminal D is a screw on the movable. head of the coil and the wire Z connects directly to the contact Y of the breaker. The breaker con stationary and do not reure type. volve as i

Fig. 194 shows the high tension circuit. Here the end C of the high tension winding goes to a metal plate D carried on the upper side A of the coil. Against D bears a connection F, which is practically one piece with the traveling contact J, which connects to the spark plug segment L, the circuit being completed through the spark plug, engine frame and frame of magneto in the usual manner without brush G.





Fig. 193 Low Tension Primary Circuit of Dixie Magneto

The proper distance between the platinum points when separated should not exceed 1/50 of an inch, and a gauge of the proper size is attached to the screwdriver furnished with the Dixie.

The platinum contacts should be kept clean and properly adjusted. Should the contacts become pitted, a fine file should be used to smooth them in order to permit them to come into perfect contact. The distributor block should be


removed occasionally and inspected for an accumulation of carbon dust. The inside of the distributor should then be wiped dry with a clean cloth. When replacing the block, care must be taken in pushing the carbon brush into the socket. The magneto should not be tested unless it is completely assembled, that is, with the breaker box, distributor cover and wires in position.



High Tension Circuit of Dixie Magneto

In order to obtain the most efficient results with the Dixie magneto the normal setting of the spark plug points should not exceed .025 of an inch and it is advisable to have the gap just right before a spark plug is inserted into the cylinder. The spark plub electrodes may be easily set by means of the gauge attached to the screwdriver furnished with the magneto.

EISEMANN MAGNETO. There are two types of the Eisemann magneto. First, the low-tension gneto requiring a transformer to raise the tage of the current; and second, the high




Eisemann High-Tension Magneto

sion magneto, which has a double winding the armature and does not require a non-rator coil.

The low tension magneto gives off from 20 to 40 volts only. One end of the armature winding is grounded, the live end passing to the insulated contact of the interrupter, which is located at the end of the armature shaft. From this point the circuit continues to one terminal of the primary winding of the coil, the other terminal of which is grounded. grounded part of the interrupter, a pivoted lever, is operated by a cam carried on the armature shaft, and makes and breaks contact with the insulated part. The cam is set in such relation to the armature that the breaking of the circuit by the interrupter coincides with the production of maximum current in the armature winding. When the interrupter is making contact, the magneto current is offered two circuits by which it may flow to ground, one being through the interrupter and the other through the primary winding of the coil. resistance of the former being low, the current takes that path in preference to the other, which is of higher resistance. When the current reaches its maximum the cam breaks the interrupter circuit, and the only path by which the current can then flow to ground is that offered by the primary winding of the coil. This sudden and intense flow causes the core of the coil to throw out a powerful magnetic field. which induces a current in the secondary winding of from 20,000 to 40,000 volts. This current is passed to the proper spark plug through the

medium of a distributer located on the magneto and driven by the armature shaft. A condenser is connected across the interrupter contacts to reduce the sparking as the circuit is broken, and to effect a more abrupt change in the magnetic field of the coil.



General Wiring Diagram for Eisemann Magneto

A later Eisemann magneto is of the hightension type, as shown in Fig. 195, in which A is the cam nut; B, steel contact for high-tension distributer; C, platinum contact for makeand-break lever; D, high-tension distributer cover; E, nut for adjustable contact screw: F, spring for make-and-break lever; G, carbon contact for high-tension distributer; H, make-and-break lever; I, low-tension carbon brush; K, adjustable platinum contact screw; L, grease box for large toothed wheel; M, nut; N, cam; O, cable joints; P, distributer plate; Q, metal contact; S, screw for spring for make-and-break lever; V, high-tension distributer.





Fig. 197

Magnetos are made to turn in either direction, but the magneto once finished turns in one direction only, and this direction is indicated by an arrow placed on the gear wheel case.

The spark occurs in one of the cylinders at the moment that the contact points are separated by the cam. The advance mechanism is arranged in three different ways: (1) by means of a lever working the make-and-break mechanism (quadrant advance); (2) by means of a piston sliding longitudinally, and fitted to the end of the driving axle (piston advance); (3) by rocking the magnets bodily around the armature (pivoting advance). In all cases a displacement of 45 degrees can be obtained. In magnetos with quadrant advance the driving spindle is fixed by means of a pin and nut.


This type of magneto is consequently shorter than the one with piston advance. In the latter case the driving pinion is fixed on a hollow spindle.



Pole Piece Construction in Eisemann Magneto

The Eisemann dual system consists of a direct high-tension magneto and a combined transformer coil and switch. The transformer proper is used only in connection with the battery; the switch is used in common by both battery and magneto systems. The magneto is practically the same as the single ignition instrument. Separate windings and contact breakers are used for battery or magneto current. On the other hand, parts that are not subject to accident, or rapid wear, are used in common.

A distinctive feature is that the pole pieces are of a certain shape, Fig. 198, whereby the most extended portion thereof is approximately opposite the theoretical axis of the winding upon armature core. This construction results in the flow of the magnetic lines of force being drawn from the extremities of the pole pieces towards the center of the core; a large volume of the magnetic line of force is thus forced through the winding.



Breaker of Eisemann Magneto

The make-and-break mechanism, Fig. 199, consists of a bronze plate on the back of which, and cast in one piece with it, is a cone, fitting into the armature shaft, which is bored out and provided with a key-way. It moves inside of the timing lever and is fastened to the arma-

ture by means of the screw. If this screw is extracted the whole mechanism can be removed.

The primary current is led from the winding through the armature shaft to the contact screw by the insulated screw, which also serves to hold the mechanism to the armature shaft as already described. When the armature reaches the correct position, a lever is lifted by two steel cams fastened to the magneto body; the primary circuit is broken and the current is induced in the secondary winding. The beginning of the secondary winding is connected with the end of the primary winding, and the other end, through several mediums, finally delivers the spark in the cylinder.

In addition to this the magneto is also fitted with the battery circuit breaker, which is mounted at the back of the magneto breaker. It consists of a steel cam, having two projections which actuate a steel lever mounted into the breaker housing.

A condenser is built in between the T-shaped end of the armature and the bearing. This prevents a spark occurring at the platinum contacts with the consequent pitting and burning, when the contact breaker opens, and it also increases the intensity of the spark at the plugs.

The coil consists of a non-vibrating transformer and a switch, which is used in common to put either the battery or magneto ignition into operation. It is cylindrical in shape, compact,

and is placed through the dashboard. The end which projects through on the same side as the motor has terminal connections for the cables. The other end, facing the operator, contains the switch and the starting mechanism. The transformer proper is used only in conjunction with the battery.

As the spark occurs when the primary circuit is broken by the opening of the platinum contacts, it is necessary that the magneto will be so timed that at full retard the platinum contacts will open when the piston has reached its highest point on the firing stroke. To arrive at this, turn motor by hand until piston of No. 1 cylinder is on the dead center (firing point). Place the timing lever of the magneto in fully retarded position, then turn armature of magneto until No. 1 appears at the glass dial of the distributer plate, and make sure that the platinum contacts of the magneto are just opening. Fix the driving medium in this position.

If no window is seen, turn motor by hand until piston of No. 1 cylinder is on dead center (firing point), remove the distributer plate from the magneto and turn the drive shaft of the armature until the setting mark on the distributer disc is in line with the setting screw above the distributer. (For magneto rotating clockwise use setting mark R, and for counter clockwise use mark L.) With the armature in this position the platinum contacts are just opening and the metal segment of the distributer disc


is in connection with carbon brush for No. 1 cylinder. The driving medium must now be fixed to the armature axle without disturbing the position of the latter, and the cables connected to the spark plugs.

If a spark plug cable becomes disconnected or broken, or should the gap in the spark plug be too great, then the secondary current has no path open to it, and endeavoring to find a ground will sometimes puncture the insulation of the armature of the coil. To obviate this, a so-called safety spark gap is placed on the top of the armature dust cover. It consists of projections of brass with a gap between them. One of these is an integral part of the dust cover, and therefore forms a ground. The other brass part is connected with the terminal H M and the secondary current will jump across the intervening gap above mentioned, thus protecting the armature secondary winding and the high tension insulations.

In the coil, this safety gap is placed at one end of the core, and hence is not visible. It consists of a pointed brass finger, attached to one end of the secondary, and pointing towards the iron core of the coil.

The contact points may be cleaned with gasoline until the contact surface appears quite white, or use a fine file, but very carefully, so that the surfaces remain square to each other. The gap at the contact points should not amount to more than 1/64 inch and, as the contacts

wear away in time, they must be regulated now and then by giving the screw a forward turn, or eventually by renewing. When this platinum tipped screw is adjusted, care must be taken that the lock-nut is securely tightened in place. By loosening the center screw, the whole interrupting mechanism may be taken out, so that the replacement of the platinum contacts without removing the apparatus can be easily done at any time. The fixing screw of the make-andbreak is held fast by a lock spring, so that it is impossible for this screw to loosen. When it is desired to remove this screw, the lock spring must first be removed by turning it over the head of the screw. Do not forget to put the spring in the original position after having fixed the make-and-break to the armature.



Automatic Advance Mechanism of Eisemann Magneto

The Eisemann automatic advance, Fig. 200, is accomplished by the action of centrifugal force on a pair of weights A attached at one end to a sleeve B, through which runs the shaft C of the magneto, and hinged at the other end to the armature.

Along the armature shaft arm run two spiral ridges which engage with similarly shaped splines in the sleeve. When the armature is rotated the weights begin to spread and exert a longitudinal pull on the sleeve which in turning changes the position of the armature with reference to the pole pieces. In this way the moment of greatest current is advanced or retarded, and with it the break in the primary circuit, for the segments which lift the circuit breaker and cause the break in the primary circuit are fixed in the correct position and thus the break can only occur at the moment when the current in the winding is strongest. On magnetos without this advance it is the segments which are moved forward or back, as the case may be. As there is only one actually correct position for the segments, every degree away from this weakens the spark.

The spreading of the weights rotates the armature forward, and advances the spark and the resumption, either total or in part, of their original position close to the shaft, retards it by rotating the armature backward.

As the timing is accomplished by changing the relative positions of armature and motor and not those of the segments in the timing level which cause the breaking of the circuit, the spark is always bound to occur at the moment of greatest current and the apparatus thus given as strong a spark at retard as when fully advanced.

444 The Automobile Handbook

As the speed becomes slower a spring D brings the weights together again, so that by the time the motor has come to rest the magneto is fully retarded, this being the correct position for starting.




Fig. 201 Magneto Used on the Ford Cars

In the rear end of the governor housing there is a transverse slot into which fits a key, fur-

nished with each magneto. When this key is shoved in as far as it can go the armature is fixed in the position where the platinum contacts begin to open. The shaft is held tight in the correct position and the coupling may be screwed up with the assurance that the magneto is correctly set and without danger of damaging the armature.

Ford Magneto. The Ford magneto, Fig. 201, is of a peculiar design, it being constructed as an integral part of the flywheel, in which A is the support for the magneto coils; BBB, magneto coils; CC, permanent horseshoe magnets; DD, the flywheel; E, planetary pinions; F, low speed brake band; G, reverse brake band; H, disc-clutch for high speed; I, transmission




Fig. 202 Flg. 20 Details of Ford Magneto

brake; J, clutch rocker shaft, and K, high speed clutch spring. The permanent magnets, which are U-shaped, are bolted to the forward face of the flywheel, as shown in Fig. 202. Close in front of their outer ends is a series of insulated coils mounted in a circle of practically full flywheel diameter, with their axes parallel with that of the crankshaft. They are supported upon a stationary spider, as shown in Fig. 203. As the flywheel revolves, this magnet and coil combination, which is similar to that used on some

types of alternating current generators, produces a current which is used through a four-unit current timer to cause the ignition spark. The magneto is of the inductor type, the armature coils being stationary, and the field magnets moved past them. Sixteen separate field magnets are used, made of vanadium-tungsten steel. They are substantially horseshoe shape, being secured to the side of the flywheel as illustrated in Fig. 203. They are held in place by screws at their middle, and by clamps near their poles, all screws used for fastening them being securely locked in place by wire locks.

The magnets are so arranged that like poles are adjacent to each other, forming a six-teen pole field magnet crown. Instead of being placed close against the flywheel, these magnets are clamped against a ring of non-magnetic material (brass for instance), in order to reduce leakage of magnetism through the flywheel rim. At their middle these magnets are fastened directly to the flywheel, as at this point they are neutral, and there can be no leakage. A series of sixteen armature coils is carried on a coil supporting ring slightly in front of the flywheel, as shown in Fig. 202. These coils are wound with heavily insulated magnet wire, and are so grouped around the supporting ring that the winding of adjacent coils is in different directions, one being wound clockwise, and the next one counter clockwise. The coils are connected in series, the terminals being brought

out near the top of the casing. As the poles of the magnets are located opposite and very close to the coils, the magnetic circuits are completed by the cores of these coils and the coil support. There are evidently sixteen electrical impulses produced during the revolution of the crankshaft and flywheel, although only two impulses are required for the ignition of the motor, one per stroke. However, as the armature circuit is closed only when a spark is wanted,




Fig. 204 Herz Magneta

a current only flows at that period, and there is no loss from the other impulses.

HERZ HIGH TENSION MAGNETO. This magneto differs from the regular conventional type in that it is cylindrical in shape, due to the employment of ring-shaped field magnets A—Fig. 204—instead of the horseshoe type generally adopted. The six Herz magnets are in reality as many flat steel rings clamped together with a polar space, or armature tunnel, C, cut in

he ring surfaces are ground with the accuracy in order to obtain the best effect when they are all clamped to-These magnets are mounted on an a base S. A second unconventional-




Fig. 205 Herz Make-and-Break and Armatur

at the usual independent, soft-metal es, which bolt to the ends of the horsenets in the conventional magneto, are I with entirely. In the Herz system C, which accommodates the armature,

is bored out from the magnets A, and in this manner sharp angles in the magnet system, which invariably result in a leakage of lines of force in the magneto, are avoided. The armature D, Fig. 205, is of shuttle shape, accommodating the low, and high-tension windings E within the frame portion of it. So careful has the construction of this armature been superintended that there is but 1-10-millimeter air space between it and the curved portions of the magnets A. The armature revolves on ballbearings, mounted in special cages, and is fitted with lubricating means sufficient for many months' use. The armature windings consist of a primary winding, in which is generated the low-tension current and also a secondary winding in which is generated the induced, or hightension circuit. At one end of the armature, and encased in a brass box, is the condenser, F, Fig. 205.

The make-and-break devices for interrupting the primary circuit are illustrated in Fig. 205, the entire device being a detachable unit, which secures to the armature shaft by a key-way and feather. This make-and-break mechanism contacts with one end of the primary winding of the armature through a small carbon brush, fitted into the contact disk, which presses against a ring alongside of the ball race on the armature. The contact device consists of three parts: First, a curved spring G, having a platinum flat contact on one end; a steel block H

carrying an adjustable platinum contact, and a small, hard-fiber roller K carried on a pin. This roller is set so that if it is given a slight push at the edge it tends to move up the incline plane formed by the steel piece H, and in doing so pushes against the end of the spring G and separates the platinum contacts L. This




Fig. 206 Herz Magneto Advance

contact-maker revolves bodily with the armature, and in its rotation the fiber roller K strikes upon two steel projections M—Fig. 206—held in the case, thus breaking the circuit at the points of maximum induction twice in each revolution, at which time the induced current is set up in the secondary winding of the magneto.

It is scarcely necessary to comment here that

the primary and secondary windings are oughly insulated from each other, and with the making and breaking of the princurrent an induced current is set up in the ondary winding, which because of the r turns of wire in this winding, is of a par larly high voltage. For cutting off the s when desired a terminal is provided on the tact-maker case, which gives a connection means of a spring pressing on the head




Fig. 207 High-Tension End

end of the primary winding, which thus be short-circuited at will. In advancing retarding the spark, connections are made the ball ending N, Fig. 206, the contact-m having a 30-degree movement for this pur. The high-tension end of the armature mounted upon it a deeply recessed insula collar, with a metallic sector within it. It this sector are small carbon brushes for d


ing off the high-tension current. In Fig. 207 appears a magneto suitable for a two-cylinder engine with its high-tension terminals R located at 90 degrees to each other. To obtain the two sparks the high-tension contact piece, orsector is fitted with an insulating collar, which does not go quite half way round, and thus makes alternate contact with the two carbon brushes R, sending the spark to the respective cylinder. In four-cylinders a distributer is combined. The safety spark gap is located between the high-voltage sector and the armature, and if the spark exceeds \% inch it bridges the insulating collar to the armature.

MEA MAGNETO. The most noticeable difference between the Mea magneto and other standard forms is that the magnets are bell-shaped and are placed horizontally and with their axes in line with the armature shaft. This is a distinct variation from the customary horseshoe magnets placed at right angles. This makes possible the simultaneous movement of the magnets and breaker instead of the advance and retard of the breaker alone.

It will be seen that, as a result of this construction, the relative position of armature and field at the moment of sparking is absolutely maintained, and the same quality of spark is therefore produced, no matter what the timing may be.

Fig. 208 shows a longitudinal section of a four-cylinder instrument. In the bell-shaped

magnet 100, having the poles on a horizontal line near the driven end of the magneto, rotates armature 1 in ball bearings 17 and 18. The armature consists mainly of an I-shaped iron core, mounted on a spindle, and wound with a heavy primary winding of a few turns and a light secondary winding of many turns. On this armature are also mounted the condenser 12, the collector ring 4, and the low-tension



breaker 26-39. The latter is built up of a disc 27, which carries the short platinum contact 33; the other contact point 34 is adjustable and supported by a spring 20, which in turn is fastened to the insulated plate 28 mounted on disc 27. The breaker is actuated by the fibre roller

31 in connection with cam disc 40, which is provided with two cams and located inside the breaker, being fastened to the field structure. In revolving with the armature the roller presses against the spring supported part of the breaker whenever it rolls over the two cams and in this manner opens the breaker twice every revolution. Inspection of the breaker points is made possible by means of an opening in the side of the breaker box, provided at the point of the circumference at which the breaker opens. The box is closed by a cover 74, supporting at its center the carbon holder 47, by means of which the carbon 46 is pressed against screw 24. This latter screw connects with one end of the low tension winding, while the other end is connected to the core of the armature. It will, therefore, be seen that the breaker ordinarily short-circuits the low tension winding and that this short-circuit is broken only when the breaker opens; it will also be apparent that when the screw 24 is grounded through terminal 50 and the low-tension switch to which it is connected, the low-tension winding remains permanently short-circuited, so that the magneto will not spark. The entire breaker can be removed by loosening screw 24.

The high tension current is collected from collector ring 4 by means of brush 77 and brush holder 76, which are supported by a removable cover 91, which also supports the low tension grounding brush 78 provided to relieve the ball

bearing of all current which might be injurious. Cover 91 also carries the safety cap 89, which protects the armature from excessive voltages in case the magneto becomes disconnected from the spark plugs.

The distributer consists of the stationary part 70 and the rotating part 66, which is driven from the armature shaft through steel and bronze gears 7 and 72. The current reaches this distributer from carbon 77 through bridge 84 and carbon 69. It is conducted to brushes 68 placed at right angles to each other and making contact alternately with four contact plates embedded in part 70. These plates are connected to contact holes in the top of the distributer, into which the terminals of cables leading to the different cylinders are placed.

In the front plate of the magneto is provided a small window, behind which appear numbers engraved on the distributer gear which correspond to the numbers marked on the top of the distributer. This indicator allows a setting or resetting after taking out, without the necessity of opening up the magneto to find out where the distributer makes contact. Numbers on indicator and distributer show the sequence of sparks, not the numbers of cylinders which the magneto is firing, as the sequence of firing varies with different motors.

The variation of timing is effected by turning the magneto proper in the stationary base which is accomplished through the spark lever connections attached to one of the side lugs. The spark is advanced by turning the magneto in the direction of the rotation of the armature.

If the magneto is defective, the trouble will usually be located in the breaker. The platinum contacts burn off in time and a readjustment becomes necessary, although this should be the case only at very long intervals. The adjustment should be such that the breaker begins to open with the armature in the position of greatest current flow, and that the distance between contact points when fully open is about 1/64 inch or slightly more. The small gauge attached to the magneto wrench may be used for checking this adjustment. The small lock nut of the contact screw must be tightened securely after each readjustment of the contacts.

In addition any oil or dirt reaching the contact points will in time form a fine film which prevents perfect short-circuit of the low-tension winding. If the condition of these points is very bad, or if a complete inspection of the breaker is desired, the latter should be removed from the breaker box. This can readily be done by loosening the long center screw holding the breaker to the armature, and screwing it into the small tapped hole provided in the breaker, so that it may be used as a handle in lifting the breaker out. The cleaning of the points should be done with a fine crocus paper, or if necessary, with a very fine file, after which a

piece of very fine cloth should be passed through between the points so as to remove all sand or filings. Special care must be taken not to round off the edges of the contact points; the satisfactory operation of a magneto depends largely upon the perfect contact at this point, and the whole surface of the contacts should therefore touch.




Fig. 209 Inductor Magneto Shaft

REMY INDUCTOR Magneto. This type of magneto, now so extensively used for ignition purposes, is a comparatively recent product, the result of many years of experiment and development. The principles of its action are as follows: By revolving a solid steel shaft on which are two drop-forged steel magnet inductor wings, as shown in Fig. 209, the magnetic field is

versed twice during each revolution, and eates two electrical current waves, or imless per revolution. The direction of flow the magnetic current is changed at each imlee, thereby generating an alternating curt. A circular shaped stationary winding of agnet wire is imbedded between the poles of




Fig. 210 Distributor for Inductor Type

e magnets and around the inductor shaft, d a strong current is generated in it and cared directly through the circuit breaking dece by means of heavy lead wires, thus disnsing with the use of carbon brushes and cotctor rings.

There are no revolving windings nor movg contacts, and consequently many sources of trouble are eliminated. The current is carried to the transformer coil located on the dash-board, where it is stepped up to the high voltage necessary for creating the hot jump-spark.

From the transformer the current is conducted back to a hard rubber distributer, see




Fig. 211 Longitudinal Section Through Inductor Type of Magneto

Fig. 210, on the face of the magneto, and from thence to the spark plugs. The distributer shaft, located immediately above the inductor, revolves a metallic segment past the terminals of the wires leading to the spark plugs. The high tension current is carried to this segment, and transmitted to the spark plug. A magneto

this type, and gear-driven, gives what may perly be called perfect timing. A hot spark delivered in the cylinder under compression the exact instant desired.

The device is also reliable for starting the tor from the seat without cranking, for the son that the motor always stops with the gneto in such a position that the first spark I occur in the cylinder under compression I where batteries are used a push button is vided, which by merely touching will crethe spark where needed. Fig. 211 shows a tional view of the magneto.

In important difference between the Remy gneto just described and other models of the uctor type is in the handling of the inductor ghts. In models "RD" and "RL," each uctor wing has been balanced by a bronze ght fastened to the magneto shaft and on opposite side of the shaft from the wing t it compensates for. The weight, being de of non-magnetic material, does not in any v affect the operation of the magneto electedly.

The inductor principle is not used in later dels of the Remy magneto, this feature being laced by an armature of the shuttle type h a single low-tension winding. A sepaely mounted transformer coil is used with se instruments, this coil carrying a switch t allows use of the current from the magneto nature or from a set of dry cells or storage

battery, the current, from whichever sour passing though the same breaker, coil, distrittor and plugs.

The breaker of the new models is composed a steel cam mounted upon and turning with t armature shaft and which strikes against contact piece in a pivoted arm that carries o of the contacts of the breaker. Except for t





Fig. 212 Breaker Mechanism of Remy "RD" Magneto


movement required in altering the time of t spark, the contacts and the pivoted arm rems stationary, the cam being the only revolvi part of the breaker mechanism. The condens that is attached between the breaker contacts carried in a housing that is mounted above t magneto armature and between the magnet less See Fig. 212.

A device, known as a timing button, is incorporated on the Models "P," "30," "31" and



"32" Remy magnetos, for the purpose of timing the magneto in connection with the engine.

To set the magneto turn the engine crankshaft until the piston of No. 1 cylinder is at top cen-



ter after the compression stroke. Press in on the timing button at the top of the distributor turn the magneto shaft until the timing butis felt to drop into the recess on the disiter gear. With the magneto in this posimake the coupling with the engine without
ng any attention to the position of the
ker cam. The location of the distributer
inal for the plug in No. 1 cylinder is deterid by the direction of rotation of the mag-

If the magneto runs clockwise, No. 1 teril is at the lower left hand corner of the disiter, while for anti-clockwise drive No. 1 inal is at the lower right hand corner. The ig for the Models "P" and "32" is shown 'ig. 213, while the connections for Models 'and "31" are shown in Fig. 214.


MMS MAGNETO. The armature is of the true -tension type, on which is wound both the ension primary and high-tension secondary lings, connected in series. The magneto rates a high-tension current directly in the ture, and does not use an exterior coil or device to step-up or transform the cur-

safety spark gap is provided to prevent age to the magneto, in the event of one or of the high-tension cables becoming disected from the spark plugs. This gap is ocated that its action may be readily obed for the purpose of locating the cause of ible misfiring.

ne model "S U D" consists of a dual system hich is provided a small non-vibrating coil

which can be either attached to the fra dash of car, as the coil is unaffected by moisture or heat.

The switch operating the battery circui connection with the starting switch and the starting pedal is depressed (thereby ing the starting motor into operation) the rent flows through the switch coil and ma



Magnets and Extended Pole Pieces of Siz Magneto

As soon as the engine starts, or the stapedal is released, the circuit is automated disconnected, and the engine runs on the neto. One of the principal features of Simms magneto is the extended pole shoe, at in Fig. 215.

To time the magneto to engine: Turn the engine over by the starting crank until No. 1 piston reaches top dead center on compression or firing stroke. Remove the dust cover, or if a dual magneto, the commutator, and turn the armature shaft until the figure 1 appears in the "sight-hole" of distributor, Fig. 216. This shows that that distributor brush is in contact




Fig. 216
 Simms High Tension Magneto

with distributor post 1. Retard the contact breaker and move the armature, either to the right or left, as occasion requires, until the platinum points just break, or, in other words, just separate. With the magneto in this position couple it to the engine (to dead center on compression stroke), and connect the remaining terminals up in the proper firing order of the engine.

For timing the model S U D, proceed as above. The above instructions relative to engine position apply also in this instance. The only change is as follows:

For locating the position of the carbon brush on No. 1 distributer segment, remove the distributer, which is held in place by means of two spring clips, and turn the armature shaft until the distributer brush is brought into position, namely, opposite No. 1 segment.

If the magneto is not firing, try the following test. While the motor is running, disconnect one of the high tension cables from spark plug, being careful not to touch the metal terminal, and hold the cable with the terminal close, about ½" to 3/16", to any part of the motor. This will show the strength of the spark and each cable may be tested in turn. If the magneto is not delivering a good spark, examine the contact breaker. The break or gap between the platinum points, when open due to the cam action, should correspond to the thickness of the gauge furnished, which is approximately .015.

Splitdorf Magneto. The system used in older models is that having an armature with but one winding, and giving a current of comparatively low tension. The current is discharged through a transformer having a low and a high-tension winding somewhat similar to regular

spark coil. This steps the current up to a voltage sufficiently high to enable it to jump the necessary gap between the points of a spark plug in the compressed mixture in the cylinder of the motor.

The plain H, or shuttle, armature is mounted between two annular ball bearings, Fig. 217. One end of the shaft is the driving end and the other is equipped with the breaker cam and the





Fig. 217 Section Through Splitdorf Magneto

insulation plug which delivers the current generated in the armature to the collector brushes from which it is transmitted to the transformer connection.

From A, Fig. 218, the armature current goes through the primary of the transformer, returning through the binding post No. 2 to the contact screw bracket on the breaker box. No. 3 is a common ground connection for both the magneto and transformer. The circuit being broken


at the proper moment, a very high voltage current is induced in the secondary winding of the transformer, and being delivered to the heavily insulated cable D, is conducted to the central brush of the distributor, whence it is delivered to the spark plugs in the different cylinders in correct sequence.



Wiring of Model "S" Splitdorf Magneto


In addition to using the current from the magneto, the transformer may be used as a spark coil by using the breaker mechanism of the magneto in the circuit to interrupt a current from the battery, which can be switched in for starting purposes or for an emergency. The distributor is used to deliver the current thus generated to the spark plugs. This gives a dual system with one set of spark plugs, and the movement of the switch controls both systems. Fig. 219.

A later development is the new standard "T S" type of transformer, Fig. 220, which has practically superseded all other types, par-



Wiring of Splitdorf Magneto With Transformer Coil

ticularly as it does away with the separate switch and still leaves the dash free. Both leads from the battery must run direct to transformer.



Wiring of Splitdorf Magneto With Tubular Coil

After securing the magneto to the prepared base on the motor, crank it until cylinder No. 1 is exactly on its firing center (i. e., the point of greatest compression. The motor must remain in this position until the balance of the work is finished.

Retard the spark advance mechanism at the steering wheel to its limit and connect it to the spark advance lever on the breaker box of the magneto, so that if the magneto shaft revolves in a clockwise direction looking at the driving end, the breaker box lever will be at its topmost position. If the shaft revolves left-handed the lever should be at the bottom limit, and advanced upward.

Now revolve the armature shaft in its direction of rotation until the oval breaker cam comes in contact with the roller in the breaker bar and begins to separate the platinum contacts.

If it is desired to start on the magneto side, ignoring the battery entirely, advance the spark mechanism about one-half or two-thirds of the way and crank as before. No back kick should be observed. Do not drive the motor with the spark retarded, but as far advanced as the motor will permit.

If the platinum contacts after much usage become pitted so that a bad contact results, they can be filed flat with a fine file, taking care not to file off any more than is necessary. Then reset the screw so that the break is not more than .025 of an inch.

Don't forget to occasionally brush the distributer disc and interior of distributer block clean of any accumulation of carbon dust.

The "E U" magneto is a new high tension machine designed for four cylinder motors developing as high as 40 horse power.

The construction of this magneto embodies an aluminum base to which the pole pieces are secured, and between which revolves an armature on two annular ball bearings. The circuit breaker is attached to one end of the armature shaft and revolves with it. The magneto is self-contained, having both a primary and secondary winding on the armature.

The high tension winding of the armature is connected to a collector ring, imbedded in a spool mounted on the driving end of the armature shaft. From this ring a carbon brush leads the current through a water-proof holder to the center of the distributer disc.

The cam holder may be shifted to the extent of 30 degrees, enabling an advance or retard of the spark to be obtained, thereby causing ignition to take place earlier or later.

The condenser necessary for the protection of the platinum points and the proper functioning of the machine is placed in the driving head of the armature and revolves with it.

The distributer consists of a disc of insulating material having a metal segment to which the high tension current is led from the collector brush. The distributer block has four small

carbon pencil brushes which lead the current the brass connection imbedded in the block, which the plug wires are fastened. The postion of the segment on the disc can be see through the little window in the face of the distributer block for the purpose of setting the machine when timing.

A spark gap for the protection of the arms ture winding is located at the inside end of the brush holder under the magnets.

The main bearings of the magneto are provided with oil cups, and a few drops of light oil every 1,000 miles are sufficient to lubricate them. The breaker arm should be lubricate with a drop of light oil applied with a toothpic to the hole in the bronze bearing pivoted of the steel pin. The cams are lubricated by a fer packing, and a little oil applied to the holes if the edge of the cams will last a long time; and surplus oil should be removed and care take to prevent any oil getting on the platinum points.

The proper distance between the platinu points when separated should be .020 or 1/50 an inch. A bronze gauge of the proper size attached to the wrench furnished for the adjustment of the platinum screw and lock nut.

The fibre roller on the end of the breaker ar is held in position by a pawl spring. The weating surface of the roller may be renewed I rotating the same a quarter turn, thus bringing a new surface to bear on the cam, and as the

are four slots in the roller four wearing surfaces are available.

To time the magneto, rotate the crank shaft so as to bring the piston No. 1 cylinder 1/16 of an inch ahead of the upper dead center of the compression stroke. With the timing lever fully retarted, the platinum points of the circuit breaker should be about to separate. Some motors may require an earlier setting.

The distributor segment should show in the little window in the block and the plug wire to No. 1 cylinder should be fastened under the brass nut directly over the segment. The rest of the plug wires should be fastened in turn according to the proper sequence of firing of the cylinders to which they lead.

U AND H MAGNETO. The particular feature of this magneto, is that the starting spark is a maximum, whether the crank is turned slowly or fast.

In the operation of the U and H magneto, Fig. 221, a low-tension current of electricity is generated by the rotation of the armature of the magneto. An interrupter, or timer, interrupts the flow of this low-tension current at the proper time, this interruption causing a high-tension current, similar to that delivered by the induction coil of a battery ignition system, to be induced in the rotating armature by a peculiar arrangement of the windings of the armature. The high-tension current is conducted to a so-called distributer, the duty of which is to

distribute the high-tension current to the spark plugs of the various cylinders in the proper sequence of firing. The wiring diagram of the U and H magneto is shown in Fig. 222.





Fig. 221 U. & H. Magneto

The magneto consists of three pairs of permanent horseshoe magnets, placed parallel, and having secured to each of their free ends a soft iron block. These blocks are exactly

ike, and form a permanent magnetic field.

ney are bored so as to allow an armature to volve between them. The armature is of the uttle type, and is provided with a double




inding. The inner or primary winding consts of a few layers of coarse insulated wire. ne outer or secondary winding consists of a reat number of layers of fine insulated wire. he beginning of the primary winding is

grounded to the armature itself. The end the primary winding is connected with carbon brush 1, which is carefully insulat from the armature shaft. Brush 1 bears again the interrupter block screw 2, which in tu conducts the current to the interrupter block and to the condenser plate 4. From the int rupter block 3 the current is conducted means of the platinum pointed interrupter co tact screw 5 to the platinum contact on 1 interrupter lever 6. The interrupter lever has metallic contact with the body of the ma neto, and is therefore grounded and in el trical connection with the beginning of the p mary winding. It will be seen that when t interrupter lever 6 is in contact with interru ter contact screw 5, the primary circuit closed, and the primary winding of the arr ture is short-circuited.

The beginning of the secondary winding connected to the end of the primary winding being in fact a continuation of the prima winding. This fact should be borne in minas it has direct bearing upon the results tained with this magneto. The end of the sondary winding is connected to the armat slip ring 7, which is thoroughly insulated from the armature. From the armature slip ring the current is conducted by means of brushes 8-8 to the distributer slip ring 9, from whence it is led to the distributer brush 10 means of the distributer brush spring seat

The distributer plate 13 is provided with as many brass distributer segments 14, evenly spaced around the distributer bore, as there are cylinders to be fired, and as the distributer brush is revolved it comes into contact in succession with the segments. These segments are in turn connected with the secondary terminals 15, located at the top of the distributer plate, one terminal for each cylinder. From these terminals the high tension current is conducted



U. & H. Magneto Interrupter

by cables to the spark plugs of the cylinders, from whence, after jumping the gap it is conducted to the grounded end of the primary coil, through the primary coil to the beginning of the secondary winding, thus completing the secondary or high tension circuit.

U AND H INTERRUPTER. The interruption of the primary circuit is accomplished by the interrupter, as shown in Fig. 223. This device consists of the interrupter plate 16, which is located in the interrupter 17. Attached to the interrupter plate 16 is a stud 18, upon which is pivoted the interrupter lever 6. The interrupter lever is provided with a platinum pointed contact screw 19, which is normally held by the flat spring 20 in contact with the platinum pointed interrupter contact screw 5. The interrupter contact screw 5 is connected to the end of the primary winding, as already described.

Keyed to the interrupter end of the armature shaft, and rotating positively with the armature, is the interrupter cam housing 21. Securely attached to the interrupter cam housing is the interrupter cam 22, consisting of a ring of hard fiber, having on its inner face two projections or cam faces 22A.

The interrupter housing 17 is held in accurate alignment with the interrupter cam 22 by the construction of the rear end plate 23, and as the armature revolves the projections 22A-22A are brought into contact with the interrupter cam pin 24, causing a movement of the interrupter lever 6 sufficient to separate the contact screws 5-19, and thereby interrupt the primary circuit twice in every revolution. As the projections 22A continue to revolve, the interrupter lever 6 instantly resumes its normal position, and completes the primary circuit. The entire housing of the interrupter is easily removed for inspection, or adjustment by pushing the spring clip 31 to either side.

Induction Coil. The form of coil generally used on gasoline cars is known as the jump-spark coil. It is of two types, one known as a plain or single jump-spark, the other as a vibrator or trembler coil.

A jump-spark coil consists essentially of a bundle of soft iron wire, known as the core, over which are wound several layers of coarse or large size insulated copper wire, called the primary winding. Over this are again wound a great many thousand turns of very fine or small wire, known as the secondary winding.


Inertia. Inertia is that property of a body by which it tends to continue in the state of rest or motion in which it may be placed, until acted upon by some force. As used by the non-technical, it is almost universally employed in the former sense, i. e., that of the resistance which a body offers against a change in its position, an inert body usually being intended, so that the definition is perfectly correct so far as it goes. The popular impression is that only inert bodies have inertia, it being likewise generally thought that a moving body is possessed of momentum alone, whereas an object at rest is possessed of inertia, and the same object in movement has both momentum and inertia.

Insulating Material. Asbestos, lava, and mica are severally used for the insulation of spark plugs and sparking devices.

Vulcanized fiber or hard rubber or even hard wood are used for the bases of switches, connection boards and other places.


India rubber, or gutta-percha form the of the insulated covering of wires used for trical purposes. The coils of small magnets the cores of induction coils are usually with cotton covered wire, or in some instathe fine wire is silk covered, as in the cas secondary or jump-spark coils.

Joints, Ball and Socket. To produce a flex joint capable of operation within certain tations in any direction, the ball and so form of joint is generally used on the end the rod which connects the arm of the steemechanism with the steering lever attache the hub of one of the steering pivots of front axle.



Joints, Compensating. On account of distortion of the frame or running gear o

automobile, due to unequal spring deflection and irregularities of the road surface, means should be provided to insure flexible joints or connections between the various rotating parts of the mechanism of a car. The device shown in Figure 224 is not susceptible to any great amount of angular distortion, but will transmit power with a practically uniform velocity, with the axes of the shafts considerably out of align-



ment in vertical or horizontal parallel planes.

The form of compensating joint shown in Figure 226 may be operated with the axes of the shafts at an angle to each other, or with the shafts out of alignment with each other in vertical or horizontal parallel planes, and has quite a range of operation with either condition. Both





Fig. 226

forms of the device require to have bearings on either side, as shown, to insure their proper working.






Fig. 228

Joints, Knuckle. Swivel or knuckle-joints for connecting the steering arm of the wheel, or lever steering mechanism to the arms on the knuckle-joints of the steering wheels are of various forms. Figures 225 and 227 show knuckle-joints which may be used for the above purpose. They are of simple construction and practically inexpensive to make. They may be used with any standard drop-forged jaw-ends.

Joint-Universal. The elementary form of a universal-joint or flexible coupling consists of a spiral spring. Such a form of universal-joint is sometimes used to drive a rotary pump, or a small generator on a car. The rear wheels or axle of a car are sometimes driven by means of a longitudinal shaft with a quarter-turn drive on a counter shaft, or a bevel gear drive attached to the differential gear of the rear axle. In such cases some form of universal-joint is necessary to allow the rear wheels and axle to accommodate themselves to the inequalities of the road surface. Three forms of universaljoints are shown in Figure 228. The upper view in the drawings shows the form most generally used on motor-cars, for the purposes just described. The one shown in the center view will allow a greater amount of angular distortion than the form shown in the upper view, but is of a more expensive construction. Where only a slight amount of angular distortion is needed, the construction shown in the lower figure in the drawing is very suitable, the two jaws or

knuckles of the joint being flexibly attached by means of a plate of spring steel.

A form of universal joint, or flexible coupling, of recent introduction, is that making use of leather or other flexible material securely fastened to two forked members in such a way that with the members placed at an angle to each other, power is delivered from one to the other through the flexible material that is fastened to both of them.

Large powers are transmitted in this way by using a ring of heavy material similar to tire fabric and fastening the couplings of the two shafts to this ring at alternate positions by secure fastenings and bolts. The difference in alignment is taken care of by the ring of flexible material, and it has been found that this form of drive is quite free from trouble, and, of course, requires neither lubrication or covering against dust and dirt.

Kerosene as a Fuel. Kerosene has been used as an explosive power, and crude petroleum is gaining favor as an efficient liquid fuel. With a specific gravity varying from 0.78 to 0.82, and a vapor flashing point at 120 to 125 degrees Fahr., kerosene ignites at 135 degrees Fahr., and boils at 400 degrees Fahr. Its vapor is five times heavier than air, and requires 76 cubic feet of air to one cubic foot of vapor for its combustion, giving 22,000 heat units per pound, or 4,000 more than gasoline.

KEROSENE AS A CLEANSING AGENT. Kerosene

injected into a motor cylinder and allowed to remain over night will remove all deposit from the piston head. It should then be blown out through the relief-cock or the exhaust-valve.

Knight Engine. See Engine, Knight.

Knocking-Locating Cause of. Tracing a knock is sometimes a puzzling job. It may be in one of the main bearings of the engine, in the camshaft bearings, in a loose valve lifter, in a loose camshaft gear key, in a loose pump or magneto drive coupling, an unsuspected loose bolt between two parts supposed to be fast, or in any of a dozen, or score of other unsuspected places. A valuable aid in locating a mysterious knock is a flexible speaking tube such as is used with phonographs. One end of such a tube can be held to the ear and the other moved about from point to point until the exact spot is found where the noise is loudest. Another aid is a light bar of iron, one end of which is pressed against the part where the knock is suspected and the other touched to the forehead or the teeth, when the sound is clearly transmitted.

Knocking or pounding is an inevitable warning that something is wrong with a motor. It may be due to any of the following causes:

Premature ignition: The sound produced by premature ignition may be described as a deep, heavy pound.

Using a poor grade of lubricating oil will cause premature ignition. The carbon from the

oil will deposit on the head of the piston in cakes and lumps, and will not only increase the compression, but will get hot after running a short time and will ignite the charge too early, and thereby produce the same effect as advancing the spark too much. If this is the cause the pounding will cease as soon as the carbon deposit is removed from the combustion chamber.

Badly worn or broken piston-rings.

Improper valve seating.

A badly worn piston.

Piston striking some projecting point in the combustion chamber.

A loose wrist-pin in the piston.

A loose journal-box cap or lock-nut.

A broken spoke or web in the flywheel.

Flywheel loose on its shaft.

If the spark plug be placed so as to be exactly in the center of the combustion space, an objectionable knock occurs, which has never been fully explained. In some motors it renders a particular position of the spark control lever unusable; this form of knock disappears either on making a slight advance or retardation of the ignition.

Explosions occurring during the exhaust or admission stroke. This is almost always due to a previous misfire, and it is prevented by stopping the misfires.

If the ignition is so timed that the gases reach their full explosion pressure during the compression stroke, that is, if the spark be unduly advanced when the motor is not running at a high speed, an ugly knock occurs, and great pressure is developed on the crank-pin bearing, wrist-pin, and connecting rod. The result may be the bending or distorting of the rod.

The crank-pin may not be at right angles to the connecting rod.

The bearings at either end of the connecting rod may be loose. A knock during the explosion stroke, and also at each reversal of the direction of the piston.

If the crank shaft is not perfectly at right angles to the connecting rod, the crank shaft and flywheel will travel sideways so as to strike the crank shaft bearings on one side or the other.

Lamps, Electric. The small incandescent lamps used for automobile lighting are almost invariably of the tungsten filament variety. Two types are in use, considered from the bulb standpoint, one of which exhausts the air from the bulb until a high degree of vacuum is secured, and the other one of which replaces the air with the inert gas, nitrogen. One is called the vacuum bulb and the other the nitrogen bulb. Two types of bulb base are in use, the single contact, in which one side of the circuit is secured through metal of the base, and the double contact with two insulated leads. Lamp bulbs vary in diameter from ¾ to 2-1/16 inches.

Lighting, see Starting and Lighting Systems.

Lubrication. To ensure easy running, and reduce the element of friction to a minimum it is absolutely necessary that all surfaces rubbing together should be supplied with oil or lubricating grease, but it is also a fact, not so well understood, that different kinds of lubricant are necessary to the different parts or mechanisms of a motor car.

As the cylinder of an explosive motor operates under a far higher temperature than is possible in a steam engine, consequently the oil intended for use in the motor cylinders must be of such quality that the point at which it will burn or carbonize from heat is as high as possible.

While a number of animal and vegetable oils have a flashing point, and yield a fire test sufficiently high to come within the above requirements, they all contain acids or other substances which have a harmful effect on the metal surfaces it is intended to lubricate.

LUBRICATING OILS. The qualities essential in a lubricating oil for use in motor cylinders include a flashing point of not less than 500 degrees Fahrenheit, and fire test of at least 600 degrees, together with a specific gravity of 25.8.

At 350 to 400 degrees Fahrenheit, lubricating oils are as fluid as kerosene, therefore the adjustment of the feed should be made when the lubricator and its contents are at their normal heat, which depends on its location in the car. Steam engine oils are unsuitable for the dry

heat of motor cylinders in which they are decomposed whilst the tar is deposited.

All oils will carbonize at 500 to 600 degrees Fahrenheit, but graphite is not affected by over 2,000 degrees Fahrenheit, which is the approximate temperature of the burning gases in an explosive motor. The cylinder of these motors may attain an average temperature of 300 to 400 degrees Fahrenheit. So that graphite would be very useful if it could be introduced into the motor cylinder without danger of clogging the valves, and could be fed uniformly. These difficulties have not yet been overcome. Graphite is chiefly useful for plain-bearings and chains.

The film of oil between a shaft and its bearing is under a pressure corresponding to the load on the bearing, and is drawn in against that pressure by the shaft. It might not be thought possible that the velocity of the shaft and the adhesion of the oil to the shaft could produce a sufficient pressure to support a heavy load, but the fact may be verified by drilling a hole in the bearing and attaching a pressure gauge.

Roller and ball-bearings provide spaces, in which, if the oil used contains any element of an oxidizing or gumming nature, a deposit or an adhesive film forms upon the sides of the chamber, the rollers or balls, and the axle. This deposit will add to the friction, hence it is the

more important to use a good oil, or a petroleum jelly in such bearings.

Air-cooled motors, being hotter than water-cooled, must have a different lubricant, or one capable of withstanding higher temperatures.

The effect upon animal or vegetable oils of such heat would be to partially decompose the oils into stearic acids and oleic acid and the conversion of these into pitch. Such oils are therefore inadmissible for air-cooled motor use.

Mineral oils are not so readily decomposed by heat, but at their boiling points they are converted into gas, and any oil, the boiling point of which is in the neighborhood of the working temperature of the motor cylinder, is useless, as its body is too greatly reduced to leave an effective working film of oil between the cylinder and the motor piston.

The essentials for the proper lubrication of air-cooled motors are:

That the oil should not decompose.

That it should not volatilize, as this will result in carbon deposits.

That its viscosity should be equal to that of a good steam engine oil at similar temperatures.


That it should be fluid enough to permit of its easy introduction into the cylinder.

That it will have no corrosive effect on the cylinders and no tendency to gum.

That it will not oxidize with exposure to air and light.

LUBRICATING DEVICES. Some makers of verti-

cal cylinder motors use the splash system, whereby oil fed by gravity from a tank above the level of the crank-case flows into the crank-case, whence it is splashed over the piston and the wrist and crank-shaft bearings. The large end of the connecting rod, which works in the crank-case, is made to dip or splash into a bath of oil. This lubricates the crank-pin. The splashing is invariably utilized to lubricate the cylinder by wetting the bottom of the piston



and splashing into the cylinder. A little ring is sometimes made in the crank-case, into which the oil collects and into which also the end of the piston dips.

Fig. 229 shows a vertical cylinder motor using splash lubrication.

The various methods of oiling outlined under Lubrication Systems should be noted, inasmuch as they give the principles by which any system may be classified. Practically all applications are modifications of one or the other.




Fig. 230

McCord Mechanical Oiler. A, Center Post. B, Worm Wheel. C, Drive Shaft. D, Plunger. E, Yoke. F, Cam. G, Plunger Spring. H, Adjusting Screw. I, Basket. J, Center Post Spring. K, Spring Guide. L, Spiger. M, Stuffing Pad. N, Stuffing Box. O, Gland Lock Nut. P, Stuffing Gland. Q, Bleeder Nut. R, Spider Lid Screw. S, Lid Screw. T, Lid Frame. U, Safety Ratchet. V, Oil Inlet Port.

The number of feeds used varies on the different cars from two to fourteen, depending upon the number of cylinders and bearings used on the engine. In a six-cylinder car, it is usual to find four feeds going to the crankshaft bearings, six to the cylinders, three to the crankcase, and one to the fan bearing.





Fig. 231 Hancock Mechanical Oiler

When mechanical oilers are used for lubricating the motor, the crank-case is usually divided into partitions, most of them dividing it into halves, one compartment for the two front cylinders and the other for the two rear cylinders. Sometimes three partitions, giving four compartments, are used. This arrangement gives one portion for each connecting rod. When this construction is used, the center partition will be found higher than the other two.

A force feed lubricator usually consists of an oil tank through which passes a shaft, which has a slow, but constant motion through mechanical connection with the engine. This shaft successively operates by means of cams, or otherwise, a series of small piston pumps, usually submerged in the oil, each pump feeding an oil tube. The piston displacement of each pump may be adjusted independently by changing the length of stroke so that any amount of oil desired may be delivered. Each pump stroke corresponds with a definite number of engine strokes.

In some systems of force feed lubrication the oilers are made without valves, double plungers being used to force oil to the sight feeds, and drawing positively from the sight feed and forcing to the delivery points.

The Hancock lubricator, Fig. 231, is of this type, and action is as follows: Worm A drives worm gear B and the shaft to which it is attached. On this shaft are two eccentrics C which impart a reciprocating motion to rod D carrying rocker arms E, and E'. To one end of these arms are fastened pistons F, and F'. The crank G is secured to the taper shaft H, and through connecting rod J a rocking motion is transmitted. This taper shaft H is provided with holes K, which on the suction stroke register with the openings L, and L', and the pistons, and on the forcing stroke with openings M, M, and the pistons. The arrows indicate the direction of flow of the oil to delivery points, the quantity being regulated by controlling the stroke of piston F through the lost motion allowed between the stop rod L and a ulating piece O. P is the regulating screw, a vided with a projection Q, which fits firmly a the upper end of piece O, forming a posalocking device. Shaft H is equipped at end with a spring R which holds it to its s



At the other end, washer S and two lock-nu and T' hold the shaft in its correct posit The shaft is thus allowed to run free in its grequiring but little power. Any number feeds from one to sixteen may be used to against pressure. In the Lavigne mechanoiler, Fig. 232, the pumps are without cl

valves, or springs of any kind. The plungers P, are raised and lowered by arms A attached to the drive shaft. On the up stroke a certain quantity of oil is drawn into each pump cylinder, and on the down stroke this quantity is discharged.

At the base of each plunger is an oscillating valve V, which, as illustrated, has the opening O ready for the up stroke, so that oil may be drawn from the reservoir into the plunger. Before the down stroke begins, the valve is oscillated by a cam device so that the entrance O is closed and the oil is directed through the lead L, which connects with the bearings. There is a time when the plunger L, is stationary at the top, and also at the bottom of the stroke, which is achieved by the cross head H, which raises and lowers the plunger. This cross head slides on the plunger until it contacts with a lower shoulder S and an upper one T. And during the period of no movement of the plunger the valve V is being oscillated to be ready to open the entrance O for intake stroke, and another passage for the expulsion stroke.

The Pierce-Arrow oiling system, Fig. 233, is partly positive, and partly gravity. The oil pump is positively driven from the engine, and pumps the oil from the crank chamber up into the reservoir located on the engine. Pipes lead from this reservoir to every crankshaft bearing, the flow to the bearings being by gravity under a head of twelve inches, which corre-

sponds to a pressure of about six ounces. The crankshaft bearings are drilled hollow, and in this way the crankpins and large ends of the connecting rods are lubricated. A gauge is usually placed on the dash to indicate the quantity of oil in the reservoir.

The Pierce system does not allow any oil to remain in the crankcase, the oil flying off the




Fig. 233
Pierce-Arrow Oiling System


crankpins being sufficient to lubricate the cylinders. As there is always a mist of oil flying around in the crankcase, it is known as the "mist" system.

As shown in Fig. 233 the oil supply is carried in a sump S beneath the crankcase, and the crankcase bottom is sloped towards the center so that oil falling in it is immediately

drained into the sump. The gear pump P, driven from the camshaft through a vertical shaft, elevates the oil to a tank T carried above the cylinder heads, and from this a lead L passes direct to each of the crankshaft bearings. From these bearings the oil passes through the drilled crankshaft to the lower bearings of the connecting rods, whence any overflow falls into the crankcase, or is thrown into the cylinders in the form of a mist through the slot in the baffle plate, closing the lower end of the cylinder to prevent an excess of oil getting on the walls. This mist not only cares for the cylinder walls, but also oils the wrist-pin bearing. The flow of the oil through the leads L from the tank to the bearings is regulated by thimbles M, inserted in the upper ends of the leads where they enter the oil tank, and in each thimble is a small opening which allows only a limited amount of oil to flow. The size of the openings in the thimbles is varied to suit the demand of the bearings for oil.


FLYWHEEL OILING SYSTEMS. In the Ford flywheel system of oiling illustrated in Fig. 234, the flywheel casing serves as an oil reservoir, and the rotation of the wheel throws the oil up into pockets, from whence it is conducted through pipes to the crank-case. The angle of the pipes is such that even on extreme grades there is sufficient drop to insure a flow of oil. A depression M is found in the crank case beneath each connecting rod, in order to limit

the amount of oil carried in the crankcase, and also to insure an even level of oil within the case.




Drilling Oil Passages in the Crank Shaff. Figs. 235 and 236 show two different methods of drilling the crankshaft to convey the oil to

the crankpins, and it will be noticed that the oil holes discharge at the highest point of the revolution, corresponding to the position of the piston at the beginning of the power or firing stroke. The supply is received by the main bearings from the oil pump and the oil hole in the shaft, coinciding with that from the oiler has a little oil forced in each revolution and, generating centrifugal force throws it rapidly through the passages. The majority of modern motors are equipped with splash lubrication and have the connecting rods dip into the oil



each revolution and splash it all over the inside of the crankcase. Some types are equipped with a scoop pointing in the direction of rotation, at the lower end of a passage connecting with the crank pin. The oil is sent into these passages with considerable force, owing to speed of rotation, thus assuring sufficient oil to the connecting rod bearings.

This is worked to the ends of the bearing and thrown off in the shape of a fine mist that penetrates to every part of the crankcase. The oil splashed onto the lower cylinder walls and not carried up by the piston is caught in little troughs, cast in the crankcase and drilled so that the oil runs down to the main bearings. In addition to the pipe from the oiler, the better designs provide an oil wick, or an oil ring or chain, all types carrying oil from a shallow pocket corded in the bearing cap, the wick by capillary attraction, and the ring or chain, revolving with the shaft, their lower ends immersed in the oil will carry up a considerable quantity that will spread over the shaft. This



oil ring system is used very successfully in electrical machinery. With a splash lubrication it is advisable to drain the crankcase at frequent intervals, and also to put in a fresh supply of cil.

Care should be exercised to select heavy oil for air-cooled engines or old engines, and a comparatively light oil for new cars.

CYLINDER OIL TESTING. There are really two parts to the fire test, as it is called. One is the test for flash point. This may be determined

as follows: Take two pieces of glass of the same size, and large enough to cover a small glass beaker. In one of them cut a couple of notches. These are for two purposes. One is for the thermometer and the other for the flash point determination. Insert a thermometer in the beaker, filled with the oil under test. Place the notched glass over this and the other piece of glass over that, taking care to cover the notch not in use. Now uncover this notch, note the temperature, and apply a lighted match to the opening. If nothing results, warm the oil slowly over a flame to a higher temperature and take another trial and reading. Continue the test until upon the application of the lighted match the oil vapor over the oil flashes. The thermometer reading at that point gives the flash point. The glass plates may now be removed, and heating continued. The match is applied at similar intervals, until finally the oil burns, which will usually occur at about 50 degrees above the flash point.

An additional test is for precipitation at a known temperature. This is also made in a beaker. Two ounces is the usual amount. It is heated to the desired temperature, at which the oil may change color, but must not show a precipitation. Still another good oil test is the evaporation test. This is the result of slow heating, and the usual specification is that the oil shall not lose over 5 per cent. of its volume when heated to 150 degrees Fahr. for 12 hours.

LUBRICATING SYSTEMS:

Full Force Feed. Oil is forced by pump pressure to the main bearings and, by means of drilled holes in crank webs, to crank pins and through hollow connecting rods, or oil pipes attached thereto, to the wrist pins. Oil returns to sump, or reservoir, and is circulated again.

Force Feed. Oil is forced by pump pressure, or the centrifugal force of the revolving flywheel, to main bearings and through drilled holes in crank webs to crank pins. The wrist pins and cylinder are supplied by oil thrown from connecting rods. The connecting rods do not dip. Oil returns to sump, or reservoir, and is circulated again.

Force Feed and Splash. Oil is forced by pump pressure, or the centrifugal force of the revolving flywheel, to the main bearings and through drilled holes in the crank webs, to crank pins. The oil from the main bearings falls to wells in the bottom of the crank case, or to adjustable troughs, into which the connecting rods dip and splash oil to all parts of the engine.

Splash. A constant level is maintained in the crank case by an overflow to the sump, or reservoir, below, whence the oil is circulated again.

Lubrication of Gears and Clutches. The modern ball-bearing gear box requires but little attention. Periodic filling with suitable lubricants is sufficient. On chain-driven cars the gears and differential are usually exposed by lifting one cover. On shaft-driven cars the

differential and rear axle system requires a certain amount of attention, as too much oil in the differential is liable to leak through the axle sleeve and hub, usually getting on the brake drums. If this happens, the best thing to do is to jack the wheel up and squirt gasoline on the drum, slowly revolving it meanwhile. Manufacturers usually put a plug in the differential case showing the proper height at which to keep the oil level. The gear box should be kept a little less than half full. If too much is put in, the oil will be thrown out of the shaft and bearing housings, but a little leakage does no harm as there is always dust present and the oil leaking will serve to fill the crevices and make the case dust-tight. In regard to the wheels, universal joints, clutch, and many little places about the car, all need attention occasionally as almost any motor car driver knows.

The wheels should be cleaned and packed with grease once or twice a season, universal joints at intervals necessarily shorter. Latest designs provide for their lubrication through the shaft from the gear box. Earlier types are best packed in grease and enclosed in a leather boot. On many shaft-driven cars, where the shaft runs through a sleeve, daily attention should be given. The lack of a few drops of oil may rob the car of 50 per cent of its power. Multiple disc clutches use oil, or an oil and kerosene mixture, and the tendency seems to be

for the oil to gum. Their action when slipping or dragging is sufficient indication as to when they are in need of attention. Leather-faced clutches will work much better when cleaned with kerosene and given a dose of neatsfoot or castor oil. The oil should be spread over the surface of the leather by using a long knife blade, or by running the motor for a few moments with the clutch released. When treating the clutch leather this way it is better to let it stand over night if possible, and with the emergency brake lever, or a block of wood against the pedal hold the clutch disengaged. A hand oil can with a long spout is almost indispensable, and the starting crank, the steering pivots and connections, and the spark and throttle connections, gear control and emergency brake levers, clutch and brake pedals. shafts and connections and the fan bearings will all work much quieter and sweeter for a few drops of oil regularly. It is the practice of drivers to fill the oil can from the cylinder oil supply and this practice is to be commended. as many lower grade oils contain acids enough to etch steel.

GEAR CASE AND REAR AXLE. It is a familiar fact that the gear case requires to be periodically emptied of oil, and the accumulated metal grit washed out before fresh oil is supplied. The same is true of the rear live axle casing, except that the gears in the axle do not clash and therefore do not wear out as fast as the change

speed gears. At least once in a season the oil in the rear axle should be drained out, a liberal supply of kerosene introduced, and the axle jacked up while the engine is run to agitate the oil and wash out the differential, etc.

Magnetic Gear Shift. The electric gear shift may be said to consist of two units, the "shifting assembly," or group of magnets attached to the transmission case, and the "selector-switch," or push-button group, located on the top of the steering column. The electrical current required to energize the magnets is derived from a storage battery, Fig. 237, ordinarily supplied as part of the starting and lighting systems on all cars.

The selector-switch is made up of a number of buttons, one for each speed, and one for the "neutral" which has not electrical connection. There is also a button for operating the horn. These buttons are provided with arched, laminated contacts of copper, backed up with a steel spring and insulated from the button proper. The top of the switch carries a locking-plate for locking any button which may be depressed and also carries an interlock, which makes it impossible to press down more than one button at a time. At the bottom is a hard rubber base, which carries a copper contact for each button and a contact common to all speeds. It also serves as a base for the return spring provided for each button.

The wiring, Fig. 238, consists of a lead pasing from each coil through a terminal block




Fig. 237
Action of the Magnetic Gear Shift

its particular speed button on the select switch, while the other lead from the coil joined to a neutral wire directly through terminal block to the battery, with a master-switch intervening, while another wire from the battery passes through the terminal block to the contact of the selector-switch which is common to all speeds. The current travels from one terminal of the battery through the depressed push button on the selector-switch, down and around the coil selected, and then back to the other terminal of the battery.




Fig. 238
Connections of the Magnetic Gear Shift

The Vulcan electric gear shift mechanism consists of a case which is attached to the transmission housing. This case, in turn, carries the magnets or solenoids. These in turn surround the plungers on which the shifting forks which move the sliding gears in the transmission are mounted. In this case, also, is carried the operating mechanism by means of which the gears

are mechanically drawn to their neutral position through a connection with the clutch pedal. The case is divided into two compartments, the smaller of which is a pocket in which the operating mechanism for the neutralizing of the gears and the operation of the master-switch is carried. This compartment is entirely enclosed on the bottom, and is not open to the transmission case.

The neutralizing mechanism consists of two shafts on which cams are mounted. One of these shafts carries a pawl which engages with a latch on a rocker arm. Upon the opposite end of this rocker arm shaft is mounted a lever through which the connection with the clutch pedal is made.

Assuming that all gears are in a neutral position (that is, the sliding gears are not in mesh), and it is desired to start, the first speed button on the selector-switch is depressed, closing one break in the electric circuit. The operating lever and the shaft on which it is mounted are rotated and the master-switch is pulled into engagement through its connection with the operating mechanism which engages the switch stem. As the gear flashes into mesh, and is within 14 from being "home," the master-switch snaps out instantly, due to the action of the master-switch spring, thus breaking the electric circuit. The actual time of engagement during which current is being drawn from the battery is less than 1/3 of a second.

Being in first speed, and desiring to proceed

to another, the other speed button upon the selector-switch may be depressed at the convenience of the driver. Then, when it is desired to shift, the clutch is fully depressed as before.

As the neutralizing cams rotate toward the center, they press against a boss on whichever side the gear is in engagement. This mechanically pulls the shifter fork and gear with which it is engaged back to neutral position, before the next shift can be made. The electric circuit is again made complete, the current flows from the battery through the solenoid selected and the proper gear immediately jumps into engagement. This action is the same for all speeds in the transmission.

Should it be desired to stop, the neutral button on the selector-switch is pressed. This action throws any other button which may have been depressed out of contact, that is, it automatically raises any other button which may have been depressed previously.

Any selection may be made, at any time, by pressing any push button on the wheel. This selection, however, does not necessarily influence the changing of the gears in the transmission. In fact, nothing happens until the master-switch is closed by the pressing, all the way down, of the clutch pedal.

In the operation of this device the clutch pedal may be slipped or fully released without any action taking place in the gear shift mechanism itself. This is due to the fact that the operating lever is attached to the clutch pedal by means of an operating rod provided with a link mechanism, which allows the clutch pedal to fully release the clutch before it starts to pull on the operating lever.

Magnetic Transmission, see Change Speed Gears.

Magneto; see Ignition, Magneto.




Fig. 239

Manifold, Inlet. The internal diameter of the admission or inlet-pipe leading from the carbureter to the admission-valve chamber should not exceed one-fourth the diameter of the motor cylinder.

This limitation is necessary in order to produce as great a partial vacuum as is possible in the admission-pipe. The carbureter should be placed as close as possible to the admission-valve chamber of the motor in order to secure

the best results. Short turns or bends in the admission-pipe greatly increase the air-friction in the pipe, and at high speeds greatly diminish the volume of the charge drawn into the cylinder by the inductive or suction action of the motor-piston. An admission-pipe with a side inlet and short bends, for a two-cylinder motor, is shown in Fig. 239. Such forms of construc-




Fig. 240

tion should be avoided whenever possible. Fig. 240 shows an admission-pipe of approved design, with long bends, for a two-cylinder motor. The radius of curvature of the pipe on its center line should not be less than twice the outside diameter of the pipe. If space allows, a radius of three times the outside diameter of the pipe will give better results than two diam-

The desire to prevent condensation of the gasoline vapor in the inlet manifold has led many designers to fasten the carburetor flange directly to the cylinder casting at the point of entrance to the inlet valve passages. Others have either completely or partially water-jacketed the inlet manifold for its entire length. In all cases, the distance between the carburetor mixing chamber and the inlet valve port is made as short as possible.

A troublesome condition on many cars is that caused by minute air leaks in the inlet piping and connections. If carburetor adjustment is difficult, squirt liquid gasoline on the inlet connections with the engine running. Any change in engine speed is a sure indication that one or more air leaks exist.

Motor, Electric Vehicle. A well designed motor for use in connection with a storage battery for automobile propulsion must be capable of withstanding an overload of over 100 per cent for at least thirty minutes at a time, or for even a longer period, without unduly overheating. The motors used on electric automobiles are usually series-wound, as this type of winding has been found to give the most satisfactory results in general use.

There are three types of electric motors in general use, these are:

Shunt-wound motors, in which the field-magnets are wound with a great many turns of

very small wire, the ends of which are directly connected to the terminals of the commutator brushes.

Series-wound motors, which have the field-magnets wound with a few turns of very large wire. One end of this wire is connected to one commutator brush terminal. The other end of the wire on the field-coils, and the other brush terminal being connected with a battery or other source of current.


Compound-wound motors are a combination of the above motors, having the field-magnets double-wound, that is with both shunt and series-windings.

The armature of an electric motor is built up of a number of disks of sheet iron, which are separated from each other by a suitable coating of varnish or by the use of thin sheets of paper between the disks, this is to prevent what are known as eddy currents, which are a source of constant trouble if not eliminated.

The function of the commutator of an electric motor is to receive the current from the battery or other source of power, by means of the brushes, and transmit it to the windings or coils upon the periphery of the armature.

The essential features of an electric motor are as follows:

The brushes, which are located upon and around the periphery of the commutator and serve to transmit the current to the commutator from the outside source of supply.



The commutator or current distributor, and laminated wrought iron armature.

The field-magnets and pole-pieces; the latter are usually an extension of the magnet core.

The magnet frame, usually of cast steel.

Figure 241 shows a form of series-wound electric motor of the style most commonly used for automobile work. The motor is of the fourpole type, having its field-coils arranged at equi-distant points around the periphery or circumference of the armature. The armature shaft is carried by ball bearings, with suitable screw and clamp adjustment as shown. The armature is of the slot-wound type and has a commutator with self-adjusting carbon brushes. The left-hand extension of the armature shaft is fitted with a key and washer for the driving gear or sprocket, while the right-hand end has a pulley or brake wheel to use for stopping the car under ordinary conditions of travel. The magnet frame is of cast steel, and the magnet cores and armature disks of laminated wrought iron. The field-coils are machine-wound, and the armature coils form-wound, while both are thoroughly taped and waterproofed. The commutator generally has the same number of sections as the armature has slots and is usually of large diameter and wide contact face.

ELECTRIC MOTOR TROUBLES. Electric motor troubles may be classed as follows: Open-circuits, improper connections and short-circuits.

An Open-circuit may be found at any one of the following places:

Battery terminals. These may be badly corroded or worked loose, so as to form a poor or improper electrical contact.

Controller. A connection may have worked loose, or the spring contact-fingers are not making good contacts.

The removable plug may be out or not making a proper contact.

Brushes. One of the carbon brushes of the motor may have fallen out, or the brush springs may be too weak to insure a good contact.

The reversing switch may be halfway over. thus leaving the batteries and motor on an open circuit.

All points of contact, such as terminals or binding-posts, brush-holders, switches and controller spring contact-fingers, should be bright and clean so as to give a perfect metal-to-metal contact.

The fact that the car will not start and the ammeter shows no current indication is generally an indication of improper battery connections.

When the different trays of the battery are not properly connected together, short-circuits will occur between these sections and run down or exhaust the batteries in a very short time. All battery terminals should be plainly marked so that it is impossible to make wrong connections. If the trouble above stated occurs the

battery trays must be wrongly connected amongst themselves.

If the ammeter indicates a large current and the motor refuses to turn, the trouble is what is known as a short-circuit, or a path for the current outside of the motor.

Lift one of the commutator brushes, and if the amperage shown by the ammeter drops, or perhaps disappears altogether, one of the fieldcoils is short-circuited or there is a broken wire touching some part of the metal of the car or an exposed portion of another wire.

ELECTRIC MOTORS, SPEED-REGULATION OF. The speed and consequently the power of an electric motor may be varied in three ways, as follows:

First, by introducing variable resistances in the motor and battery circuit.

Second, by varying the voltage of the batteries by different combination of the battery trays.

Thirdly, by connecting the field-coils of the motor; all in series, in series-parallel and all in parallel. Various other combinations of the above named methods may also be had.

Muffler, Exhaust. When the exhaust gases of an explosive motor are allowed to pass out through the exhaust pipe directly into the atmosphere, the sharp explosions rapidly succeeding each other are very annoying, and it is for this reason that the device termed an exhaust muffler is, or at least should be, used. Various types of mufflers are in use, each no doubt possessing its own particular merit. The function of the muffler is to deaden the noise of the escaping gases, and the general requirements of the device are as follows: (1) It must be built strong enough to withstand the force of any explosion liable to occur within it, due to the escape of an unexploded charge, which may take place in one of the engine cylinders. (2) It must check the velocity of the escaping




Fig. 242

gases without causing too much back pressure on the motor. (3) It must deaden the noise. The last two requirements may be attained by:
(a) Breaking up the gases into a number of fine streams; (b) Allowing the gases to expand and cool; (c) Reducing the pressure of the gases, until they are as nearly as possible at atmospheric pressure.

The terminal or exhaust pressure ranges at from 30 to 50 pounds per sq. in. above atmospheric pressure, while the temperature will be 800 to 1100 degrees F.

MUFFLER CUT-OUTS. Mufflers are generally equipped with muffler cut-outs, which by-pass the gas so that it exhausts direct into the atmosphere with its attendant noise. There are three reasons why they are so equipped, namely: to tell if the engine is exploding regularly; to clean the exhaust pipe; to have it act as a safety valve in case of explosions in the muffler. If the power of the engine increases when the muffler is cut out, it is a sure sign that the muffler is of defective design or needs cleaning.

MUFFLER CUT-OUT VALVE. One form of cutout valve is shown in Fig. 243. It is inserted in exhaust pipe P, by sawing a hole in its under




Fig. 243
Muffler Cut-Out Valve

side. The cut-out valve housing clamps to the pipe by a couple of V-clamps. The valve is carried in a cylindrical compartment under the exhaust pipe, and consists of a spring closed poppet valve a little larger in diameter than the internal diameter of the exhaust pipe. It opens against the exhaust pressure to prevent leakage.

CARE OF MUFFLERS. From time to time, all mufflers should be cleaned, because it will be found that they will contain a considerable amount of carbon deposists. These deposits not only tend to increase the back pressure, but they retain the heat of the exhaust, thus allowing the gases to escape at a higher temperature than they should. A muffler should be taken apart and cleaned once a year, or oftener if there are any indications of loss of power, resultant from back pressure.

A frequent cause of damaged or broken mufflers is the practice of ignition testing employed by some mechanics. In case of trouble with either source of ignition, the car is run at a rather high speed on the good system, and the ignition switch is then quickly turned to the faulty side. If no explosions result, the switch is again changed. In the time during which no explosions occurred in the engine, the unburned mixture was pumped back into the muffler. When the switch is thrown to the good side, the first power stroke sends a flame into the muffler with the result that an explosion occurs there, usually damaging the muffler seriously.

Packing. Packing or material for making gas, or water-tight joints is of various kinds. Asbestos packing comes in sheets, called asbestos paper or board, in the form of woven cloth, and also as string or rope. Rubber packing is made in sheets, either plain or with alternate layers of canvas and rubber. Some forms of

packing are known as Rubberbestos, and Vulcabestos, and are made of asbestos, impregnated with rubber and afterwards vulcanized.

Picric Acid. Gasoline will absorb or take up about 5 per cent of its weight of picric acid. The addition of a small quantity of kerosene will enable the gasoline to absorb about 10 per cent of pircric acid.

Picric acid is only dangerous when fused, or when in a highly compressed state.

An increase in motor efficiency of about 20 per cent is claimed for the picric-gasoline mixture.

About three-tenths of a pound of picric acid is required for each gallon of gasoline. The mixture should be allowed to stand for two days, agitating occasionally during this time, then strain through two or three thicknesses of very fine muslin before using.

It must be remembered that picric acid is an etching ingredient, which is another way for saying that it will destroy the cylinder walls.

The explosive force of picric acid is very much overrated. If thrown upon a red hot plate of iron, it simply burns with a smoky flame, and striking a small quantity of it upon an iron anvil will not explode it.

Piston Head Scraper. In most engines the piston heads can be scraped clean of carbon without removing the pistons from the cylinders, by means of specially formed scrapers introduced through the opening over the valves, cr

through the spark plug holes when the latter are horizontal. The form and size of scraper will depend on the particular engine, but almost any suitable form may be made from 5-16-inch steel tubing about 12 inches long having the ends hammered flat, and turned over at right angles in a vise. The ends are then filed straight, and sharp, and the shank of the scraper may be bent to right or left, if necessary, or left straight. Frequently two scrapers will be needed in order to use both right and left hand bends. The advantage of tubing for this purpose is that no blacksmith work is necessary.

Platinum. The contact points of the vibrator of an induction coil should always be of platinum. German silver or any other metal spoils the quickness of the break on account of the greater tendency of the contact-points to carbonize, when of any other metal than platinum. Spark plug points should also be of platinum or iridio-platinum, which is better yet, as it is more capable of withstanding the intense heat in the combustion chamber than the platinum itself. Any other metal than platinum (except gold) will turn green or black if tested with nitric acid.

Polarity. To ascertain the polarity of the terminals of a storage battery or light circuit, place the ends of the wires on the opposite ends of a small piece of moistened litmus paper. The

vire on the side of the paper which has turned ed is the negative pole of the battery.

Porcelain. Porcelain tubes used for the inulation of the center rod of a spark plug have igher insulative properties than lava or mica, out on account of the liability of the porcelain o break from too sudden change of temperaure, it is not as reliable as other forms of inulating material.

Pounding—Causes of. The most obvious ause of pounding is that of a spark advanced oo far. This, however, nearly always occurs spon hills, in deep sand or mud, or elsewhere, whenever the engine is laboring very hard. In he case of too far advanced spark, manipulation of the spark would only make the pound vorse than ever. So, too, if the spark was nornally set too far advanced, it would pound nore at high speeds than at slow, just the reverse of the actual case.

Preignition causes pounding, and is itself aused by overheated piston or cylinder walls. Howing points or deposits of carbon within he cylinder, as well as faulty or uncertain igniion also cause it. Leaks in the chamber are ometimes the cause of pounding, so too, are poseness of parts. Among the latter may be ited: connecting rod bearings, main bearings, pose flywheel, cracked flywheel, other lost motion. Beyond these things, the only other cause f pounding is that of some moving part which trikes as it rotates.

Preignition—Causes of. If the inside surfaces of the combustion chamber are free from sharp corners or projections formed in casting. preignition is probably due to the combined influences of high compression, and carbon or dirt on the piston head. Next to the exhaust valve itself the piston head is the hottest part of the engine, since it cannot be water cooled. this reason it is much more important to keep the piston head clean than the other surfaces exposed to flame, and this is best accomplished. first, by the use of a good non-carbonizing oil. and, second, by thoroughly screening the air If preignition is troublesome it will pay to fit a dust screen underneath the engine in case none is already provided, since whatever dust touches the piston head will be held there by the oil, and will be fully as effective in causing preignition as the same amount of carbon. The intake itself should draw air through at least one, and preferably two or more fine wire gauze screens of sufficiently large area to permit the air to pass through them slowly. These screens should be removable, and should be inspected, and cleaned with gasoline and a toothbrush as often as may be necessary. It will be found that the fitting of a suitable dust screen beneath will make an immense difference in the amount of cleaning, which the gauze screens require. In the manufacture of high classed motor cars the greatest care is taken in scraping the walls and dome of the cylinder castings forming the combustion space, the aim being to remove every projection that might cause a pre-ignition point as also to remove every burr, or rough spot to which foreign matter would adhere. The lubrication system of a car is a most important factor in the elimination of preignition due to the proper amount of oil being fed to the cylinders at all times.

Pump, Water. The circulating pump is used in the belief that it affords a means for regulating the temperature of the jacket water supply, which would not always be the case with a thermal-syphon system. Such is not the case, as the pump, being driven direct from the motor, operates at a speed which varies with the motor speed. On starting the motor, it pumps cold water into the jacket. It pumps slowly at slow speeds, although the motor may be taking a full charge and heating rapidly. pumps fast at high speeds, although the wind pressure and its consequent cooling effect may be very great. If a circulating pump could be used in connection with a device to control the regulation of the motor temperature, the results would be more satisfactory.

Rotary pumps used in the water circulating system of gasoline automobile motors are of two forms, centrifugal and positive, or force-feed. A positive or force-feed rotary pump is shown in Figure 244. An annular ring around the pump shaft carries two blades, one of which is

hinged to, and the other attached directly to




Fig. 244

the pump shaft. The outer ends of the blades are supported in the periphery of the annular ring, and rotate eccentrically with it. The pump shaft is concentric with the pump chamber, but the annular ring is located eccentrically around the shaft, which drives it by means of the fixed blade on the shaft.

Fig. 245 illustrates another form of positive-feed rotary pump, in which the pump shaft is eccentrically located in the pump chamber. A short cylinder which forms a part or portion of the pump shaft, carries two blades in a slotted opening parallel to, and coincident with the axis of the pump shaft. These blades are kept in contact with the interior periphery of the pump chamber by means of coil springs, located between the blades as shown. Rotation of the cylinder in the pump chamber causes a sliding

reciprocating action of the blades, due to




Fig. 245

pressure of the coil springs between their er ends.

rumps—Centrifugal. In this type of pump height of lift is governed by the tangential se. Owing to this fact centrifugal pumps for on automobiles may be made of aluminum the housing, as it is both light and strong, y able to withstand the pressure, there being rubbing surfaces. The wheel, however, uld be made of phosphor bronze of a good de. In these pumps the suction inlet is ally at one side surrounding the axis, see . 246. The pump should be geared to a speed high if not higher than the crankshaft speed. In minimum peripheral velocity of the pump should be 500 feet per minute. For autobile service the general rule is to have a

three vane wheel, and the curving is away from the direction of rotation.

Pumps, Water Circulating. If steam is seen coming from the relief, or outlet of the water




Fig. 246
Section of a Centrifugal Water Pump, Showing Entrance
of Water at the Side, Around the Shaft

circulating system, look for a blockage of the circulation, or failure of the pump.

If some of the radiator tubes are cool and others are hot, look to the pump.

To test the pump before starting, run the motor for a few minutes. Then ascertain how

long it takes before the top radiator tubes are thoroughly hot. If the heat of the pipes is uniform the circulation is all right.

Rheostat. A rheostat is a device for regulating the flow of current in a closed electrical circuit, by introducing a series of graduated resistances into the circuit.

Rubber, India. All articles made of commercial rubber should be kept from contact with oil, kerosene, gasoline or grease if they are to be kept in good condition. Vulcanized rubber should not be exposed to a temperature of more than 130 degrees, Fahrenheit. Commercial or vulcanized rubber contains not to exceed 30 to 35 per cent of pure India rubber, as its stretching quality, stickiness and rapid deterioration under the action of light and air make its sole use undesirable.

Rubber Cement, How to Make. Marine glue, so-called, is an excellent cement. This consists of one pound of caoutchouc to one gallon of coal tar naphtha, and twenty pounds of shellac. Heat gently and pour on metal plates to solidify. When needed, melt. By using more naphtha, this is made thinner so as to stay liquid. The sulphur in this is in the caoutchouc, but if found insufficient in any one case, more sulphur may be added to the cement in the powdered form, when making it up, or if necessary, when remelting.

Another excellent cement is gutta-percha

cement. The composition of this is two parts of gutta-percha to one part of common piten. It is melted together, and well-stirred in the melting, the stirring being fully as important as the materials. When thoroughly melted and stirred, it is poured into cold water. This makes it into a hard brittle substance, which softens at a low temperature, and at 100 degrees is a thin fluid. Like the former recipe, this earries its own sulphur in the gutta-percha, but if more is necessary, it can be added as a powder. In this case, it is not advisable to add the sulphur during the remelting process, but it should be put in while making up a batch of the cement.

As a rule, as little cement should be used as is possible to make a good job. Moreover, all cement should be given plenty of time to dry. Rubber surfaces to be united should be thoroughly cleaned, either with naphtha or with a thin cement. When the latter is used, it is brushed over the surface very lightly, using a fine brush, and then the surfaces are heated gently. This helps the whole operation, because it both softens the rubber, and evaporates the solvent, which is then unnecessary to complete the operation, having served its usefulness.

In addition to the various substances mentioned before for cements, it is very often necessary to have the cement dry very rapidly. In these cases, specific driers are added, and may usually be added to any cement at will, the quantity added being measured only by the re-

quired speed in drying. Then there are cases where certain degrees of tenacity are required. For these, other gums are added, as rosin, mastic, gumlac, etc. These, however, should be used only when needed, and much discretion should be used in adding them to an already very satisfactory cement.

Running Gear. A complete running gear includes the frame, springs, wheels, motor, speed-change-gear, axles and the machinery of the car except the body. The French word, chassis, is sometimes used to designate a running gear,

Secondary Current. The current which takes its rise in the fine wire of the induction coil, and which flows through the wire to the spark plug, is induced in the fine wire by the sudden reversal of the magnetism of the iron core.

This change of magnetism is caused by the sudden interruption of the primary current.

Self-firing, Causes of. If the motor should continue to run after the switch has been opened, it is due to an insufficient supply of lubricating oil, causing the motor to overheat, or to the presence of soot or some projection in the combustion chamber becoming incandescent. It may also be due to lack of water or to the water circulation working poorly, causing the motor to overheat.

Shaft Drive. The principal advantages which may be advanced for the shaft drive are, absence of noise, convenience with which all the parts may be housed in oil and protection from

dust. It is especially adapted for use upon cars carrying their engines in front, with the crank-shafts parallel with the length of the car, as the direction of the power shaft does not have to be changed until the rear axle is reached, and as the power must also pass through one set of bevel gears, it is more efficient.

The principal disadvantages of the shaft drive are that it is difficult to repair; it is some-




Fig. 247
Pouring Parson's Metal

what more complicated; it has considerable end-thrust and it is claimed that it is harder on the tires.

Shop Kinks. To reline a journal box with Parson's white brass, proceed as follows: Prepare a reasonably smooth cast iron plate A, Fig. 247, which is bored to receive a vertical mandrel B about 3/16 inch smaller in diameter than the finishing bore of the box. An annular brass ring C, about ½ inch wide, and whose in-

side diameter is about ½ inch smaller than the outside diameter of the end flange D of the box to be lined, is then located on the iron plate concentrically with the mandrel, and secured by means of pins or otherwise. This ring serves as a support for the box itself, and in the process of pouring, the space between the ring and mandrel is filled with white brass which is afterward turned off. Any imperfect metal which may be poured will




Fig. 248

find its way either into this space or into the space above the box, leaving the lining of the box itself perfectly sound. The box itself is assumed to have been suitably counterbored and recessed to hold the lining as shown in the sketches E and F, Fig. 248. It is preferable to use the arrangement shown at F and allow the lining to extend beyond the ends of the box, and form the outer surface of the flanges. In this case the diameter of the flange formed by the lining will be the inside diameter of the sup-

porting ring, which will be slightly smaller than the diameter of the flange of the box itself.

The halves of the box—if it is split—are wired together and the box and the mandrel are heated by torches and assembled as shown in the sketch. A second ring-not shown-similar to the supporting ring is placed on the top of the box, and all the cracks are luted with moist fire clay. Meanwhile, the white brass has been melted in a kettle to a fairly high heat somewhat higher than the pouring temperature. While it is being melted, it is kept covered by about 1 inch of powdered charcoal. which excludes the air. When the maximum temperature is reached, the charcoal is quickly skimmed off and a handful or two of powdered salammoniac is thrown on. The salammoniac is immediately volatilized and forms a heavy, though colorless gas which shuts off the air from the surface of the metal and causes it to stay bright. The pouring is then done with all possible haste, and on cooling the metal will be found perfectly homogeneous and solid. If the box is split the lining can be condensed by pening. If the box is solid, the lining is simply bored to the proper size.

To Restore a Sagged Frame. A frame which is sagged to the extent of permanent deformation can be restored so as to approximate its original shape, by heating it in a charcoal fire with an air blast. To do this properly, it will most likely be necessary to cut out the rivets,

so that the side members can be handled independently. A good plan of procedure is to inclose the bent portion of the frame in a section of stovepipe of sufficient size in which the char-. coal fire is built. A length of 1-inch gas pipe, closed at one end, and having 5/16-inch holes, drilled at intervals of about 6 inches, is laid in the bottom of the pipe and furnishes the air supply from a bellows. When the charcoal fire is well kindled, the frame is introduced upside down, and is supported at the ends. The fire is then concentrated on the bent portion, and as the frame becomes hot it will straighten itself. It must be watched carefully and the air blast stopped as soon as the frame is seen to be straight. Most of the frames used in American cars are ordinary carbon steel, and require no special treatment. It will be well, however, on stopping the air blast to shift the stove pipe to a cooler portion of the frame, to permit the part which has been straightened to cool as quickly as exposure to the air will permit. A frame which has been sagged and straightened in this manner will require to be trussed to prevent recurrence of the trouble. As conditions vary so much the best rule to follow is to observe the truss arrangement on some similar car. The struts should be about 4 or 5 inches long, and should be located at the spots where the sagging has occurred. The truss rod itself should be about ½ inch in diameter, and drawn taut by a turnbuckle, which may be finally

SPANISH WINDLASS. The old fashioned Spa ish windlass, in Fig. 249, may be occasional employed where no other hoist is available. is extremely handy in setting, and lining a motors, transmissions and rear axles. It co sists of a round bar or piece of pipe, a piece rope, and a lever such as a small crowbar




Fig. 249 Spanish Windlass

jack-handle; all of which are quite common the ordinary repair shop. The round bar laid across the side members of the frame, t rope is made fast to the object to be hoisted loop of it is wound around the bar as show and the lever inserted in the end of the lo Although this is as old as the hills, it is not a common to see a man lying on his back, in ansmission case up into place while another is ying to locate the bolt holes, and adjust the ters; whereas, if this makeshift windlass were aployed, one man could raise and set the gear-ax with much less trouble.

STRAIGHTENING SPINDLES. In Fig. 250 a tool shown which is used in a local repair shop, r straightening spindles. The tool, which is heavy construction, is placed in a vise; the





Fig. 250
Tool for Straightening Spindles

indle is heated to a red heat, the ends cooled f with water, and placed between the centers, illustrated. A lever is then placed between e bent portion of the spindle and the shank the tool, so that when pressure is brought to ar on it, the spindle arm may be brought ck into its normal position.

CLEANING ALUMINUM. Aluminum, such as ed for foot-boards of cars, may be cleaned by ing hyposulphate of soda, as this substance is solvent of aluminum tarnish. The dirty sur-





ce should be washed with a strong solution the hyposulphate; then rinse the surface with ater and dry.

CARE OF TIRE PUMP LEATHER. The proper bricant for the cupped leather washer of the re pump piston is vaseline. Oil is too thin id it tends to work into the rubber hose, and ren into the tire itself if too much is used. Vasine, on the other hand, clings to the leather id lasts a considerable time. If the leather comes dry it does not hold air well, and pumpg to high pressure becomes impossible, while e labor of pumping even to low pressure is reatly increased.

REPLACING BROKEN BALL. When replacing a oken ball in a ball bearing it is better to resw the whole set, unless the new ball can be refully gauged to be of the same size as the hers. If this is not attended to, the new ball, wing to bear more than its share of the eight, quickly succumbs. The greatest care ould be taken, of course, to use grease free om grit, and to clean the balls and bearings fore they are replaced.

CLEANING TOPS. Tops may be cleaned by usg gasoline, a little ivory soap and a brush. metimes, however, when cleaning with gasone the water-proofing quality of the materials ay be destroyed. This can be restored by an oplication of paraffine. Dissolve the paraffine ith gasoline and apply with a clean brush, the soline will carry the paraffine into the fabric and will evaporate, leaving the paraffine in the fabric.

USEFUL HINTS. At A, Fig. 251, is shown a simple tool found to be universally useful for wedging off magneto driving pinions, and other small members fitted to coned shaft ends, with or without key retention. This can be easily made from a large file, or any piece of steel of sufficient dimensions, depending upon the work to which it would be applied. The opening in the fork need not be more than three-quarters inch for the average magneto, the tines about two inches long, and three-eighths inch wide and taper from nothing to about one-quarter inch at the thickest part. Two of these are needed and are placed back of the gear, the tapered portion of one piece resting on that of the other, as shown. To remove the gear the ends are driven in toward the centre at the same time. This exerts a lifting effort, due to the wedge action of the tools immediately back of the pinion. The advantage of this method is that the shaft on which the gear is mounted is not subjected to any side strains, such as would result if attempts were made to drive off the gear by holding an S wrench back of the gear and driving against it with a hammer. When removing worn sprockets from the counter shaft in order to replace them with new ones, trouble may be experienced in loosening the nut especially if the rear wheels have been removed. In such cases the chain may be utilized to hold the sprocket in the manner shown at B, Fig. 251, by anchoring it to the axle with an S hook made of three-eighths inch cold rolled steel rod The sprocket will be firmly held and the nut removed without difficulty.

Although some grades of rubber hose are better than others, unless properly cared for even the best will deteriorate rapidly. Among the factors which make for rapid wear are careless stowage and abuse. The hose is left on the wash stand, cars are run over it, and when it has served its purpose, it is thrown in a heap and oil and grease accumulations soon work havoc with the rubber walls. A good rule to follow is to have a place for everything and everything in its place. It is not unusual to see a coil of hose carefully hung upon a nail, shown at C, each coil having a sharp "kink" in it, both top and bottom, as indicated. This sharp bend tends to break the fabric walls, and the hose soon leaks. The proper way of hanging a hose is to use five or six wooden pegs arranged around an arc of a circle, as shown. Under these conditions the coils take a gradual curve, and do not assume a sharp angle as when but a single point of support is utilized. If the hose is one of some length a reel should be used.

Often when fitting bushings and parts, and in general operations where reamers are used it is found that the tool will be just a trifle undersize, or that it is desirable to have the reamed hole just a little oversize. In such cases a simple expedient, as shown at D, Fig 251, will be found valuable. A small sheet of brass, or zinc is rolled in such a manner that it will fit between two of the cutting edges of the reamer. If the reamer is inserted with the roll of metal in place it will be evident that the reamer will be forced a trifle from the centre of the bore and the cutting edges of the reamer opposite the inserted metal roll will remove the metal. Very fine cuts should be taken, and the metal roll placed between different cutting teeth each time that the tool is used. In tapping out nuts it is often desirable to have the thread a little deeper than the standard, or to have the nut a loose fit on the bolt, as is sometimes necsesary when trying to place a machine screw nut on a carriage bolt. In this case a similar roll of metal may be placed between the cutting edges of the tap, as shown at E, Fig. 251.

SOLDER. Silver solders are generally used for very fine work. They are very fusible, and non-corrosive. Hard spelter is used for steel and iron work, and soft spelter for brass work.

When copper is soldered to iron or zinc, resin should be used, or if chloride of zinc is used for a flux, the joint should be washed afterwards to remove the acid. Un-annealed wires should be soldered at as low a temperature as possible. Solder is always an alloy of other metals. It must not only be more fusible than the metal, or metals to be joined, but it must have some chem-

ical affinity for them. Different kinds of solder are therefore employed for different purposes. It is called either hard or soft, according to its fusing point.

Solders and spelters for use with different metals, and their proportional parts by weight are

Solder for:

Electrician's use—1—Tin, 1—Lead.

Gold—24—Gold, 2—Silver, 1—Copper.

Patinum—1—Copper, 3—Silver.

Plumber's—Hard—1—Lead, 2—Tin. Soft—3—Lead, 1—Tin.

Silver—Hard—1—Copper, 4—Silver. Soft—1—Brass, 2—Silver.

Tin—Hard—2—Tin, 1—Lead. Soft—1—Tin, 1—Lead.

Spelter for:

Fine brass work—8—Copper, 8—Zinc, 1—Silver.

·Common brass—1—Copper, 1—Zinc.

Cast iron—4—Copper, 3—Zinc.

Steel—3—Copper, 1—Zinc.

Wrought iron—2—Copper, 1—Zinc.

FLUXES FOR SOLDERING. Some good fluxes for soldering purposes are:

*Chloride of zinc is simply zinc dissolved in hydrochloric (muriatic) acid, until the acid is out or killed.

SCRATCHED CYLINDER. The cylinder may be temporarily fixed by taking it to a first-class tinsmith and having the scratches filled with silver solder. The soldered places must be then carefully scraped flush with the bore of the cylinder. The best way is to have the cylinder rebored and the piston-rings re-turned.

If the scratches are not too deep the cylinder can be rebored, and a new set of piston-rings made to fit the new bore. The limit to such an increase in bore is about one-sixteenth of an inch.

If the damage to the cylinder walls has been comparatively slight, due to the conditions being recognized early, the engine should be disassembled and the surfaces thoroughly cleaned of any dirt or carbon. After reassembling, the full amount of lubricating oil should be put into the engine, and with the oil should be mixed an amount of graphite, in either the amphorous or flake form, proportioned to the kind being used and the body of the oil. Continued use of graphite will tend to fill the small scratches in the metal.

Garage—Cleaning Floors. A hot saturated solution of common washing soda will do very well. This can be made up in quantities and stored against future use. If this method is used, be sure to reheat it before using, the boiling point being about right. Since that will be too hot to apply with the hands, use any old broom or brush to "slosh" it around on the

floor. An equally good, if not better, solution to use for this purpose is trisulphate of sodium, marketed by several chemical companies, and sold at from four to five cents per pound at retail. This can be used cold and will not injure the most delicate hands; on the other hand, it will clean them very thoroughly, so that users of this solution use it for the hands as well as for the floors. This is strong, however, and may be used to remove paint.


PROTECTION FROM FIRE. The recommendations of the National Fire Protection Association pertaining to garages and their operation are as follows: No dynamo or gas engine should be permitted where gasoline is stored or handled; all exposed lights should be eliminated; cleaning of acetylene lamps and removal or renewing of carbide should be carried on outside of garage; the residue of acetylene lamps should never be cast on the floor; machines should have oil tanks emptied before being put in the repair shop; the use of extension electric wires is condemned, as they may cause fire; motor testing should be done outside, for sparks might ignite the fumes of gasoline; storage tanks should be filled from outside of garage; all volatile oils should be stored in good, heavy tanks under ground, as far away from the building as possible; pipes for filling storage tanks should not pass through the garage in any way; a filling station should be twenty to thirty feet from the entrance to the garage, and

tanks of cars filled from there if it is necessary to fill them when the cars are inside of the garage; furthermore, the station should be fire-proof, and all cars should be brought to this point for filling; smoking and carrying of matches, or use thereof should be strictly prohibited; floors should be kept free of oil drippings, and pails of sand should be kept handy in proximity to gasoline.

A garage of ordinary size should be equipped with at least four or five chemical fire extinguishers, and these should be placed so that they may be quickly reached by any one in case of emergency. The stream from such an extinguisher will smother a fire before it has done much damage if the flame can be reached within a minute or so of the time when it started. The chemicals usually used will not harm the finish of the car if the surfaces exposed are immediately washed in the usual way. Slight marring is of course preferable to destruction.

Spark Plugs. The trouble with motors misfiring, is generally due to dirty spark plugs. This is caused by using too much cylinder oil, which, when subjected to the intense heat in the cylinder, turns to carbon. This carbon deposits on the insulated porcelain and the body of the plug, and instead of the current jumping from the point in the body to the point in the porcelain and making a spark, it follows the easiest path, which is the carbon, and does not make a spark at the plug points at all. When

this occurs the motor will misfire. The first thing to do when a motor misfires is to test the spark plug. Turn the motor until the battery circuit is closed. Unscrew the spark plug from the motor, then reconnect the wire to it just the same as it was before. Lay the metal part of the plug body on the flywheel or some other un-



A-Platinum point.

B-Thread.

C-Plug body.

D-Bushing.

E-Insulated terminal.

F-Porcelain bushing.

-Expansion spring.

H-Asbestos washer.

J-Lock nuts.

K-Assembly nut.

painted part of the motor, being careful that the metal part of the plug body only touches the motor and that the porcelain part is clear. If the spark jumps in short jerks between the inner end of the porcelain and the interior of the plug body it is scoted, and needs cleaning. If it jumps at the points as it should do, the trouble is elsewhere; probably at the batter loose connecting wires, or the vibrator of the coil is not properly adjusted.




Fig. 253

To clean a spark plug properly use a 50 percent solution of hydrochloric (muriatic) aci washing the points of the plug with a tool brush, occasionally dipping the plug into the




Fig. 254

acid. After cleaning the spark plug in the manner, rinse it in water.

SPARK PLUGS—CONSTRUCTION OF. Two spaplugs are shown in Figure 252, which, while d fering radically in their construction, effect t

same purpose, that of producing a spark or arc in the combustion chamber of the motor. The accompanying table and reference to Figure 252, will fully explain the construction of the spark plugs.

Cross-sections of four different forms of spark plugs are shown in Figure 253. All are constructed with a view to make the outside or extraneous path caused by sooting, as long as




Fig. 255

possible, so as to prevent if possible short-circuiting of the plug from this cause.

Figure 254 shows a form of spark plug in which two extra air-spaces are provided, one between the center rod or terminal and the porcelain bushing and the other between the porcelain bushing and the shell or body of the plug.

The spark plug shown in Figure 255 has a closed chamber around, and over the center insulated rod or terminal; this chamber is a part

of the body of the plug and forms the other te minal of the plug. It acts as a small combu tion chamber, and streams of fire are suppose to be thrown from the small openings in the chamber, when the arc or spark occurs therein




Fig. 256

An exterior view of a form of spark plug it general use is shown in Figure 256.

Spark plugs of American manufacture ar made with three different sizes of threads: One half inch pipe-size, the actual outside diamete of which is .84 of an inch, with 14 threads pe

inch. Seven-eighths of an inch diameter, with 18 threads per inch, and .7 of an inch diameter, with 17 threads per inch. The last named one is the French, or Metric standard thread.

Specific Gravity. In the absence of a proper instrument, the specific gravity of gasoline or any other liquid may be obtained as follows:

Weigh a certain quantity of distilled water at 4 degrees Centigrade, or 39 1/3 degrees Fahrenheit.

Weigh the same quantity of gasoline or other liquid under test.

Divide the weight of the liquid by the weight of the water, and this will give the required specific gravity of the liquid.

The specific gravities of various liquids are as follows:

| Alcohol at 15° C | |
|---------------------------|----------------------|
| Acid, nitric | 1.217 |
| Acid, sulphuric | 1.841 |
| Ether at 15° C | 0.720 |
| Naptha | 0.848 |
| Oil, linseed | 0.94 |
| Petroleum | |
| Gasoline at 15° C0.680 to | $\boldsymbol{0.720}$ |
| Water, sea, at 4° | 1.026 |
| Water, pure, at 4° | 1.0 |

The specific gravity of the electrolyte used in storage batteries is usually close to 1,250 under ordinary conditions. This figure will reach 1.300 or 1.310 with a fully charged starting and lighting battery, and may fall as low as 1.100 with a battery that needs charging badly.

The specific gravity of a storage battery should be tested while the battery is being

charged or immediately after the charge has been discontinued, never just after water has been added.

To test the gravity, it is necessary to use a hydrometer made and graduated for this work, the instrument being preferably enclosed in a tube fitted with a bulb and nozzle and called a hydrometer syringe. With the filling caps removed from each cell of the battery, the bulb is compressed, the nozzle inserted into the cell and enough liquid drawn up to float the hydrometer. The marking on the hydrometer stem at which the surface of the liquid remains is the specific gravity of that cell. The gravity should be nearly the same in all cells with a good battery. The liquid should be returned to the cell from which it was drawn.

Springs. The length and number of leaves in the springs of motor cars of similar weight and power vary, and without any reason for so doing. The general use of pneumatic tires hides many imperfections in this respect as well as in others. Springs of insufficient strength are a source of great danger, and frequent examination should be given to them. Springs are not necessarily of insufficient strength because they appear to be light. Short springs are not desirable, as they are more liable to break than a longer spring, the deflection per unit of length being greater. Stiffness in short springs is usually avoided by lightness, which is likely to lead to breakage, especially when the hole



Fig. 257
Full Elliptic Spring, Scroll Ends



Fig. 258 Semi or Half-Elliptic Spring




Fig. 259
Three Quarter Elliptic Spring



Fig. 260
Fixed Cantilever Spring




Fig. 261
Three Quarter Floating Cantilever Spring

for the bolt through the center of the spring is made larger than necessary.

Springs—Dimensions of. In calculating the dimensions and elastic limit of springs for motor-car use, the elastic limit must be carefully considered with regard to the dead, and maximum loads to be carried by the car. The dead load is the weight of the car when at rest. The maximum load is the greatest weight that can possibly be carried with good spring action. The springs to retain their elasticity should have their ultimate strength far beyond their maximum load capacity.


The old practice of fixing a uniform curvature of the spring leaves frequently leads to breakages due to distortions set up at the spring perch. This tendency is now aborted by making the spring leaves in such a way that the curvature begins at points beyond the spring perch, so that the clamps when they are pulled into tight relation do not straighten out the plates. It is still the custom to use a leather pad on which to rest the springs, because thereby the coefficient of friction becomes that of leather, and creeping tendencies are as a consequence remote. There is also the question of the camber given to the respective spring plates. If the plates are all of the same thickness, they should all be curved to the same radius, for then the extreme fiber strain would be equal in all the plates for every alteration in camber incidental to the service they are placed to perform.

Springs—Testing and Material. The life of a spring is forecast by the maker thereof, almost independently of the quality of the material. If the spring is limber, and it is so placed as to indicate spring play, just at the point of reversals of camber, the life will be shortened. The superior grades of materials will stand this abuse for a comparatively long time, but the dynamic life of steel, like the life of every other animated thing, is limited. Inferior materials, advantageously situated, might last far longer than the superior products working at a disadvantage. The initial camber to give a spring, for a given static camber, is a problem for the springmaker.

Fig. 262 shows three views of a given spring, under the conditions as follows: The spring under static load, indicating the static camber; straightened out under load; in reverse camber, in a testing machine, to the limit before permanent set.

It is worth while to study these three conditions in relation to springs, because they have to do with the life of the spring in service, and the easy riding qualities of the car due to spring action. It might be said in general that the greater the difference between the initial and the static camber, the more pronounced will be the easy riding qualities, and it might be said as well that the greater the initial camber, and

the greater the possible reverse camber, the better will be the life of the springs, especially if we take into account that the spring action in service will be limited between the two points, as represented by the initial camber on the one hand and the condition, which means that the spring leaves will no more than straighten out in actual service. If the service conditions are such as to eliminate any reversal of camber,



then it may be said the factor of safety will be represented by the amount of the reverse camber in a testing machine before permanent set.

Springs should be examined occasionally, and while often overlooked this seemingly trifling matter has a direct bearing upon the smooth, easy running of the car. Owing to the fact that the springs are exposed to the weather, rust is very likely to occur at

this point, and to this unsuspected corrosion is often due the occasional "squeak." Although many cars are provided with some means for lubricating the friction surfaces, many cars are not so well provided for and when rust makes its appearance along the joints there is a crying need for oil. This may be conveniently applied by placing the jack between spring and frame, and slightly opening the leaves or plates.




Fig. 263

The toggles and links should also have a little oil occasionally and when about this work it is well to examine the nuts of the clips. These nuts are prone to work loose.

Sprockets. The circular instead of the linear pitch is often erroneously used in calculating the pitch diameter of a sprocket wheel. Reference to Figure 263 will illustrate the difference between circular and linear pitch, and help to demonstrate the case more clearly. The view at the left of the drawing shows the circular pitch,

and the view at the right the linear pitch of a gear or sprocket wheel respectively. If the circular pitch of the gear be one inch and the gear has six teeth as shown, the pitch diameter will be 6×0.3183 , which gives 1.91 inches as the pitch diameter. Let the linear pitch of the sprocket be also one inch, and with six teeth as before. In a sprocket having 6 teeth, the radius is equal to the linear pitch, as the figure is composed of six equilateral triangles, and the pitch diameter of the sprocket wheel is consequently 2 inches.

The pitch of the sprocket must, of course, be the same as that of the chain to be used with it. Chain pitches usually measure in even inches and common fractions. The type of chain, whether roller, block or silent, must also be considered. It is not safe to use mismated chains and sprockets.

Sprockets, Dimensions of. Table 11 gives the pitch diameters of sprockets for roller chain of 1 inch, 1¼ inch and 1½ inch pitch, with 7 to 28 teeth. The outside diameters may be found by adding the diameter of the roller to the pitch diameter of the sprocket.

Sprocket Chain Lubrication. The best lubricant for sprocket chains is a constant puzzle. If oil is used it is absorbed by the dust which settles on the chain. If tallow or other animal grease is employed it is pushed away from the bearing surfaces, and the latter get dry. The ideal lubricant would seem to be something be-

TABLE 11.

DIMENSIONS OF SPROCKETS FOR ROLLER CHAIN.

| Number of Teeth in Sprocket. | 1 Inch Pitch. | 1¼ Inch Pitch. | 1½ Inch Pitch. |
|------------------------------------|------------------|-------------------|-------------------|
| | Pitch Dia. | Pitch Dia. | Pitch Dia. |
| 7 | 2.31 | 2.88 | 3.46 |
| 8 { | 2.61 | 3.27 | 3.92 |
| | 2.92 | 3.65 | 4.38 |
| 10 | 3.24 | 4.04 | 4.85 |
| 11 | 3.54 | 4.44 | 5.33 |
| 12 | 3.86 | 4.83 | 5.79 |
| 13 | 4.18 | 5.22 | 6.27 |
| 14 | 4.50 | 5.62 | 6.75 |
| 15 | 4.81 | 6.01 | 7.22 |
| 16 | 5.12 | 6.41 | 7.69 |
| 18 | 5.76 Ì | 6.41 | 8.64 |
| 20 | 6.39 | 7.99 | 9.59 |
| 22 | 7.03 | 8.79 | 10.55 |
| $\overline{24}$ | 7.66 | 9.58 | 11.49 |
| $\mathbf{\bar{26}}$ | 8.31 | 10.38 | 12.44 |
| 28 | 8.95 | 11.19 | 13.42 |

tween an oil and a grease, too thick to be drawn out by absorption, yet soft enough and clinging enough to stay in the rollers. This mission is approximately fulfilled by a mineral grease, such as non-fluid oil, or Keystone grease, which are not affected by moderate changes of temperature, and have the clinging quality which animal greases lack. The makers of these greases, however, do not recommend heating them, and they cannot be introduced into the links and rollers of the chains, except by rendering them temporarily more fluid than they are desired to be in service. A very good lubricant for this purpose is made by dissolving Keystone grease in gear case oil, in amounts sufficient to produce a viscous fluid at the boiling point, which thickened when cold, and would just barely flow. A fairly liberal quantity of graphite was added, about half a cupful to three quarts of dope, and the chains after cleaning were boiled for half an hour or longer in the mixture to enable it to penetrate thoroughly.

* 3

Starting and Lighting Systems.


Four principal types of engine starters have een used; the air starter, the mechanical carter, the acetylene starter and the electric carter. Beginning with the production of 1916 ars, the electric starter is the only one found s standard equipment.

Acetylene starters were used by many cars 1913. This form admits acetylene gas from 1916 lighting tank to the cylinder that is ready if fire through a distributor valve. The passage f an ignition spark caused by operating a but on on the dash fires the gas and the force of 1918 explosion starts the engine.

Mechanical starters are found in many forms. hey consist of a mechanism through which the river is enabled to turn the engine crankshaft rough connections that lead to a handle or ver that may be reached from the seat.

Compressed Air Starters. In a typical airressure system the motor is operated with ompressed air until regular explosions take lace in the cylinders; the air supply is then out off and the motor takes up its regular perations.

The parts of this self-starter are as follows see Fig. 264): 1, a high-pressure, four-cyliner air pump, for compressing air in a storage ank; 2, a pipe for carrying air from pump to torage tank; 3, a pipe which carries air from



tank to push valve on the dash; 4, a pipe which carries compressed air from the push valve to the "distributor"; 5, pipes through which air is carried from the distributor to the various cylinders; 6, poppet valves—one in each of the cylinders—by means of which compressed air from the distributor is admitted to the cylinder ready for the working stroke; 7, a pressure gauge on the dash, which keeps the operator informed of the amount of compressed air in the storage tank; and 8, a pump clutch, operated by a foot pedal, which throws the gears of the air pump into mesh.

The air pump in this system is driven by a silent drive chain from the water pump shaft, and operates only when the gears are thrown into mesh by pressing the pump clutch foot pedal. It is a simple device for compressing the air and delivers a steady flow to the storage tank. A pressure of 50 lbs. in the tank will start the motor under ordinary conditions, but it is advisable to keep the pressure at about 150 lbs.

The storage tank is carried beneath the body of the car and is tested for a pressure of 600 lbs. to the square inch.

The dash push valve opens the air line from the storage tank to the distributor and simultaneously opens the cylinder valves so that air coming from the distributor through the pipes shown in Fig. 264 has ready access to the cylinders. When the foot is removed from the dash button, both the escapement valve and the cylinder valves are closed automatically and the compressed-air starter is shut off from the motor.

The distributor sends charges of compressed air into the cylinders ready for the working stroke, in their order of firing. It is geared to the pump and magneto shaft and positively timed for feeding air.

This type of self-starter is also used for the purpose of inflating tires by means of a special shut-off valve and hose.

The principle of compressed-air starters is to admit air under 50 to 150 lbs. pressure from a generous reservoir directly to the motor cylinders at the beginning of each expansion stroke. This operates the motor without affecting the mixture in the cylinders. When running under air pressure the admission of the compressed air at almost the moment of the spark operates the same as an ignition, causing a rise of pressure in the cylinder. After it has performed its work this pressure is released by the exhaust valve in the same manner as the burned gases are released when the motor is running under its own power.

Allis-Chalmers Equipment. The most commonly used type of Allis-Chalmers equipment makes use of a combined motor-dynamo, Fig.




Fig. 265

Allis-Chalmers Motor-Dynamo. E, Commutator. F, Brush Holder. G, Brush Connection. H, Brush Connection.

265, operating at six volts pressure for starting, charging and lighting. In addition to the motor-dynamo, the system includes the battery, a start-

ing switch and a separately mounted combined cut-out and regulator.

Pushing the starting switch connects the battery with the motor-dynamo, which then operates as a motor to crank the engine to which it is mechanically connected. The switch is then released after the engine fires. The motor-dynamo speeds up with the engine and, when it reaches a certain predetermined speed, is automatically connected to the battery and the lighting system by means of the cut-out. If the lights are burning, part of the current is used in lighting, the surplus going to charge the battery. When the engine slows down below the charging speed, the cut-out opens the circuit between the generator and battery.

By removing the cover band, the commutator may be examined. When in good condition it will show a glaze and will be dark brown in color. If the commutator appears dirty or greasy it should be wiped off with a clean cloth free from lint, slightly moistened with oil.

Do not disturb the brushes so long as the motor-generator appears to be operating properly. They should make good contact with the commutator and slide smoothly in the brush holders.


The purpose of the combined cut-out and regulator is to connect the generator to the battery when its voltage equals that of the battery, and to maintain a practically constant charging current with the widely varying speeds of the en-

gine. It also disconnects the battery when the motor-generator voltage falls below that of the battery, preventing the battery from discharging.

The regulator-cutout consists of a compound wound electromagnet with two armatures, one of which serves as the cut-out while the other regulates the charging current. The shunt regulator winding is always' connected across the generator terminals. When the generator voltage is sufficient for charging, the electromagnet attracts the armature, closing the circuit through the series coil of the regulator of the battery. The current flowing in the series coil then assists the shunt coil to hold the contacts together. With an increase in generator speed, the charging current will increase, strengthening the regulator electromagnet. At a certain critical point the second armature will vibrate, alternately cutting a resistance in and out of the generator field circuit, which will reduce the charging current by lowering the generated voltage. When the generator speed, and consequently the voltage, drops below charging value the reverse battery current flowing in the series winding neutralizes the shunt winding, releasing the armature and thus opening the circuit before the battery can discharge.

The internal connections and mechanism of the regulator-cutout are shown in the diagram, Fig. 266.

The regulator is provided with a fuse to pro-



Allie-Chalmers Motor-Dynamo Internal Connections

tect the system from excessive charging current, or an improper discharge through the starter, in case the regulator should not function properly. This fuse has a capacity of 45 amperes and carries the shunt field current as well as the battery charging current. The fuse, which is made of an especially hard alloy to withstand the high temperature near the engine, should always be replaced by one of the same make. If several fuses are blown within a short time, the regulator is probably out of order and should be replaced. This fuse does not protect the lighting and horn circuits.

To prove whether the motor-dynamo is charging the battery or not, remove the wire from the "BAT.+" terminal of the regulator and insert an ammeter between this terminal and the wire, with the positive terminal of the meter connected to the terminal of the regulator. With the engine running at about 60 revolutions per minute or higher, the meter should show a charging current of 10 to 18 amperes. If the meter shows no current, the motor-dynamo is either not developing any voltage or there is an open circuit in the charging line. To determine whether the motor-dynamo is developing any voltage, open the circuit at ammeter and then remove the wire from the "F L D" terminal of the regulator. With the engine still running as above, there should be quite a flash on removing the wire from the "F L D" terminal of the regulator. All these tests are to be made

with a good fuse in place on the regulator. If no flash is obtained on removing the wire from the "F L D" terminal, hold the wire on the fuse clip for a few seconds and note whether there is a flash on removing it. A flash here and none from the "F L D" terminal indicates a fault in the regulator. No flash from the fuse clip indicates a fault in the motor-generator. It is assumed here that the connections between the regulator and the motor-dynamo have been examined and found correct and sound.

If the motor-dynamo develops its voltage but still does not charge the battery, the fault is either in the regulator or the auxiliary contact of the starting switch. This can be located by connecting up the ammeter again as before, and with the engine still running hold a wire pumper in the hands and first connect the "DYN+" terminal of the regulator to the "BAT+" terminal. If the battery now charges, the fault is in the regulator. If no result is obtained, connect "BAT+" terminal of the regulator to the positive terminal of the battery. The charging of the battery now would indicate that the fault was in the starting switch.

The motor-dynamo should not be run with the charging circuit open, except for a minute or two at a time in making tests and not at all at very high speeds, as it would damage both the motor-dynamo and the regulator, and also the lights if turned on. If it is necessary to operate the car with the battery removed or with the

battery circuit open in any way, so that it cannot charge, the fuse must be removed from its place on the regulator.

Auto-Lite Equipment. These systems consist of separate unit dynamos and starting motors operating with a six-volt pressure in all




Fig. 267
Auto-Lite Dynamo With Permanent Field Magnets
and Clutch Governor

cases. The first models were of the permanent magnet type, that is to say, the dynamo field consisted of six powerful steel magnets without the usual coils, Fig. 267. These magnets were of the inverted U, or horseshoe, type, and underneath the arch thus formed was mounted an electromagnetic cut-out which closes the charging circuit whenever the dynamo voltage is suffi-

ciently high to charge the battery. This part of the mechanism may be exposed by removing the brush wires and taking out the plate that carries the positive and negative dynamo terminals.

This permanent magnet dynamo is driven from the engine by silent chain, but between the chain sprocket and the dynamo armature shaft is a form of slipping clutch governor contained in the drum seen at the left hand end of Fig. 267. The shell of this drum has its driving connection to the shaft by means of two shoes that are pressed outward by springs. weights are carried at or near the ends of corresponding arms inside of the drum, and when the armature shaft has reached a certain predetermined speed the centrifugal action of the weights overcomes the tension of the springs and the shoes release their hold on the shell. thus preventing an armature speed above the desired maximum, the voltage and output of the dynamo is held at a point suitable for battery charging.

A later form of Auto-Lite dynamo is shown in Fig. 268. This model retains the inverted U form of field magnet cores, but around the top of the magnet arch is placed a field coil housing and in this housing is a shunt and a reversed series field winding. The shunt field winding is attached between the brushes in the usual way, and the entire dynamo output passes out through the reversed series winding. This series winding being placed in such a way that

it opposes the action of the shunt, dynamo output above a certain point is made to overcome the field magnetism to such an extent that the amperage shows no further rise. The two dynamo terminals are seen on the front of the field housing and with this machine the electromagnetic cut-out is separately mounted, usually on the dash of the car.




Fig. 268 Auto-Lite Dynamo With Electromagnetic Fields

A third type of Auto-Lite dynamo is shown in Fig. 269. This machine is fully enclosed and has its fields placed above and below the armature. The field windings and regulation of output by means of the reversed series coil is the

same as in the type just described. The brushes and commutator may be exposed by removing the plate A.

Bijur Equipment. These systems are made in three distinct forms, two being six-volt separate unit dynamo and starting motor types, while the third is a combined motor-dynamo operating at twelve volts for both charging and starting.




Fig. 269
Auto-Lite Fully Enclosed Dynamo.


One of the six-volt systems makes use of a straight shunt-wound dynamo having a combined regulator and cut-out mounted in an aluminum housing on top of the dynamo case. Connected in series with the shunt winding is a coil of high resistance wire which is automatically inserted in the shunt field circuit by the regulator, this action keeping the voltage constant. The regulator consists of an electromagnet with its winding shunted across the

brushes, so that current always flows around the magnet when the dynamo runs, also the regulator contacts which are connected to carry the shunt field current around the resistance coil when they are closed. As the dynamo voltage rises, the magnet pulls the armature against the small spring and opens the contacts. The shunt field current then flows through the resistance and is so reduced that the field strength and voltage immediately fall. The low voltage reduces the strength of the electromagnet and the spring again closes the contacts, allowing the field current to avoid the resistance coil and raise the voltage. The regulator contacts vibrate this way at the rate of about 100 times a second and this holds the voltage at a point determined by the strength of the regulator spring or its tension.

The cut-out is electromagnetic with two windings and is carried in the same case with the regulator, this case being on top of the dynamo. All connections between dynamo, regulator and cut-out are made between the regulator housing and dynamo case and are not exposed. Two wires only come from the dynamo, one positive and one negative.

The dynamo wires end in a brass plug on one end of the regulator case. This plug may be rotated in its socket so that it makes part of a turn one way or the other. Turning this plug as far toward the engine as it will go makes one wire positive and the other negative, and turn-


ing it as far from the engine as it will go reverses this polarity. This reversal should be made every 500 miles, being sure that the plug is turned as far as it will go so that it locks in place. This action reverses the polarity of the dynamo and prevents pitting of the contacts.



Bijur Wiring Diagram for Voltage Control System

After adjustments are made the regulator box is sealed at the factory and the maker's instructions say not to open it. The entire box may be removed from the dynamo by unscrewing the small milled nut on top, the connections between the cases being made with split pins. Lights and starter will run from the battery while the regulator is returned to the makers for repairs. A complete wiring diagram for this form of Bijur apparatus is shown in Fig. 270.

In Fig. 271 is shown the application of another form of six-volt separate unit system.



This dynamo has no controller box as has the one just described, but the shunt field winding

is connected to an additional brush bearing on the dynamo commutator. This brush is for the purpose of limiting the dynamo amperage and is so placed in relation to the main brushes that the current passing into it, and thereby into the shunt field, diminishes with increase of speed. The normal tendency of the output to increase with the speed of rotation is therefore counteracted and a safe maximum is maintained. This is the form of regulation known as "third brush."

The electromagnetic cut-out for this system is mounted inside of the brush and commutator end of the dynamo case. This end of the machine is closed by a removable brass band, and through the openings left with this band removed the working parts of the machine may be inspected. Mounted on the outside of the dynamo case, and connected in series with the field windings, is a small fuse which will blow out whenever the current passing through the fields becomes excessive. This fuse will protect the dynamo in case of a broken circuit between dynamo and battery or lamp lines.

Separate starting motors of Bijur make may drive to the engine through an overrunning clutch, through direct acting spur gears or by means of a Bendix screw. With the Bendix screw, a single contact starting switch is used which sends the full battery current to the motor when the switch is closed. With the spur gear drive, the starter switch makes a preliminary

contact through a resistance coil and continued movement of the switch pedal and plunger closes the contacts that short circuit the resistance and send the full battery current through the motor. The same operation that meshes the starting gears moves the switch plunger.

Bijur motor-dynamos operate at twelve volts and have their output controlled by the "third brush" system as explained for the type just described. Drive is direct to the engine crankshaft through a silent chain. No cut-out is used, but when the motor-dynamo is connected to the battery by means of the starting switch, the switch is allowed to remain closed and the increasing speed of the unit when driven from the engine causes the voltage as a dynamo to rise to a point that recharges the battery. When the car is operated at a speed below about ten miles an hour, the dynamo voltage falls below that of a battery and the unit again becomes a starting motor. A neutral position is provided on the starting switch for use when the car is being driven at low speeds or when the engine is idling. With the switch in this position the motor-dynamo is disconnected and battery discharge is prevented.

Bosch Equipment. The dynamo is shown in Fig. 272 and is used in connection with a starting motor of the Rushmore type and having the Rushmore form of drive to the flywheel.

The dynamo is a separate unit, shunt wound, delivering 12 volts with a maximum output of

8 to 10 amperes at high car speeds with a partially discharged battery.

A box mounted on the dash carries a voltammeter, voltage regulator, cut-out, lighting and ignition switches and fuses. A small lever is moved to cause the meter to show either volts or amperes on the same meter.



Fig. 272 Bosch Dynamo

Regulation acts to maintain a steady voltage. The regulator consists of a small cylinder of carbon particles with one end of the shunt field winding connected to one end of the carbon pile and the corresponding dynamo brush connected to the other end of the carbon. The shunt field current thus passes through the carbon. The carbon particles are held tightly compressed by a plunger fitting inside the cylinder with a coil spring holding the plunger down. Under this condition the resistance of the carbon is very low and allows practically the whole of the

shunt field current to pass without interruption. An electromagnet forms part of the regulator and is connected in shunt across the dynamo brushes so that its strength increases with the rise in voltage. This electromagnet acts to pull up on the plunger against the action of the spring, and as the voltage rises the pressure on the carbon is lessened in this way and the resistance of the carbon pile increases rapidly as the particles are loosened. This resistance in the field lowers the voltage and output.

٦,

An electromagnetic cut-out is carried in the dash unit housing with the voltage regulator. These systems make use of the single wire, ground return method of wiring. The starting cable is, however, covered with a copper sheath that assists in carrying the return current to the battery.

Delco Equipment. A majority of Delco applications have been of the motor-dynamo type, this method being departed from for the first time on some of the applications made on 1916 cars. The first Delco system to be used consisted of a motor-dynamo that operated as a starter at 24 volts and charged to six volts for lighting and battery charging. The battery for this system consists of twelve cells divided into four sections of three cells each. By means of a two position multiple contact knife switch carried in the battery box, these sections were placed in series for starting and in parallel for lighting and charging.

complete charging circuit diagram is shown in Fig. 273.

The battery charge is controlled by a form of wattmeter, called an ampere-hour meter. Current flowing into the battery causes this meter to revolve in one direction and current





Fig. 273
Charging Circuit of Delco 6-24. Volt System

flowing out of the battery causes it to revolve in the opposite direction. After a certain flow has entered the battery, the meter has moved to such a position that a resistance is inserted in the shunt field winding of the dynamo and the rate of charge is thereby reduced. Further




movement of the meter in the same direction opens the shunt field current and further battery charge is prevented. Withdrawal of current causes the meter to reverse this movement and the field circuit is first closed through the resistance and the resistance is then cut out entirely, allowing a resumption of full battery charge.

Fig. 274 shows the complete circuit diagram for this system. The magnetic latch is for the purpose of allowing the driver to close the starting switch and mesh the motor gears with the flywheel when the clutch pedal is depressed. By means of a small push button, usually on the heel board, the latch magnet is energized and the latch itself connects the starting gearing with the clutch pedal. Depression of the pedal then causes starting action as described. The application of this system on a car, with external wiring shown, is seen in Fig. 275.

A form of Delco motor-dynamo having two separate commutators and two sets of brushes is shown in Fig. 276. One of these commutators is for the dynamo generating action, while the other is for starting.

When the unit is generating current for charging the battery, for lights and ignition, it is a simple shunt wound generator. It is driven from the engine by an extension of the pump shaft. The generator is driven at one and one-half crankshaft speed, and in order to compensate for the higher ratio when the








Fig. 276

Delco Motor-Dynamo With Starter Switch Mounted Above Flywheel Drive Gearing. A, Oil Hole. B, Oil Hole. C, Grease Cup. D, Gear Shift Yoke. E, Switch Operating Rod. F, Switch Spring. G, Flywheel Gear. H, Motor Pinion Gear. I, Clutch Shaft. J, Shift Yoke Rod. K, Tripping Collar. L, Contact Block Latch. M, Contact Block.



unit is in starting relation to the engine, a second one-way clutch is provided adjacent to the forward housing. This clutch permits the armature to run ahead of the driving shaft during the cranking operation.

Fig. 277 illustrates the Delco "Junior" motor-dynamo and the starting switch is shown



in Fig. 278. These units cannot well be shown in their actual locations and are therefore shown separate. Referring to Figs. 277 and 278, the yoke H fits into the collar I which is pinned to the rod D. The movement of the rod from the starter pedal operates the gearing and the starting switch.

When the starting pedal is pushed down it pulls back the rod D and closes the contact E, which completes the circuit between the battery and dynamo armature. The closing of the circuit causes the armature to revolve slowly so that the gear J will mesh with the motor pinion as it slides along on its shaft. As the starting pedal is pushed further down it continues to pull the rod D, which opens the contact F, breaking the circuit between the battery and dynamo armature. This action of the rod at the same time causes the motor brush switch to drop onto the motor commutator, and the train of gears to slide on its shaft until in mesh with the motor pinion and the teeth on the flywheel.

The motor brush dropping on the commutator causes the circuit to be closed between the storage battery and the motor armature, which causes the motor to crank over the engine.

When the starting lever is released the motor switch brush is raised from the motor commutator and the train of gears is thrown out of mesh, when the contacts F will automatically close.

If the speed of the motor generator is above 350 revolutions per minute, the cut-out relay, Fig. 279, will close the circuit between the storage battery and motor generator, thus permitting the generator to charge the storage battery. If the speed of the motor generator is less than 350 revolutions per minute, the cut-out relay will remain open and all current for

ignition and lights, if they are in use, will come from the storage battery.

Oil is conveyed to the ball bearings through oil cup B and the small hole A in the front end cover. This hole is made accessible by removing the upper front end cover. At the time 4 or 5 drops of light oil are put in the oil cup B and the hole A, the grease cup C should be




Fig. 279
Delco Reverse Current Cut-out


given 1 or 2 turns or replenished if empty.

The cut-out relay, Fig. 279, is located in the rear end housing of the generator. This instrument closes the circuit between the generator

and the storage battery when the generator voltage is high enough to charge the storage battery. It also opens the circuit as the generator slows down and its voltage becomes less than that of the storage battery, thus preventing the battery from discharging back through the generator. The cut-out relay is an electromagnet with a compound winding. The voltage coil or fine wire winding is connected directly across the terminals of the generator. The current coil, or coarse wire winding, is in series with the circuit between the generator and the storage battery, and the circuit is opened and closed at the contacts A. When the engine is started, the generator voltage builds up and when it reaches about six volts a current passing through the voltage winding produces enough magnetism to overcome the tension of the spring B, attracting the magnet armature C to core D, which closes the contacts A. These contacts close the circuit between the generator and storage battery. The current flowing through the coarse wire winding increases the pull on the armature and gives a good contact of low resistance at the contact points.

Delco systems used during 1915 consist of single armature motor-dynamos, one application of which is shown in Fig. 280. The armature carries two commutators, one on each end or both on the front end, the rear end commutator being for the starting motor action.

Two separate field coils are used; a shunt for



280 Delco Starting and Lighting System.

the dynamo action and a series for the starting motor action. These coils are both on the same field magnet core and have separate terminals.


The drive as a dynamo is from the rear extension of the pump shaft through a roller overrunning clutch which releases when the armature turns at high speed as a starting motor.

The starting motor drive is through a pinion on the rear end of the armature shaft to a ring gear on the flywheel. Two gears, fastened together, are free to rotate as a pair on an auxiliary shaft, the gears being slid along this shaft by a yoke connected to the starting pedal until one is in mesh with the armature shaft pinion and the other with the flywheel gear, completing the drive connection. A roller clutch is incorporated in the front one of the pair of sliding gears, this clutch releasing while the armature is being driven as a dynamo.

Starting switch action is secured by normally holding one of the motor commutator brushes away from the commutator by means of a rod connected to the starting lever or pedal. When the lever or pedal is moved this rod is drawn back so that the brush drops onto the commutator under the action of its spring, completing the circuit from the battery through the series winding and armature. This rod is fastened to the sliding gears so that they must be in mesh before the brush can drop.

The dynamo brush that is grounded completes its connection to ground through a pair

of contacts, one stationary and one movable. Fig. 281. The movable contact is attached to an arm on the movable starter brush in such a



Commutator End of Delco Governor Controlled Motor-Dynamo

way that the contacts open as the starter brush drops onto the commutator. This prevents dynamo action while the armature is acting to start the engine.

No fuses are used, but there is a magnetic circuit breaker, the electromagnet of which acts to open the contacts from the battery and dy-




Fig. 282

Governor and Overrunning Clutch Mechanism of Delco Motor-Dynamo

name to the lamp and car wiring when 25 amperes flow. After the circuit breaker opens the contacts continue to vibrate open and closed if

there is a flow amounting to five amperes. The circuit breaker will not stay closed until the ground or short circuit that is causing the leak of current has been removed. The spring of this current breaker should not be adjusted in any way as it is a safety device.


Delco systems may have any one of three different systems for regulating the dynamo output. One type consists of a differential or bucking coil carried on the field magnets and connected in series with the main line from the dynamo brush to the dash switch unit.

Another method makes use of a coil of resistance wire carried on a spool in the front end of the dynamo case on the right hand side, Fig. 282. One end of the shunt field winding is grounded through this resistance coil so that the field current would have to pass through the coil. This high resistance would allow but little flow and would weaken the field to such a point that the output would be very low. When the dynamo is running at low speeds the field current, after passing to the lower end of the resistance coil, goes to the ground through an arm making contact with the coil. This arm carries a contact which slides up and down on the resistance coil, the arm being moved by a centrifugal governor attached to the ignition distributer shaft. As the dynamo speed increases, the governor weights cause the movable arm to raise so that its contact is farther from the bottom of the resistance coil, and the field current must consequently flow through a greater length of resistance wire before reaching the contact on the arm and passing to the ground. This greater resistance in the shunt field circuit allows less current to flow and by thus weakening the field cuts down the dynamo output at high speeds.

The third system of regulation also causes the shunt field current to pass to the ground through a coil of resistance wire. This resistance coil is wound on a spool and the spool is carried at one end of a rod, the other end of the rod forming the plunger of a solenoid coil. The strength of this solenoid increases with the voltage, being connected in shunt with the brushes. Increased strength of the solenoid pulls the plunger farther into the coil. This solenoid coil is in the upper end of a cylindrical housing, and the resistance coil is carried below the solenoid. The plunger and resistance are normally in a low position but are raised by the solenoid action. In the low position the resistance coil lips into a well partly full of mercury so that the shunt field current does not have to pass through all the resistance wire but passes into the mercury and to the ground from a contact fastened to the mercury well. As the voltage rises the solenoid becomes stronger, lifting the plunger and pulling the resistance coil up out of the mercury well so that the shunt field current must flow through a greater length of resistance wire before reaching the ground. This added resistance allows less current to flow through the shunt field and consequently lowers the field strength and the output of the dynamo.

Delco systems use either of two methods of reverse current cut-out. One type comprises a dash switch with five buttons. The three lefthand buttons are for the lights, the two righthand being for the ignition. The button on the extreme right is for the storage battery ignition, the one next to it being for the dry cells. Each of these buttons carries two contacts inside the switch, one completing the ignition circuit and the other completing the charging circuit. When the engine is to be started either of the ignition switches is pulled out. The current then passes from the battery to contact (1) on the switch, through the inner connection of either dry cell (Bat.) or storage battery (Mag.) switch and out of terminal (6) to the shunt dynamo winding and armature brushes. causes the dynamo parts to act as a motor of very low power and the armature revolves slowly so that the starting gears can be meshed. As soon as the gears are meshed the motor brush drops onto its commutator and completes the starting circuit while breaking the dynamo circuit as described before. The battery current will then cease to flow through terminal (6) but will flow through the circuit breaker, whose points are held closed by a spring, and through the other connection on the switch button plunger, out through terminal (7) and to

The Automobile Handbook



the ignition coil. If the "Bat" button is pulled out the dry cell current comes into terminal (2) and out through (7) to the ignition coil. When the engine has been started and the dynamo generates a voltage greater than the battery, current will flow from the dynamo through the differential winding (if one is used) into terminal (6), through the inner contacts of the switch and out through (1) to the battery. If the ignition switches are left closed with the engine idle the battery will discharge through the switch contacts and dynamo parts, these switches acting as the cut-out with the dynamo and engine idle.

The construction of Delco apparatus used during 1916 differs from that already described in one important particular. The output of the dynamo when charging the battery is controlled by the "third brush" principle.

One of the applications is shown in Fig. 283 and it will be noted that the armature and field location, starting drive and ignition mechanism is similar to the forms previously used. The brush position is shown in Fig. 284. The action is explained as follows: The full voltage is obtained between the large brushes and the voltage between the left hand large brush and the small regulating brush is less than the full pressure. This reduced voltage is applied to the field coils. With the armature rotating, the magnetic field is twisted out of its normal path between the pole pieces, the degree of deflection

sing in direct ratio to the increase of speed. his deflection causes the magnetic flow to be-





Fig. 284 Brush Mechanism of Delco Motor-Dynamo

ome weaker at the points on the pole pieces at affect the flow into the "third brush" and is weakened field current compensates for te higher output that would otherwise be aused by increase of speed. Fig. 285 shows ie starting motor end of this same machine.

Another application of the third brush dy name does not make use of the motor-dyname



Motor Brush Switch Connections of Delco Motor Dynamo

combination, but uses a separate series wound motor driving to the flywheel through a Bendit screw.

Dyneto and Entz Equipment. These incallations make use of a combined motor-dyamo operating with twelve volts in some cases and with eighteen in others. A compound field inding is used, series and shunt coils acting




Fig. 286
Five Terminal Dyneto-Entz Motor-Dynamo

gether in starting and forming a reversed ries controlled machine in generating. The versal of the direction of flow through the ries field while generating causes this winding oppose the shunt winding at high armature seeds and the dynamo output is thereby limitl to a safe maximum. Dyneto and Entz outfits do not make use of a cut-out of the usual form. The motor-dynamo is placed in circuit with the battery when the starting switch is closed and this switch is left closed as long as the machine operates. As soon as the unit has started the engine, the





Fig. 287
Four Terminal Dyneto Motor-Dynamo

engine causes the armature speed to increase to a point at which the voltage is greater than the battery and charging then commences. If, at any time, the armature speed falls below a certain point the machine again resumes its action as a starting motor.

The ignition is controlled by the same switch that makes the battery and motor-dynamo circuit. With this switch in the "Off" position, the ignition is inoperative and the battery is disconnected from the motor-dynamo. With the switch in the "On" or "Running" position, the ignition is on and the battery is connected to the electric machine. A switch position midway between the two mentioned is provided, this position being called "Neutral." With the switch at "Neutral," the ignition is operative but the motor-dynamo circuit is open so that the battery will not discharge, and the machine will not act as a starting motor at low engine speeds.

The number of terminals differs on various types; one with five connections being shown in Fig. 286 and another unit with four terminals being illustrated in Fig. 287.

Gray & Davis Equipment. The type of equipment used from 1912 to 1914 is described below. This system comprises two units: 1, the starting motor; 2, the dynamo for charging



hattery and lighting. The function of the dynamo is to furnish current for lamps and current for the battery. The starting motor starts the engine. This motor is connected with the flywheel by gears, and when a starting pedal is


pressed the motor turns the flywheel and crankshaft and keeps turning until the engine "picks up." The starting motor then automatically ceases to operate.

The dynamo system includes the following:

1, a constant-speed dynamo, driven from the engine or jackshaft by gear or a silent chain;


2, a governor, to take care of the varying speed of the engine; 3, an electric cut-out, to disconnect the dynamo from the battery when running below the charging speed; 4, a battery to operate the lights when the dynamo is not running at the necessary speed or when the engine is stopped. This battery may also be used for firing the engine.

- 1. The dynamo is of the compound-wound type, designed to run at a constant speed of 1000 revolutions per minute. The system is so wired that the series field is carrying current only when the lights are burning. See Fig. 289.
- 2. The governor is of the simple, centrifugal type, but operates a friction clutch of new design. In operation the clutch slips just enough to hold the dynamo speed always at 1000 r. p. m., whether the engine speed corresponds to a car speed of 13 or of 60 miles an hour.
- 3. The electric cut-out consists of an electro-magnet with a compound winding, the fine wire part of which is connected across the dynamo terminals. Its function is, as stated, to disconnect the dynamo from the battery when the engine is running very slowly or is at rest.




n automatic switch of this nature were not the circuit the battery would discharge ugh the dynamo when the dynamo was no er maintaining charging voltage.

A battery rated at 6 volts, 80-ampere



r capacity at a discharge rate of 8 amperes irnished with this system sufficient to carry full lamp load for ten hours or the side and lamps for thirty hours. The arrangement of the switch connections is such that the dynamo operates as a shunt-wound machine while charging the battery and as compound-wound when supplying the lamps directly. This gives the battery a tapering charge.




The wiring for this system is plainly shown in the accompanying diagram. See Fig. 289.

The newer models of Gray & Davis equipment make use of a separate dynamo or ignition-dynamo with a combined output regulator and cut-out carried in a housing on top of the unit.

The interior construction of the dynamo is shown in Fig. 291, the particular model illustrated being arranged for carrying an ignition head at the drive end and providing a spiral gear drive.

The cut-out and regulator are in the same case and the one large electromagnet operates both. This magnet carries two windings, shunt and series. When the dynamo is idle the cutout contacts are open and the two regulator contacts are closed, being held that way by their respective springs. Fig. 292. Current enters the shunt coil of the controller through the grounded end and down through the terminal A to the negative brush, thus receiving current from between the brushes whenever the dynamo runs. When the voltage rises to a point in this coil so that the magnet overcomes the tension of the cut-out spring the cut-out contacts close. Current which has passed from the grounded positive brush of the dynamo through the battery in charging, returns to the terminal B and passes through the entire length of the series coil on the magnet before going through the cut-out contacts to the terminal A and negative brush. Current which has passed through the lamps returns to the terminal L and through only a part of the series coil on the magnet



Internal Connections of Gray & Davis Vibrating
Regulator System

before reaching the negative side. The more lamps are turned on the more current they take and the less current is left to pass through the battery. It will therefore be seen that if enough lamps were turned on to leave nothing going through the battery the part of the series coil between L and B would carry no current and the strength of the magnet would be weakened. For the same reason it will be seen that the more lamps turned on the weaker this coil and magnet become. This is part of the regulator action as will be explained.

The regulator action is as follows: Current passes from the positive brush through the shunt field and into the terminals F and F1, then through the regulator contacts which are closed and back to the terminal A to the negative As the voltage passing through the shunt magnet coil increases after the cut-out has closed, its strength finally reaches a point where the tension of the regulator contact spring is overcome and the contacts are pulled open. The current from terminals F and F1 must now return to the negative brush through the resistance wire coils seen between the two regulator contacts, this resistance retarding the flow and weakening the dynamo fields and consequently lowering the output and voltage until the weakened magnet allows the regulator contacts to again close. This action causes these contacts to vibrate and keep a steady output. As explained above, the strength of the magnet is decreased as more lamps are turned on, so that the regulator contacts remain closed for a longer time, and, as the resistance is not in the field when they are closed, the output is allowed to rise to care for the added lamp load.

The cut-out is of the simple electromagnetic type. The action of the regulator allows the battery to receive a small charge even with all lamps on.

Removable plates cover either side of the dynamo, allowing access to the inside without disturbing any parts or wires.

A charge indicator is located on the dash or cowl. The pointer turns upward if current is passing to the battery and downward when current passes out of the battery for any purpose. If the pointer is straight across the battery is neither charging or discharging. This indicator should show charge at car speeds above 10 to 12 miles per hour.

The output of the dynamo may be tested by turning on all lamps and disconnecting the wire from terminal B. The lamps are then burning directly from the dynamo and if they go out the dynamo is at fault.

The regulator and cut-out may be tested by connecting a wire from terminal A to terminal B while the engine runs at a speed which would correspond to a car speed greater than 10 miles per hour. If the indicator then shows charge when it failed to show this before the test the cut-out or regulator is at fault. If the indi-

cator remains straight across something is preventing the dynamo from delivering its current.

The lighting switch is of the rotary snap type and carries all lamp and circuit wires on the engine side. On the back of the switch are four fuses in clips. Near the fuses are letters H, S, R and B, indicating the fuses for head, side or dimmer, rear and tail, ignition and horn circuits respectively.




Fig. 293 North East Motor-Dynamo

The starting motor drives into a flywheel ring gear or crankshaft through sliding reduction gearing and overrunning clutch. The starting switch pull rod operates the sliding gear through

a coil spring so that switch contacts may close whether gears are in position to mesh or not, the first turning of the armature causing the gears to snap into mesh under the action of the compressed spring. One side of the starting switch may be grounded or the lead from the positive motor brush may be grounded. In either case two wires lead to switch and starting motor.

North East Equipment. This starting and lighting system makes use of a combined motor-dynamo having two field windings, a shunt and series. The series field is used for starting and the two fields compound for generating. One of these units is shown in Fig. 293.

The brushes and commutator may be exposed by removing a cover from the end opposite the drive. The upper part of this cover, which encloses the brushes, is held in place by spring clips, but the lower half is fastened with bolts that are sealed at the factory. This lower half encloses a combined cut-out and regulator. The cut-out is of the electromagnetic type and serves to connect the dynamo with the battery when the generating voltage is sufficiently high to make charging possible, also to disconnect the battery when the dynamo voltage falls below that of the battery.

The regulator is of the vibrating reed type, having two sets of contacts operated from one electromagnet. The current output of the dynamo passes through the winding of the regu-

lator electromagnet and causes the contact to open when the amperage has reached a certain predetermined limit. With the contacts open, the field current, which has previously passed through the contacts, must flow through two spools of resistance wire. The consequent reduction in field current prevents further rise in output.

North East equipment is of the two voltage type, the starting voltage being either 12, 16 or 24, while lighting and charging is accomplished at 6, 8 or 12 volts. Starting and charging circuits are of the two wire type, while lighting circuits may be either one wire with ground return or two wire throughout. A field fuse is carried in the brush and commutator compartment of the motor-dynamo, this fuse blowing out should the battery or charging lines become disconnected while the motor-dynamo is operating.

The unit is driven from the engine and drives to the engine through a silent chain, with or without spur gear reduction.

Remy Equipment. Remy apparatus consists of a variety of types, each one suited to the particular requirements of the cars to which it is applied. A complete internal circuit diagram of one of the separate unit systems with separately mounted regulator and cut-out is shown in Fig. 295.

Remy equipment may be made up of all separate units for lighting, starting and igni-

tion, with or without Remy magneto or battery ignition. The separate unit systems all make use of a shunt wound dynamo of 6 volt output. The separate motors, Fig. 294, are of four pole, series wound type and operate on 6 volts.

A separate dynamo may be driven from a shaft to the timing gear case and have one of the separate motors mounted above it, forming





Fig 294
Remy Starting Motor With Bendix Drive

a "double deck" instrument. The dynamo would be two pole shunt wound and the motor four pole series wound, both 6 volts. The motor drives down to the main shaft through two pair of spur reduction gears, the large gear on the main drive shaft carrying an overrunning clutch which runs free while the starting motor operates.



Another Remy system makes use of a motor dynamo with only one armature. This machine is of the four pole type, compound wound and operates with 12 volts. No overrunning clutch or device taking its place is used with the single armature motor dynamos, these being direct connected in all cases.

Remy dynamos are also built with a magneto type breaker mounted on one end of the armature shaft with a magneto distributer carried above it, thus forming a combined dynamo-ignition outfit. The dynamos in this case are of the two pole shunt wound type operating with 6 volts. These machines are positively driven at engine speed in four cylinder cars one and one-half times engine speed in six cylinder cars and twice engine speed in eights. A separate 6 volt starting motor is used in connection.

The 12 volt motor-generators (as described) are also built with the ignition breaker and distributer added, forming a single unit having the functions of starting motor, dynamo and igniter in one.

Wiring for lighting, charging and starting circuits may be either two wire or one wire with grounded return. Switches, current indicators, junction boxes and dimmer resistance units vary with the make of car.

Regulation of the amperage is accomplished in either of two ways. One method is by the third brush being below one of the main brushes F

on the left side facing the commutator. This brush takes current to one end of the shunt field winding, the amount of current flowing through this brush becoming less and less as the speed increases. The position of the brush is not adjustable.

The other method of regulation consists of an electromagnet carried in the same case with the cut-out and operating to insert a coil of resistance wire, also carried in this case, into the shunt field circuit as the amperage rises.

The cut-out is of the electromagnetic type with two windings, shunt and series. The circuit should close in the neighborhood of ten miles per hour, preferably at lower speeds. The cut-out mechanism or combination of cut-out and regulator may be mounted on the dynamo housing at the drive end over the armature shaft or as a separate unit on the dash or other convenient location.

The current output should be about 7 amperes at $8\frac{1}{2}$ to 12 miles per hour, rising to a maximum of 10 to 14 amperes, depending on the installation.

Starting motor drive may be through reduction gearing inside the housing as described for the double deck instruments; or by chain with overrunning clutch on separate motors but without the clutch on motor-dynamos. Separate motors also use the Bendix type of inertia pinion drive.

Starting switches are of two types, both making the circuit complete without preliminary contacts. One uses the conventional type of tapered plunger, the other uses copper bands sliding on two cylinders, the cylinders being made of insulating material and carrying contact bands in such a position that the sliding rings complete the circuit from one cylinder to the other when fully depressed into position. Either switch may act by push or pull rods or foot buttons.

Fuses for each of the lighting lines are carried in the lighting switch. A 20 or 25 ampere fuse in circuit with the dynamo field is mounted above the magnet in separate cut-outs or on the base of combined regulators and cut-outs.

Rushmore Equipment. The Rushmore system was originally manufactured by the Rushmore Dynamo Works, but this company is now a part of the Bosch Magneto Company, and the product is known as "Bosch-Rushmore" and "Bosch." The several unique features found in this equipment are described on the following pages:

The Rushmore Engine Starter. The Rushmore electric starting motor, shown in Fig. 296, acts directly on the flywheel without intermediate gears, a pinion keyed fast on the motor shaft meshing with a gear on the flywheel rim. This pinion is normally out of engagement. The closing of the starting switch causes the pinion automatically to engage the flywheel gear before the armature starts rotating. As soon as the engine picks up, the pinion automatically slides out of mesh, and remains out no matter how long the starting switch is held closed. There is no mechanism except the starting motor itself and the starting switch.

When the starter is not in use the armature is held normally out of line endwise with the pole pieces by means of a compression spring contained in and acting against the hollow armature shaft. Magnetic pull is employed to engage the pinion. The foot button starting switch has three contacts. At the first pressure upon the button the armature is drawn into the field with great force while rotating slowly so that the pinion teeth will engage. After the gears are fully engaged the third

contact applies the full force of the battery to turn over the engine.

The motor is series wound and produces a strong torque on starting. As soon as the en-




Fig. 296-Rushmore Dynamo and Starter on Simplex Engine.

gine picks up, the accelerated speed causes the counter electro-motive force in the motor to reduce the current flow to a value too small to hold the armature in line with the pole pieces against the end pressure of the spring. The

pinion then slips out of mesh and remains out, even with the circuit closed, because the current required to run the motor free is too small to overcome the spring. The armature will not again move endwise into its working position until it has stopped and the switch is again closed. The turning force developed at the flywheel rim is rated at over 400 lbs., suffi-




Fig. 297—Diagram of Rushmore Lighting System.

cient to start the largest engine with ease. The motor is wound for a 6-volt battery.

RUSHMORE LIGHTING SYSTEM. Essential elements of this system are: 1, the dynamo; 2, storage battery, 6-volt, of 80 to 160 ampere hours capacity, depending upon size of the headlights; 3, switch and terminal block on

dashboard, which simultaneously switches the headlights on or off and switches the ballast coil in or out of circuit; 4, wiring and circuit switches for small lamps.

Briefly the action of the dynamo is to reduce the strength of the field magnet at high speeds by means of counter excitation produced by a few turns of magnet wire, called a "bucking coil," on the field poles. The amount of current passing through this bucking coil is determined automatically by the varying resistance of a small coil of iron wire, called the "ballast coil," which is made in the form of a cartridge fuse and carried in clips on the switchblock in the main line between the dynamo and the battery. See Fig. 297. The effect of controlling the bucking coil by the current output is to produce an approximately constant current at the higher speeds.

Simms-Huff Equipment. This apparatus as generally mounted consists of a combined dynamo and motor with separate magneto ignition. One wire system with a grounded return for all circuits is used.

The motor dynamo is of the six pole type and has a differential compound winding. It generates 6 volts as a dynamo and operates with 12 volts as a motor. The drive for dynamo purposes is by belt from the fan pulley and crankshaft. When operated as a motor the engagement is through a pinion which slides on a counter shaft between the armature shaft

and flywheel ring gear and completes the mechanical connection.

The starting switch which makes the necessary changes in connections for charging or starting is located on the transmission case and the operating parts also act to slide the gears into mesh through the action of a stiff coil spring. Should the gears not match exactly, the spring compresses and allows the switch to close when the first movement of the armature under the




Fig. 298 Simms-Huff Motor Dynamo

starting current brings the gears into position and the compressed spring forces them into full engagement.

Regulation of output is maintained at a sufficiently high value (15 amperes maximum) by adjusting the tension of the driving belt. Excess-output is prevented by the differential ac-

tion of the reversed series field winding and by a separate regulator having an electromagnet which acts to insert resistance in the shunt field winding with rise of amperage. This electromagnet regulator is carried in a housing with the cut-out. The output is adjustable by changing the tension of the flat spring.

The cut-out is of the electromagnetic type having two windings and the time of opening and closing is adjustable by a small screw.

Two 6 volt, 35 ampere hour batteries are carried in one box under the front seat, being connected in series for starting and parallel for lighting and charging. A combined lighting and ignition switch is carried; inserting the plug turns ignition on.

Headlight dimming resistance is carried on the engine side of the switch and an ammeter switch and an ammeter is mounted on the dash.

Splitdorf-Apelco Equipment. The electrical unit for these equipments is shown in Fig. 299, and its connections with the balance of the apparatus is shown in the wiring diagram, Fig. 300. The wiring shown applies to the equipment operating at 12 volts for starting and 6 volts for charging and lighting.

These systems use a combined motor dynamo which may also carry an ignition breaker and distributor on a separate vertical head driven from one end of the motor dynamo unit. The system is therefore of one or two unit type, no separate starting motors being used. A

dynamo which does not act as a starting motor is used on the Stanley steam car. All gas cars use motor dynamos.

The unit has four poles, three windings on the fields. One coil is ordinary shunt and acts as





Fig. 299 Splitdorf-Apelco Motor-Dynamo

a shunt in both generating and starting. The output is controlled by a separate bucking coil through which all current from the dynamo passes, this opposing the shunt more and more as the speed, voltage and amperage increase. The third coil is a series winding for starting

motor action, though it also assists the shunt while generating, making a compound dynamo with bucking coil and a compound motor.



Two voltage combinations are used. One charges the battery and starts on 12 volts, using a six cell battery with all cells in series for

charging, starting and lighting. This is called the straight twelve system.

The other system uses a six cell battery divided in two sections of three cells each and is charged with the two parts in parallel at 6 volts. This system uses all cells in series with 12 volts for starting while lighting is from the parallel connections, thus giving 6 volt charging and lighting and 12 volt starting, the proper connections and changes being made in the starting switch. This is the twelve-six volt system.

Both types use separate electromagnetic cutouts mounted on the dash in all cases. cut-out carries two windings. The movable arm carries a marker which shows the word OFF on a dial whenever the contacts are open and the word ON whenever the contacts are closed. ON simply indicates that the current is flowing from the dynamo, but according to the number of lamps turned on it may be going to the battery or to the lamps or may be dividing between them. The engine speed at which the cut-out opens and closes may be changed by small screw passing through the cut-out spring. This screw may be turned to either lessen or increase the spring tension, thus lowering the cut-in speed or raising it accordingly.

The dynamo without starter action is a four pole shunt wound machine operating at 6 volts. Regulation is with a third brush which carries all the current flowing to the shunt field.

U. S. L. Equipment. Two distinctly different types of equipment have been marketed by the United States Light and Heating Company. The first type, which is described first, was used up to and including part of the year 1915. This type comprises a motor-dynamo mounted on the engine crankshaft with the controlling elements, cut out and regulator, carried in a housing on the driver's side of the dash board.

The type referred to above is known as the "external regulator" type, while the newer system is the "inherently regulated" type. This newer system makes use of a cut out on the dash, but secures regulation of current output by allowing the dynamo current, when excessive, to react ou part of the field, and by reducing the field magnetism in proportion to the speed and output, a proper rate of dynamo charge is maintained.

U. S. L. ELECTRIC MOTOR GENERATOR. In the system employed by the United States Light & Heating Co., with which many automobiles are now equipped, an electric motor generator is an integral part of the gasoline motor and furnishes current for starting and lighting. The system includes, besides the motor generator, an automatic current regulator, an oil switch and a storage battery.

The motor generator comprises a set of field coils, armature and commutator and brush ring. These parts replace the flywheel of the gasoline motor, being attached to the crank-

shaft in its stead. They are inclosed in an aluminum case and dust ring.

When a starting button is pressed down, the current from the storage battery starts the




Fig. 301-U. S. L. Gasoline Electric Motor Complete.

motor generator. This revolves the crankshaft of the gasoline motor. With the switch of the 'gnition coil in either magneto or battery position, the gasoline explosions commence. The foot starting button is then released, when the




Fig. 802-Wiring Diagram of U. S. L. Starting System.

electric motor automatically changes into an electric generator. As the speed of the gasoline motor increases, the generator gradually begins charging the battery, restoring the current discharged during the starting operation.

An automatic regulator, controlling the current to the battery, is located in the center of the dash. It has a charging indicator, the function of which is to show that the circuit is closed at the proper time, or at a speed of 12 to 14 miles an hour, and that the circuit is open when the car speed drops below about 10 miles an hour or the motor stops altogether. The regulator consists of a compound-wound magnet and a variable resistance with magnet bar and contacts for controlling field current in the generator.

The oil switch is included in this system to change the electric motor into an electric generator upon the release of the starting button.

The type of U. S. L. equipment in most general use at present does not use the externally mounted combined cut-out and regulator but secures regulation of the output as a dynamo by means of a third brush system in which the flow of current through one of the field circuits depends on the current flowing into one of the brushes. The system is known as "Inherently Regulated." An electromagnetic cut-out is mounted on the dash of the car and serves the purpose of connecting the dynamo and battery when the dynamo voltage is suffi-

cient for charging. The complete internal connections for this type of application are shown in Fig. 303.

Above the cut-out are carried two fuses, one of six empere capacity and one of 30 ampere. The six ampere fuse is in the field circuit and will blow out should the battery lines become disconnected with the dynamo operating. The thirty ampere fuse is in the main charging circuit.

The touring switch used with U. S. L. equipment may be opened when the car is used on long daylight runs, and by thus opening the field and charging circuit of the motor-dynamo, excessive battery charge is prevented. The two lamp combinations in use with this type are shown in Fig. 303; one of these being a three wire system with 7 volt lamps, and the other being the usual two wire system with 14 volt lamps. In either case, starting is accomplished with 24 volts and charging at 12 volts, the proper changes in connections being made in the starting switch.

The relative location of the parts of a U. S. L. system having inherent regulation and 12 volt pressure for all functions is shown in Fig. 304.

Wagner Equipment. Wagner apparatus may consist of a combined motor-dynamo with cut-out and starting switch mounted on the unit, or of separate motors and dynamos with a cut-out on the dynamo or mounted separately.




Fig. 303

nternal Connections of U.S.L. 24-12 Volt Inherently Regulated Motor-Dynamo System.

The motor-dynamo is a compound wound machine using the series fields for starting. The output is controlled by taking the shunt field current through a "third brush" which is so placed that excessive amperage is prevented at high engine speeds.

On top of the unit is a housing in which is an electromagnetic cut-out and also a rotary drum starting and charging switch. This switch makes such connections that starting is accomplished with 12 volts pressure by arranging all battery cells in series, while charging and lighting are at 6 volts with the two battery sections in parallel.

The motor-dynamo is driven from the engine by means of a chain to the front end of the crankshaft and is driven from the engine by this same chain. The necessary gear reduction for starting is secured through a planetary form of gearing carried in a housing ahead of the unit, this gearing being brought into play by a brake band that is tightened by the same operation with which the driver moves the rotary switch to the starting position.

If the dynamo, motor and ignition are all separate, the dynamo is shunt wound. Four brushes bear on the commutator, two receiving the main charging current. The other two brushes are slightly nearer together. The second pair of brushes carries the current to the shunt field and because of their location with reference to each other act to decrease the cur-

rent flowing to the field at high speeds because of the distortion of the path of the magnetism




Fig. 304

Arrangement of Parts in U. S. L. Motor-Dynamo
System

between the field poles. This regulation action prevents excessive charging rates at high speeds

and causes the output to be slightly decreased at these speeds. The action of this form of regulation is also to increase the output with the increase in battery voltage so that the flow is greater to a battery when nearly charged than when nearly empty.




Fig. 305
Wagner Starting Motor With Gear Reduction
L and M, Brush Holders

The starting motor, Fig. 305, drives through a spur gear reduction and chain to the front end of the crankshaft. An overrunning clutch is built into the sprocket on the crankshaft. The starting switch makes the circuit complete without any preliminary resistance, the clutch providing the engagement.

Westinghouse Equipment. Three distinct types of Westinghouse apparatus are in use. The first, and oldest, type makes use of a separate dynamo securing output regulation by means of a bucking coil field as described in the following pages, and having an electromagnetic cut-out mounted on the dynamo. Another type includes a separately mounted dynamo having a vibrating reed voltage regulator and an electromagnetic cut-out mounted on the dash board or inside of the dynamo housing. The third type consists of a combined motor-dynamo having third brush regulation.

In generating current the machine acts as a shunt wound dynamo, the reversed series coil acting to regulate the amperage in a way peculiar to these systems. One end of the reversed series coil is connected to one of the dynamo brushes in such a way that current flowing into the battery for charging passes through this coil and by opposing the shunt winding keeps the amperage down to a proper point. The line which leads to the lamps from both battery and dynamo is attached to a lead from the differential winding in such a way that current from the dynamo to the lamps does not pass through the bucking coil. That means that the amount of current which flows through the bucking coil with the lamps off is the entire amount from the dynamo going to the battery, but as soon as the lamps are turned on a part of this current passes to the lighting

lines and no longer goes through the bucking coil. The reduced flow through the bucking coil with lamps on allows the shunt field to exert its effect without so much opposition and the output accordingly rises to care for the additional lamp load. Should enough lamps be turned on to take the entire dynamo current, none will be left to the bucking coil and the dynamo will act as a shunt machine without opposition and give the fullest current flow of which it is capable under these conditions. Should still more lamps be turned on the additional current will flow to the lamp lines from the battery through the differential wind-




Fig. 306

Westinghouse Cut-out Used With Inherently Regulated Dynamos

ing, but in an opposite direction from which it passed in bucking the shunt action and will therefore serve as an additional series winding assisting the shunt and the machine is therefore compound under these conditions and the output is still further increased.


All dynamos of this type carry an electromagnetic cut-out, Fig. 306, on the dynamo housing at the drive end just above the shaft, the

magnet carrying two windings as is the usual practice. This cut-out should close at about 8 miles per hour and re-open at about 6 miles per hour. It has no means of regulating the time of opening and closing. The wiring for this system is shown in Fig. 307.

The dynamo having voltage regulation is of the shunt wound type and the regulator acts to insert a resistance in the field when the terminal voltage rises to the predetermined limit. The operating parts of the combined cutout and regulator are shown with the cut-out open in Fig. 308, and with the cut-out closed in Fig. 309. The complete internal connections of the voltage control dynamo with self contained regulator and cut-out are shown in Fig. 310.

When the dynamo is being operated at a speed below the predetermined "cut-in speed", the contacts of the cut-out armature are open, the voltage of the dynamo being below that of the battery. When the speed reaches the "cut-in speed" these contacts are closed, connecting the dynamo circuit to the battery circuit. The "cut-in speed" varies from five to ten miles per hour on high gear, depending upon the gear ratio and wheel diameter of the particular car.

The "cut-in speed" can be observed by running the car, allowing it to increase in speed slowly, and observing on the speedometer the speed at which the car is running when the cut-out contacts close, which is indicated by a slight movement of the meter needle.



Wiring of Westinghouse Ignition and Lighting System, Inherently Regulated






Fig. 308 Westinghouse Voltage Controller, Cut-out Open Controller, Cut-out Closed



Fige. 309 Westinghouse Voltage

The regulator is so constructed that the cutout operates to disconnect the dynamo from the battery circuit at a speed slightly below the "cut-in speed". This enables the cut-out to

ep the circuit closed, and not constantly open close it when the car is being run at speeds



ternal Connections of Westinghouse Self-Contained Voltage Control Dynamo

se to "cut-in speed". This disconnecting the dynamo from the battery circuit when

the dynamo voltage is below the battery voltage insures that the battery will not be discharged through the generator.

The shunt fields of the dynamo are so designed that a voltage in excess of the normal voltage would be regularly generated when the dynamo is operated at high speed and no load. This excess voltage is prevented and the voltage is held constant by the automatic voltage regulator. When the dynamo is operating below "cut-in speed" the contacts of this regulator are closed, and remain closed until the armature is revolved at a speed which generates a voltage in excess of a predetermined This voltage is fixed by the setting of the voltage regulating screw which is adjusted at the factory. When, due to the increased speed of the dynamo, the voltage tends to exceed the value for which the regulator is set, the regulating contacts open, opening the direct shunt-field circuit and cutting in the regulating resistance. This causes a momentary drop in voltage so that the contacts close again. This opening and closing of the contacts is continuous, and so rapid as to be imperceptible to the eye.

Dynamos are also furnished with ignition parts carried on one end of the dynamo frame, these parts consisting of a magneto type breaker which automatically advances the spark by a pair of governor weights acting as the breaker cams and a distributor mounted above

the breaker. Otherwise the unit is the same as the dynamos described.

The combined motor dynamos are four pole compound wound machines operating with 12 volts, while the electromagnetic cut-out may or may not be employed. When the cut-out is used it is carried as a separate unit. These machines drive to the crankshaft direct through chains or gears without the use of overrunning clutches.


Almost all Westinghouse installations use the single wire system with the positive side of the circuit grounded in all cases. The ground return for the starting motor is assisted by having the cable enclosed in copper tubing which is attached to the metal work of the car and which is therefore free to carry the current to the motor.

The lighting switch is usually of the push button type. All circuits are fused, the cartridge fuses being carried in fuse boxes which provide for 3, 4 or 5 circuits in addition to the line to the battery. The fuse for head and tail lamps should be 15 ampere, for side and tail 5 ampere, for tail alone 3 ampere and for additional circuits such as the horn 15 ampere. When 6 volt bulbs are used with short wiring one of the fuses is replaced with a coil of resistance wire so that the voltage to the lamps with short connections may not be excessive. With 7 volt bulbs this compensator coil is unnecessary. Head lamps may be dimmed by

throwing them in series or by arranging a restance coil in one lead to the lamps. Junction boxes are used to centralize the connections and disconnector blocks are used for allowing body removal. Either an ammeter or voltmeter may be used, the ammeter being connected on one of the battery lines to the lamps and dynamo in the usual way while the voltmeter is directly connected to the two sides of the battery, indicating the voltage at all times. The current drawn by the voltmeter is so small that it can be neglected in every way.

Separate starting motors are of the four pole type, series wound with the field coils carried on two of the four poles, and operate with 6 volts.

Starting motors may drive the engine in any of five different ways. One system drives from a pinion on the armature shaft to a larger spur gear on a counter shaft, this larger gear having an overrunning clutch built into it. Mounted on the counter shaft is a small pinion which is free to slide on the counter shaft until it meshes with teeth on the flywheel rim. This sliding pinion is moved by a yoke and rods from the foot pedal, these operating rods also operating the switch. The first movement of the pedal closes the circuit through preliminary contacts and resistance ribbon, causing the starting motor to whirl with little power. Further movement of the pedal breaks this electrical connection but leaves the motor spinning while the movement pulls the gears in mesh. After the gears are meshed the switch has traveled to a position in which full contact is made and the motor turns the engine. Releasing the pedal opens the switch and the gears are thrown out of mesh by a coil spring in the gear housing.



Internal Connections of Westinghouse Magnetic Pinion Shift Starting Motor Drive

Another system uses the same arrangement of gearing between armature shaft and flywheel teeth but the gear meshing and closing of the switch is accomplished by solenoid action in place of by foot power. Three switches are used, Fig. 311, one being a push button on the dash marked "start," another being a small cylindrical housing through which the large starting cable runs and to which the wire from the dash button also leads and the third being the starting switch which is connected to the shifting pinion as previously described.

Pressing the dash button allows current to flow from the battery to the small cylindershaped switch and through the windings of a magnet on this switch. This magnet pulls the contacts closed which allow the battery current to pass through and to the large starting switch. The large switch contains a powerful solenoid coil through which the current then flows and out through a small auxiliary wire to the ground. The solenoid immediately pulls on a plunger which is attached to the sliding gear and starting switch contacts and the action of closing the contacts and sliding the pinion into mesh is done by the pull of the solenoid in the same way as previously described for the foot button action. As soon as the engine starts it runs the dynamo and the voltage of the dynamo rises to a point equal to the battery voltage. This balance of pressure prevents any more current from flowing through the switch operated from the dash button and the main starting cable contacts open whether the dash button is released or not. This kills the solenoid action and all parts return to normal positions.

The starting motor may also drive to the crankshaft through gearing or chains with overrunning clutch in which case the starting switch makes full contact in the first position.

Some installations drive to the flywheel by means of a Bendix type of application.

Steering Gear—Principles of. In steering gears the generally accepted principle is that known as the Ackermann-Jeantaud, which was invented in 1878 and is a modification of the





Fig. 312

Designing Steering Knuckle Arms original Ackermann principle. In the Ackermann-Jeantaud system the steering knuckle arms OL and O¹L, when produced, meet in the plane of the rear axle or in this plane produced as shown by illustration, Fig. 313. The reader will appreciate that when the tie-rod L L is in

rear of the front axle, the steering knuckle arms, OL and O'L converge, as illustrated, but should the tie-rod be in front of the axle, these arms diverge. Strictly speaking, the points A and AI, which are supposed to be in the axle



plane, are not so, and the axle line A, AI, is a tangent to the curve in which the points of convergence will fall in a complete sweep of the steering wheels from axle to axle.

It will be realized from the foregoing explanation that the dimensions and proportions of the steering axle parts depend on the wheelbase of the car, inasmuch as with a longer wheel base the distance that the lines would be produced would be greater with the increase.




Fig. 314

Several makers have, however, discontinued the design of steering knuckles on this principle, preferring to design them as illustrated in Fig. 312, in which the produced axis of the front wheels, A and B, intersect the axis of the rear wheel at a given point O. With this condition fulfilled, the vehicle will travel around O as an imaginary center. Enthusiasts of this method of construction agree that the Ackermann-Jeantaud principle is sufficiently accurate for angles of not more than 30 degrees, but for angles varying from 30 to 45 they claim less wear on their tires by the latter construction. The exact arm for the angles in a steering gear of this nature will depend largely on the wheelbase of the car as well as the difference between the steering pivots A and B.

Steering Gear—Types of. Fig. 314 shows a sectional view of the nut and segment type of steering gear, in which there is a worm D on the steering column that engages with the nut E. On the front or gear face of the nut is a rack F which meshes with the sector G, so that as the steering wheel is turned right or left the nut is raised or lowered and the requisite movement imparted to the radius rod H. In certain screw and nut steering gears the sector is not required, the construction being a screw on the steering column on which works the internally threaded nut, and on either side of this nut are trunnions with links which connect with the axis carrying the radius arm.

Steering Gear—Lost Motion in. If the gear of the worm and sector type it may be that lese two elements are not held in the proper lation to each other. Fig. 315 shows a diam of this type of gear, and illustrates plainly le point where lost motion will be of the greatit detriment. When the wheel is turned, if lere is the slightest end play, the wheel shaft




Fig. 315

ill respond, but the geared sector will not, ntil all the end play is taken up, and as rains come on from the road wheels, the secor will rotate to and fro, causing the shaft of ne steering wheel to reciprocate and thus allow the road wheels to wobble. To overcome us it is necessary to replace the thrust washer, there be one, and if necessary, introduce a

washer, made of phosphor bronze, of suitable thickness to take up all the end play of the steering wheel shaft.

Some lost motion will follow if the worm is not set on the pitch line, in its proper relation to the sector; this will be true if the bushings are worn, and when a new thrust washer is made and fitted into place, if the lost motion is still greater than is desired, the only thing remaining is to replace the bearing brasses. When the gear is dissembled it will be possible to dimension the same, and determine by measurement if there is any great amount of journal wear, thus rendering the task less troublesome, since the brasses may be replaced without waiting to determine the remaining lost motion through actual trial.

As a rule, it will be found that the lost motion is due to end play, just as the illustration shows, and not to worn-out journal brasses on which the wear is far less than it is in thrust. If the gear is irreversible, or nearly so, as it is in many automobiles, a little lost motion is to be expected owing to the smallness of the angle of the worm, which can only be irreversible if the angle is such that a little lost motion will be present and unavoidable.

CARE OF STEERING GEAR. The steering gear is a very important part of the car, and, as the safety of the occupants may be endangered by any binding, the autoist should give it even more careful attention than the other parts.




Fig. 316 Worm and Sector of Steering Mechanism

The gear should be taken down, given a thorough cleaning and examined for possible wear,

In case the steering action is stiff and the wheel turns hard, the ball joint may be out of adjustment due to wear; the steering link may be bent, or the cause may be insufficient lubrication. If there is any considerable amount of backlash, the cause may be looked for in the joints of the levers, in the swivel pin, or in loose bearings.

Tires, Care and Repair. Aside from gasoline the greatest expense in the upkeep of a motor car is the tires, and much of the present excessive tire wear may be reduced with reasonable precaution and care. There are ten common tire diseases, as follows: wheel out of alignment, under-inflation, use of anti-skid chains, skidding, running wheels in car tracks, neglect of casing repairs, tread cuts, running in ruts, stone bruises, use of inside protectors on new tires.

When a tire is on a wheel which is out of alignment the result is that the tire is scraped across the surface of the road and the resulting friction causes the tire tread to wear rapidly. The action of the tire on the road is crosswise at the same time that the tire revolves with the wheel. Thus the tire receives its usual wear plus the wear due to the scraping. The tread of a tire which has been run on a wheel out of alignment presents a rough appearance, that which would be given it were the tire held against an emery wheel for a while. Sometimes the fabric shows in places, and this is especially

true of wheels which are wobbly. It is advisable to line up the wheels of a motor car about every three months, and if one is found which does not run true, the condition should be corrected immediately.

Perhaps as much harm is done by running a tire under-inflated as by anything else. Underinflation, as the name implies, means that the tire is running with insufficient air pressure. Such a tire appears usually with a series of hilly blisters running around the tread. The blisters are caused by the separation of the fabric from the tread due to the excessive heat generated in an under-inflated tire. With insufficient air the flexing of the walls of the tire causes heat to be generated and this heat acts on the cement between the tread and fabric and in a short time the two separate, causing a blister to appear. Even in the summer a tire should not be run under-inflated. The common version is, that if the ordinary pressure is 80 pounds, a reduction of possibly ten pounds is made for summer weather. The belief is that the heat of the atmosphere will soon raise the temperature of the air in the tire and thus cause the pressure to increase to the proper point. This practice is not advisable, as there is undue wear on the tire while the pressure is being increased by the rise in temperature, and also because the pressure will drop as soon as the tire cools. The cure for under-inflation need hardly be stated. Keep the tires inflated to the pressure specified by the maker, which is usually 20 pounds per inch of cross-section. Thus, a 4-inch tire should carry 80 pounds pressure. It matters not if the pressure is a little more, but it does if the pressure is less than that for which the tire is designed. A tire guage, such as is sold for one dollar, should be one of the important instruments in the motorist's tool kit.

When anti-skid chains are applied to the tire too loosely or too tightly, the result sometimes is a cut tread. These chains should be placed on the tire so that they fit snugly and then no material tire wear will result.

Running a wheel in car tracks may soon cause the sides of the tire to become chafed, and in some instances the wear is so much that the tread loosens at the sides and begins flopping around. The same appearance may result if the car is driven very close to the curb and the side of the tire made to scrape the stone.

Little cuts in the casing often result in the casing being unfit for use in a short time. When a small cut appears and the tire is operated, dirt and water get underneath the tread. This dirt works its way around the tire under the tread with the result that the tire is soon loose. Water, as everyone knows, is detrimental to rubber, and more so to the fabric. Fabric begins to rot in the presence of water. The small cuts may be plugged with mastic.

Often a cut appears in the tread and an inspection finds that the fabric is injured also.

In such an instance the blowout patch is the first resort. The patch, if wrongly applied, sometimes becomes wedged in the fabric cut and in this way hastens a blowout. The best way to treat a tire with a reasonably large tread cut is to have the cut vulcanized immediately. In fact, even small cuts should be vulcanized at the first opportunity. The owner may say that the cost of having the tire vulcanized every time it is cut is expensive. It may seem expensive at first, but the saving in tire wear and repair later overbalances the comparatively small cost of vulcanization.

In the fall especially country roads present a mass of hardened ruts which play havoc with tires. These hard indentations house the tire for a while and then the driver will go over the rut. The driving in and out of these ruts creates a condition which puts a tire in the rutworn class. The sides of the tread begin to show rapid wear and sometimes the wear is great enough to cause a weak spot in the tread, with the result that the tire blows out.

Stone bruises cause a great percentage of tire failure. When a tire runs over a stone, one as big a man's fist, there is a possibility of the fabric becoming broken. A broken fabric soon causes a blowout, so it remains for the driver to prevent as far possible running over such stones. Small stones sometimes present sharp edges which cut the tread and thus make an entrance for dirt and water. Stone bruises are

hardly visible from the outside, as the condition is one of a fabric break, as mentioned above. The result of a stone bruise may be seen by examining the inside of the casing, which will show clearly that the fabric is injured.

Some makers state that the use of inside protectors on new tires is not advisable, as these appliances create an undue amount of heat in the tire and thus hasten wear. For old tires the inside protector is perhaps the best accessory marketed for lengthening tire life. Some owners have obtained as much mileage with old tires and inside protectors as they have from new tires operated without protectors.

Tire Vulcanizing. Absolute cleanliness is necessary in all vulcanizing work. No matter how good a vulcanizer you have or what kind of repair stock you use, the smallest amount of oil, grease or dirt will greatly impair the work. Therefore clean every repair thoroughly with a cloth or brush dipped in clean gasoline and roughen the point of repair with a rasp or coarse sandpaper while still wet.

Tires must be dry before beginning work on them, otherwise a porous patch will result. If you think, for any reason, that the canvas in the casing is even slightly damp, clamp the vulcanizer loosely over the tire for ten or fifteen minutes before applying the first coat of cement. Interpose a piece of waste or something of the sort between vulcanizer and tire to permit the escape of moisture. It takes from fifteen to twenty minutes to vulcanize a layer of Para one-sixteenth of an inch thick if the thermometer is kept at 265 degrees, and five additional minutes for each additional sixteenth of an inch. Vulcanization will occur equally well at all temperatures between 250 degrees and 275 degrees. The lower temperatures require more, and the higher temperatures less time than stated above.

Inner tube punctures. Clean the tube thoroughly with gasoline and coarse sandpaper, for at least an inch all around the hole (be careful not to get gasoline inside the tube); then wipe with a cloth moistened with gasoline. When the gasoline has evaporated cement the edges of the hole and apply a thin layer of cement to the tube for three-quarters of an inch on each side of the hole. Let the cement dry until the gasoline has all evaporated and the cement is solid enough to resist the touch. "Tacky" is the usual word. Apply a second coat and let dry as before.

If a small hole, fill even with the surface of tube with layers of Para rubber cut the size of the hole, taking care that the Para sticks all around the edges. If a simple puncture, place a narrow strip of Para rubber over the end of a match and insert it into the hole. Cut off what protrudes outside the tube. Cut a patch of Para one-eighth larger than the hole or puncture and apply over same. Then cut another patch one-half inch larger than the hole and

apply over the first. Cover and apply vulcanizer.

Repairs of this sort are to be vulcanized for fifteen or twenty minutes at 265 degrees.

Inner tube cuts and tears. Clean as directed both inside and outside of tube; coat edges of cut and inside and outside of tube with cement and let dry. The cement should extend three-fourths of an inch back from the cut.

Cut a strip of Para rubber as wide as tube is thick and stick on edge of cut; cut a strip one-half inch wide of Para rubber cured on one side, place it inside of tube under tear with cured side down, bring edges of tear together and stick them down to this strip. If you do not have any of the Para cured on one side regular Para may be used after cementing a piece of paper to inside of tube opposite the cut to prevent patch from sticking to opposite side.

Apply another strip of Para rubber one-half inch wide on the outside of the repair. Vulcanize for twenty-five minutes.

The first step in making a casing repair is, just as in the case of all tire work, to thoroughly clean the point of repair. Apply from one to three layers of cement, allowing each to dry. If the canvas is exposed, as in a scalp cut, put on enough cement to fill the pores of the canvas and leave a smooth surface when dry. Fill the hole not quite level with surface with Para rubber. The best results are obtained when casing repairs are slightly concave. If filled too full,

the rubber will expand and flow over onto the unprepared surface in a thin film that will soon peel up and cause trouble. Moreover, a protruding patch will receive more than its share of hammering and will undoubtedly split open.

Tonneau. The name or term used in connection with the rear seats of a motor car. Literally the word means a round tank or water barrel.

Torsion Rod. When the manner in which the power is transmitted from the change-speed gear to the rear axle on the shaft-driven car is considered, it will be apparent that the turning of the shaft imposes a twisting strain on the whole rear end of the car, and that if it were not for the frame, and the weight of the car on the ground, there would be a tendency to revolve the rear of the chassis around the shaft, rather than to turn the wheels. But it would be bad practice to permit this strain to fall on the frame and hence the office of the torsion rod, which is designed to prevent its reaching that member. On cars that are not provided with independent torsion rods, it will be found that the housing of the propeller shaft has been made correspondingly stronger, and that its support has been designed to enable it to act in this double This represents a simplification of design that will be found on quite a number of cars, as it eliminates a part exposed to mud and dirt.

Traction of Driving Wheels. A horse which

exerts a pull of about 375 pounds continuously for an hour and goes a distance of one mile in an hour is working at the rate of one horse-power. If for any reason the horse is unable to exert as much as 375 pounds pull when going at the rate of one mile per hour, he is thereby prevented from working at the rate of one horsepower.

The same rule applies to a motor car. When the road is not slippery there may occur a condition which does not appear with horse traction; that the tires fail to adhere to the ground owing to insufficient weight on the driving In such a case it is impossible for the motor-car to exert a push of 375 pounds without skidding the wheels, and thus it would be impossible for it to work at the rate of one horsepower. With underpowered motor-cars this difficulty does not occur, but to develop 10 horsepower at the rims of the driving wheels while covering the ground at the rate of one mile per hour, the car must exert a push on the road of 3,750 pounds. This is, on touring cars of ordinary weight, impossible, because the weight on the driving wheels is invariably less than 3,750 pounds, while the adhesion with the road is only a fraction of the weight on the rear As the speed rises, however, the push necessary for the development of 10 horsepower goes down until at 10 miles per hour a push of 375 pounds means 10 horsepower.

Thus a 40 horsepower car, if it could start

work with the activity of forty horses, would, while it was moving at one mile per hour, exert no less a push than 40 x 375, which is equal to 15,700 pounds. This tremendous push is rendered impossible by the fact that the wheels of a car weighing 2,000 pounds only grip the ground enough to exert about 750 pounds push. Beyond this point they will skid.

This shows that a high-powered car, when the car is moving slowly, cannot develop its full power unless the road wheels are capable of adhering to the ground sufficiently to transmit this power. As a rule only about 0.6 of the weight of the car is on the driving wheels, and of that only 0.625 is available for the adhesion (owing to the coefficient of friction between rubber and road being 0.625). So a 10 horse-power car weighing 2,000 pounds cannot exert its full power when the car is starting, nor until it is traveling at 5 miles per hour.

It would be wrong to contend that on all cars having the weight distributed as at present, a 60 horsepower motor is useless, but it is needless to say that the output of such a motor is not availabe at starting or at any speed under 30 miles per hour, although the whole power is more needed then than at any other time. The remedy which suggests itself is by using all the adhesion of the car, that is, to drive with all four wheels.

Transmission of Power—Efficiency of. The efficiency of various forms of drives between

the motor and the driving wheels of a motor car may be estimated as follows:

Single-chain, with direct drive on the high speed, between the motor and rear axle—85 per cent.

Two-chain drive, from motor to speed-change gear, from speed-change gear to rear axle—75 per cent.

Quarter-turn or right-angle drive, with double-chain drive to free rear wheels—70 per cent.

Longitudinal shaft drive, with universal joints and bevel gear in differential case—65 per cent.

Transmission Shaft. The square transmission-shaft used on several highest-powered cars is a nickel steel forging with .25 to .30 per cent of carbon. The treatment is about as follows: First heated in lead bath, then transferred to the cyanide, where it remains 20 minutes, then dipped in cottonseed oil. The shaft then goes to the furnace and is heated to 1,400 degrees Fahrenheit. When removed from the furnace, only the part of the shaft upon which the sliding gears operate is dipped in oil. This class of steel before treatment averages 86,000 tensile strength, after treatment 125,000 to 130,000.

Transmission. See Change Speed Gearing.

Trouble Location. See Knocking, Pounding, Preignition, etc.

Twelve-Cylinder Engine. See Engine, Eight and Twelve Cylinder.

Unit of Heat. The heat unit or British thermal unit (B. T. U.) is the quantity of heat required to raise the temperature of one pound of water one degree, or from 39° to 40° F., and the amount of mechanical work required to produce a unit of heat is 778 foot pounds. Therefore the mechanical equivalent of heat is the energy required to raise 778 pounds one foot. high, or 77.8 pounds 10 feet high, or 1 pound 778 feet high. Or again, suppose a one-pound weight falls through a space of 778 feet or a weight of 778 pounds falls one foot, enough mechanical energy would thus be developed to raise a pound of water one degree in temperature, provided all the energy so developed could be utilized in churning or stirring the water.

Vacuum Fuel Feed. See Fuel Feed, Vacuum.

Valves.

SLEEVE VALVES. During the last few years there has been placed on the market a type of engine that does not have poppett valves, but which has a type of valve known as a "Sleeve Valve." See Engine, Sliding Sleeve Type.

Sleeve valves are made by placing two sliding




Fig. 317 Sliding Sleeve Valves

sleeves between the piston and the cylinder walls, Fig. 317. These sleeves are shaped like a section of tubing and are about an eighth of an inch thick. There are holes or slots cut through the sleeves near the top, that is, in the part of the sleeve nearest the cylinder head.

The holes, or "ports" as they are called, are placed so that when the sleeves are placed in a certain position the holes are opposite each other. When they are opposite each other they will let the mixture through into the cylinder or let the burned gas out into the exhaust pipe, depending on which thing it is necessary to do.

The lower ends of the sleeves connect with small connecting rods which are worked up and down by eccentrics on the shaft that takes the place of the cam shaft. These small connecting rods move the two sleeves up and down so that when the piston is ready to start down on the inlet stroke two of the openings come opposite each other, one opening in each sleeve. These two openings are brought opposite the opening that goes to the carburetor at the same time they are opposite each other so that the fresh mixture can be drawn into the cylinder.

After the piston passes bottom center the sleeves are moved so that the openings are not opposite each other or the opening to the carburetor and the fresh gas is shut off.

When the piston is most of the way down on the power stroke two ports on the other side of the sleeves, one opening in each sleeve, are brought opposite each other, and at the same time opposite a hole that opens into the exhaust pipe so that the burned gas can get out of the cylinder. After the piston finishes the down stroke, goes up on the exhaust stroke, and is just past top center, the two openings are moved so that they close the hole into the exhaust pipe and then the inlet openings come opposite each other again.

These sleeves are adjusted to open and close at just the right time by adjusting the length of the small connecting rods.




Fig. 318
Engine Having Single Rotary Valve

The opening and closing of the ports should come simultaneously with the opening and closing of the inlet and exhaust valves in a poppett valve engine.

ROTARY VALVES. Other engines are made without either poppet or sleeve valves but with a type of valve called a "Rotary Valve."

Rotary valves, Figs. 318 and 319, are made by having a long round shaft run along the side of the cylinders near the cylinder heads. Holes are bored through this shaft so that the holes come opposite openings into the cylinder or combustion space and at the same time open




Fig. 319
Engine With Separate Rotary Valves

into the pipe leading to the carburetor or to the exhaust pipe, according to the position the piston is in and the stroke it is making.

This long shaft or valve is set in a position to open the inlet holes at the same time as the inlet valves should open in a poppet valve motor, to close the inlet holes at the time the inlet valves should close, and to open and close the exhaust holes at the same time as the exhaust valves should open and close in a poppett valve engine.

The rotary valve is driven from the crank shaft by gears or chains so that it turns half as fast as the crank shaft, just the same as the cam shaft would turn.

DISC VALVES. There are still other engines made with a type of valve known as a "Rotary Disc Valve." These valves are in the shape of a piece of round iron as large around as the top of the piston and about a quarter inch thick. They are placed on the top of the cylinder and fastened to gears so that they rotate or turn around.

Holes are cut through the disc so that they come opposite holes cut through the cylinder head. Some of these holes connect with the pipe that goes to the carburetor and others connect with the exhaust pipe.

The discs are made to turn so that the inlet holes and exhaust holes are opened and closed at the same times as the inlet and exhaust valves are opened and closed on a poppett valve motor.

PITTED VALVES. A valve in a pitted condition causes bad compression, and the exhaust-valve should be ground occasionally. After grinding the exhaust-valve be sure that there is ample clearance between the valve and the

lifter. It should have not less than one hundredth of an inch, otherwise when the valve becomes hot it will not seat properly, poor compression being the result. In grinding a valve there is no occasion to use force, and the grinding should be done lightly, the valve being lifted from time to time so that any foreign substance in the emery will not cut a ridge in the seat, or the valve itself. After grinding the valve always wash out the valve seat with a little kerosene, and be careful that none of the emery is allowed to get into the motor cylinder.

Valves which need reseating should first be ground in place with fine emery and oil, then finished with tripoli and water.

A good mixture for grinding valves may be made by using fine emery and cylinder oil mixed in the form of a paste convenient to work with.

EXHAUST-VALVE STICKING. Sometimes a motor may suddenly stop from the failure of the exhaust-valve to seat properly. This may be due to the warping of the valve, through the motor having run dry and become hot, or it may be from the failure of the valve spring, or the sticking of the valve-stem in its guides. The valve should be removed, and the stem cleaned and scraped, or straightened if it requires it, until it moves freely in the guide, and the spring is given its full tension. If the valve still leaks so that the motor will not start or

develop sufficient power, the valve will have to be ground into its seat.

Valve Grinding. To grind a valve proceed as follows: First loosen the lower end of the valve spring from the lower end of the valve. This may be held by a number of different devices such as washers with pins under them, or grooves cut in the valve steam into which a washer slips. To loosen the spring it must first be pried up from the bottom, that is, so the end of the spring is held away from the end of the This may be done by a special valve spring lifter or the repairman can make a forked lever so that the prongs fit on each side of the stem and lift the spring by resting the lever on some solid piece. Sometimes the spring can be lifted by taking a common screwdriver and using it to pry with. Before the spring can be raised, however, the cap that covers the head of the valve must be removed or at any rate the head must be reached. Now take a screwdriver or hammer handle or a piece of wood and wedge it into the valve pocket so that the head of the If this was not done the valve cannot lift. whole valve would lift when you pried up on the spring.

After the spring is pried up out of the way remove whatever locking device was holding it and then the valve may be taken out of the hole above the valve head by letting the stem slip through the spring and locking parts. You can now examine the face and seat and you will

probably find them pitted. Also examine the stem, and if it is dirty or covered with soot (called carbon in the automobile business), it should be scraped clean with a knife blade or some sharp instrument. There must be no ridges on the valve stem that might keep it from seating the valve properly.

A valve stem must never be oiled or greased under any conditions. They are designed to work dry.

The valve is ground by placing some cutting material between the seat and face and rubbing them together. Valve grinding material may be made by taking emery powder of a fine grade and mixing it with enough engine lubricating oil to make a rather thin paste, or it may be made by mixing the emery with lubricating oil and kerosene. It may also be made by mixing powdered glass with a thin oil into a paste, this being used mostly for finishing the operation. If a very fine fit is desired a paste can be made with crocus powder and oil. A rather coarse paste is used at first if the surfaces are badly pitted and the finer, smoother pastes are used for finishing.

After making the paste take a cloth (not a piece of waste), tie a string to it and stuff the cloth into the opening from the valve pocket to the combustion space. This is to keep the grinding material out of the cylinder, where it would do great harm.

On the top of the valve head you will find a

slot for a screwdriver or else some holes that take the end of a special fork-shaped tool. These let you turn the valve face on the seat, and you will need a tool that fits the particular valve head you wish to work with. You will also need a small can of gasoline or kerosene handy so that the grinding compound may be washed from the valve and seat.

The operation of valve grinding consists of placing a small amount of the grinding compound evenly on the face but not very thick. What you can easily pick up on the tip of a pocket knife blade is plenty at one time. The valve is now placed in the cylinder or part that it came out of so that the face rests on the seat. Now take the tool that turns the valve and turn the valve about half way around and then back again. Do this several times. Do not use much pressure as the pressure forces the grinding compound from between the face and seat and makes the work slower.

After making several half turns the valve head must be raised and turned to a new position while it is not touching the seat, and then the operation is repeated. If you do not raise the valve from the seat every few half turns you will make ridges on the face and spoil the job. Also, if you turn the valve round and round without reversing the motion and raising it you will spoil the work. In order to raise the valve from the seat every once in a while you can take a light spring that fits around the stem and

place it on the valve stem just under the head. This spring should rest on the metal of the cylinder at its lower end and hold the valve about a half inch off the seat. When you press on the valve grinding tool the valve will be pressed down onto the seat, but when you release the pressure it will raise again and you can turn to a new position without pushing up on the stem from below.

The valve must be ground for a few minutes and then washed off and carefully examined. When the face and seat are a clean even light gray all around and have no marks or pits or rings at any point the job is finished and the valve should be gas tight.

The next thing to do is to test the valve for tightness. This can be done by placing pencil marks at short distances all around the face and then pressing the valve down and turning it once around. If the marks are all off the face it will be tight. You can also pour gasoline or kerosene on top of the valve and watch for it to run down the stem. If it does not leak through it is tight.

Now wash every trace of grinding material from the valve and the seat and valve pocket and replace the valve with the spring and the valve cap.

Valve Clearance. A large number of motors, especially old ones, are unnecessarily noisy because of superfluous clearance between the valve lifters and the valves, and a great part of the noise may be eliminated simply by the expenditure of a little time and care in reducing this clearance to the minimum. Every valve cam, no matter what its shape otherwise may be, is tangential at the first and last portions of the valve's movement. The sooner the valve takes hold of the cam on the lift, and the later it lets go on the descent, the slower will be the





Fig. 320

movement of the valve at these instants, and the less will be the shock both of the lifter on striking the valve stem, and of the valve head on meeting its seat. Fig. 320 shows this clearly. The tangent line Λ B starts at A, and during the arc D C the rise of the cam amounts only to a minute distance A D.


The objection to an excessive clearance is not

simply the vertical hammering, but the sidewise pressure imposed on the valve-lifters by the cams, particularly at the instant of opening the exhaust-valves. If it were possible to operate the valves with no clearance whatever, and if there were no lost motion, and if the whole mechanism were ideally rigid, the line of pressure of the cam at the instant could be said to



till the valve was off its seat and the pressure of the gases on the valve was partly equalized. As the matter actually stands, however, there is a side thrust which is considerably increased by unnecessary clearance, as comparison of Figs. 321 and 322 clearly shows. In Fig. 321 there is no clearance, and the tangent to

the line of contact is horizontal. In Fig. 322 there is a clearance, AB. The thrust acts at right angles to the tangent along the line C D, and if C E represents by its length the force required to overcome the pressure on the valve and the force of the spring, there is a horizontal thrust equal to D E. It goes without saying



that valve-lifters thus adjusted will wear loose in the guides faster than they should. As the gas pressure on the valve head may amount to 30 or 40 pounds per square inch the instant before the valve is open, there is an evident tendency to wear a hollow in the cam at the precise point where it starts the exhaust valve from its seat. Evidently, moreover, the smaller the

clearance, the greater will be the leverage of the cam, and the smaller will be its wearing tendency.

The precise amount of minimum clearance is hard to state arbitrarily. The thickness of a business card or about 10-1,000th of an inch is ample allowance for the expansion of valve stems for the average length.

Valves—Lead of. The higher the speed of the motor the greater the necessity for giving both the exhaust, and the inlet valves what has come to be known as a "lead," in that they open before the completion of the particular part of the cycle that they are intended to perform. It must be borne in mind that time is required to set a thing in motion and to stop it, regardless of its form or weight, and this is true of a gas, which has inertia the same as other substances. Further, an appreciable period, though very short indeed, is required for the creation of the vacuum in the cylinder. The gas does not rush into the combustion chamber the moment the inlet valve opens; the piston must have traveled downward a bit before this takes place and the column of gas then rushing in attains an increasing velocity as the piston approaches the lower center. In fact, it is at its greatest speed when the piston reaches the lower dead center so that the first part of its return travel has little or no effect on the incoming gas, which accordingly continues to pour into the cylinder, until the piston reaches a point on its upward

stroke, where its compression is sufficient to overcome the inertia of the stream of gas, and this is the point at which most designers of




Fig. 323
Inclined Poppett Valve




Fig. 324 Intake Valve, Poppett Type

high-speed engines set the inlet valve to close, thus permitting of the suction of the greatest possible quantity of fresh gas. Valves, Inlet, Diameter and Lift of. For a motor of any desired bore and stroke, and speed in revolutions per minute, the following formula may be used to determine the diameter of the valve opening:

Let B be the bore of the motor cylinder in inches, and S the stroke of the piston also in inches. As R is the number of revolutions per minute and D the required diameter of the valve opening, then

$$D = \frac{B \times S \times R}{15,000}$$

Example: Required the diameter of the admission-valve opening for a motor of $4\frac{1}{2}$ -inch bore and stroke at 1,000 revolutions per minute.

Answer: As $4\frac{1}{2}$ multiplied by $4\frac{1}{2}$ and by 1,000 equals 20,250, then 20,250 divided by 15,000 gives 1.35 inches as the diameter of the valve opening.

In practice, a motor of $4\frac{1}{2}$ inches bore and stroke has, with a mechanically operated admission-valve, an opening of $1\frac{1}{2}$ inches diameter and runs up to 1,200 revolutions per minute.

The upper view in Fig. 325 shows clearly the diameter D referred to in the formula, as some persons are in the habit of referring to the outside diameter of the valve itself instead of the opening in the admission-valve seat. The center view in Figure 8 shows an admission-valve with a flat seat, which is known as a mushroom valve, on account of its shape. For this form

of valve to give a full opening the lift should be exactly one-fourth of the diameter of the valve opening: therefore if L be the required lift of the valve, and D the diameter of the valve opening, then

$$L = \frac{D}{4} = 0.25 D$$




Fig. 325

The lower view in Fig. 325 shows a valuable with a bevel seat, having an angle of 45 degree which is most commonly used. The lift of the form of value requires to be about three-eight of the diameter of the value opening; that is, I is the required lift of the value and D the diameter of the value opening, then

$$L = \frac{D}{2.83} = 0.35 D$$

The bevel-seat form of valve is to be preferred to the flat-seat or mushroom type of valve, for two reasons: first, that it is more readily kept in shape by regrinding, and second, it gives a freer and more direct passage for the gases, as will be plainly seen by reference to the lower view in Figure 325.

Table 12 gives the correct diameter of valve openings for motors from 3 by 3, to 6 by 6 inches bore and stroke, with speeds from 900 to 1,800 revolutions per minute, and piston velocities of 600, 750 and 900 feet per minute, for mechanically operated admission-valves.

TABLE 12.
DIAMETER OF MECHANICALLY OPERATED ADMISSION-VALVES.

| Bore of Cylinder. | Stroke of Piston. | P | r Minute | · | | | |
|-------------------------|---|---|---|---|--|--|--|
| | | 600 | | 750 | | 900 | |
| | | Revs. per Minute. | Dia. of Valve Opening. | Revs per Minute. | Dia. of Valve Opening. | Revs. per Minute. | Dia. of Valve Opening. |
| 3 1 4 4 1 5 5 1 5 1 5 6 | 3 3½ 4 4½ 5 5 6 | $\begin{array}{c c} 1200 \\ 1030 \\ 900 \\ 800 \\ 720 \\ 655 \\ 600 \\ \end{array}$ | $egin{array}{c c} -0.72 \\ 0.84 \\ 0.96 \\ 1.08 \\ 1.20 \\ 1.32 \\ 1.44 \\ \end{array}$ | $\begin{array}{c} 1500 \\ 1285 \\ 1125 \\ 1000 \\ 900 \\ 820 \\ 750 \\ \end{array}$ | 0.90 1.05 1.20 1.35 1.50 1.65 1.80 | 1800 1570 1350 1200 1080 965 900 | 1.08 1.26 1.44 1.62 1.80 1.95 2.16 |

Atmospheric or suction operated admissionvalves require to be of somewhat larger diameter than mechanically operated admission-valves, for two reasons: first, that the incoming charge has to lift the valve from its seat and keep it suspended during the suction stroke of the motor piston, and secondly on account of the resistance offered by the valve spring, which tends at all times to keep the valve on its seat. For an atmospherically operated admission-valve which will insure practically a full charge in the motor cylinder the formula should be

$$D = \frac{B \times S \times R}{12,750}$$

The proper diameter for atmospherically operated admission-valve openings may be readily found by increasing the required diameter given in the above table for mechanically operated admission-valves, by 15 per cent.

Example: What should be the correct diameter for the atmospherically operated admission-valve of a motor of 4½ inches bore and stroke, with a piston velocity of 750 feet per minute?

Answer: Under the column headed 750 and opposite 4½ by 4½, the diameter given is 1.35. Then 15 per cent of 1.35 equals 0.20, which, added to 1.35, gives 1.55 inches as the correct diameter for the valve opening under the conditions given.

Admission-valves, Forms of. Figs. 326 and 327 are two forms of combined admission-valve




Fig. 326




Fig. 327

and valve cage or chamber. Fig. 326 has the nlet on top and Fig. 327 on the side. Figs. 328-329 show two forms of detachable or remov-




Fig 328

able admission valves. The one shown in Fig. 329 may be removed from the motor without disconnecting the admission-pipe, as it screws




Fig. 329

into the combustion chamber, and has openings around the lower portion for the admission of the explosive charge to the valve.

Vulcanizing. See Tire Vulcanizing.

Watt-Hour—Definition of. A current of one ampere flowing in an electric circuit, with an electro-motive force of one volt, is equal to one volt-ampere or one watt. The voltage of a circuit, multiplied by the rate of the current flowing in amperes, gives the rate of work, or energy expended in watt-hours.

It is oftentimes found that electric lamps for automobile lighting are rated according to their consumption in watts rather than directly in amperes. The number of candlepower secured from each watt consumed will vary according to the size of the lamp in candlepower, the material of which the filament is made and the type of bulb, whether vacuum or nitrogen. A small bulb with tungsten filament will use from 1.10 to 1.25 watts per candlepower, and this is reduced until in the largest candlepower the rate is about 0.95 watts. The consumption with carbon filaments is about two and one-half times that with tungsten. Nitrogen bulbs use less current than the vacuum type.

Welding—Autogenous. This process consists of welding, or, more correctly speaking, melting together metals by means of the oxyacety-lene flame, the temperature of which almost rivals that of the electric arc, being 6,300 degrees Fahrenheit. The facility with which it can be handled as compared with most other methods makes its commercial application comparatively simple. The possibilities attendant upon the use of a flame of such high tempera-

ture can be realized when it is remembered that the melting point of steel is about 2,570 degrees and that of platinum, one of the most refractory metals, is only 3,227 degrees Fahrenheit. Its chief field of usefulness is in combining such metal parts as would ordinarily be riveted, in welding small parts together, in repairing broken or defective castings and for cutting metals of any nature or size that occasions demand.

As it is possible to unite many dissimilar metals, and with a heat so localized that neighboring parts are not affected, autogenous welding has already found an extensive application in motor car repair work. Broken crankcases or other parts can be united and made practically as strong as new. The method of holding the pieces of a broken aluminum case, for example, is to clamp them into position temporarily while clay is packed around the parts and heated sufficiently to drive out the moisture, thus forming a solid support for the parts as well as a kind of mould. A series of holes are usually drilled at the crack, or the edges of the pieces are roughly beveled so, as previously explained, the metal can be built up from the bottom. In some instances lugs or peculiar shaped projections may have been completely worn off or destroyed, when it becomes necessary to build up new ones with additional metal. In repairing a cracked waterjacket, after the edges of the crack have been prepared, it is customary to use copper instead of iron wire for the filling metal as it flows at a lower temperature and adheres very positively. In case there is danger of warping, due to local expansion, the entire cylinder is heated before operating upon it.

Wheels. The wood work of all wheels should be of selected grades of second growth hickory, or equally good growths of other hard woods. In the driving wheels the twisting moment of the motor is transmitted to the spokes of the wheels, and this torsion must be resisted by the wood at the miter, therefore, if the hub flanging is not clamped tight there is danger of the joints "working," which will soon lead to something worse. When the hub clamping bolts are tightened up they should be so pinned that they will not turn with the nuts because if the bolts do turn it will be impossible to apply sufficient pressure, and the clamping effort will be insufficient. Fig. 332 shows a hub in which the clamping bolts are prevented from turning by means of a triangular shaped extension just under the bolt heads, which engages a slot in the flange. In this hub the flange is made integral with the brake drum, which also serves for the sprocket wheel, and the torsional effort is taken by integral metal at all points, thus relieving the wood work from shock. The nuts used on the clamp bolts shown in Fig. 332 are castellated, although it is not necessary to use castellated nuts unless the flanges have to be removed, which in modern construction is




Fig. 330
Rear Wheel Spoke, Showing Proportions

the exception, rather than the rule. In ordinary practice if the wood is thoroughly seasoned, plain nuts, if screwed up tight will hold without resorting to the method so common in shop practice of riveting the ends of the bolts over the nuts. The elastic nature of the wood will serve to hold the nuts in place. Regarding spokes, a certain symmetry of contour is necessary if they are to be machine made. Fig.




Fig. 331
Section of a Hub at the Miter Showing Depth of Flange
and Method of Clamping

330 shows a spoke in which all the advantages known to wheel making are embodied, and the depth of flanging is that which experience dictates as adequate. The dimensions of the spoke are shown in detail in the cut. The brake drum is bolted to the spokes at a considerable radius, thus eliminating excess strain on the wood work.

The strength of the spoke depends in a large




Fig. 332
Section Through Rear Wheel with Combination Brake
Drum and Inner Flange

sure upon its thickness in the axle plane at hub flange, which in Fig. 330 is 1¾ in. The nd point of importance is at A, B, where largest diameter is also 1¾ in., but in the e of the wheel instead of the axle. At the n engaging the felloe, this spoke is 1½ in., s major diameter, which is the plane of the




Fig. 333 ction of Felloe Depicting Tenon and Method of Wedging Which will Split the Felloe

, while in the plane of the wheel the minor neter of the elliptical section is 1 3/16 in., the dimension prevails in this plane from t A, B, out to the felloe. In some types of tes the section at the engagement of the felse round, and reduced gradually to the section at A, B. Fig. 331 shows a section of the

hub of another type of wheel, in which the radial depth of flanging is $2\frac{1}{4}$ in., and the axle thickness of the wood is $2\frac{1}{8}$ in. This wheel may be used on a 60 H. P. car, and will serve as a safe example of depth of flanging, as well as a guide in fixing the shear section of the spokes for stresses induced, when cars of great power skid, provided the wheel is not dished. Fig. 333 shows the same spoke at its engagement with the felloe, indicating the manner in which the spoke is wedged into the felloe.




Fig. 334
Schwarz Wheel Showing Miter Joints

Figure 334 shows the Schwarz type of wheel, indicating the method of overlapping the miter, thus making it possible to true up the wood work independent of the hub. Fig. 335 shows a section of the hub, spoke and felloe of a dished wheel, and it will be seen that the felloe is not in the plane of the miter, and the dish of the wheel is outward. When a car is running at a comparatively high speed rounding a curve, the outer wheels are stressed in such a

nner that the tendency is to set a dish in m exactly opposite to the dish given by the eel maker.

The shorter the spokes are, the greater will dishing have to be in order to insure that spokes will be enough longer than the radial




Fig. 335 ection of a Wheel Showing the Dish, Which Has Strength to Resist Skidding and Lateral Stresses

tance from the hub end of the spokes to the tring against the felloe, to serve as members compression, and the rim on the felloe will be to do the work. As the cut shows, the exsenst length of spokes marked "difference," resents the versed sine of the angle of the kes.

Wheels, Steel. Steel is extensively a the manufacture of wheels for autom These types include steel disk wheels de especially for trucks; wheels with *as spokes, built for use on either trucks or mobiles; also wire wheels, which will scribed later on.

Figure 336 shows the design and contion of a resilient spring steel wheel.




Fig. 336 springs and
Ackerman Wheel Which Has
Resilient Steel Spokes serves as carr

sists of a speci which may be or machined to standard axle, of single leaf: of specially chrome vansteel, and a ri holds the ends springs and serves as carr the tire.

These springs or spokes are carried center bearing, and they carry the load torsion at all times. In the automobile there are twelve of these spokes, each being made of sufficient width and enough to take care of the load for which designed. Provision is made for a for cent overload in the design of the s which means that the steel will never strained beyond its elastic limit. This vision against overload prevents fracture

spokes under load vibration or in ordinary road travel.

Wire Wheels. The development of the wire wheel has been very rapid during recent years. The invention of the wire wheel created a radical change in the method of load carrying, due to the fact that, instead of the compressive strain brought to bear upon a few spokes underneath the axle, as is the case with the ordinary type of wheel, there is a tensional stress on a large number of wire spokes, and the weight is thus held in suspension by the wire wheel with its steel rim and steel wire spokes.

Although the pneumatic tire is a great absorber of jolts, if the wheel strike an obstruction the shock of which is beyond the capacity of the tire to absorb, and if the wheel is fitted with rigid spokes, this shock is passed directly to the axle and from thence to the car springs, and unless these are equipped with efficient shock absorbers, the passengers are sure to feel the effects of rough riding. On the other hand the spokes of the wire wheel all act as a complex yet effective shock absorber, and in this way tend to reduce in a large measure the annoying effects of these vibrations. other advantage in connection with the use of wire wheels is that the wheel itself, owing to its construction and the nature of the material, acts as an effective tire cooler, which is not the case with the wooden wheel, for the reason that the spokes of the latter do not tend to radiate the heat generated in the tire while running, consequently this heat must radiate from the tire and rim and the process is a very slow and ineffective one. Regarding the two important features of durability and lightness of weight, experience has demonstrated that the wire wheel compares favorably with the wooden wheel. It is claimed that the lightness of the wire wheel is an important factor in reducing the tendency to gyroscopic action, which is always present in wheels running at high speeds.

The number of spokes in each wheel and method of their attachment to the hub and the rim vary according to the ideas of the designers. In some types of wire wheels the rim only is demountable, while other types have all the functions of a demountable rim and a demountable wheel. The Lindsay twin wire wheel (a semi-sectional view of which is shown in Figure 337) is a notable example of the latter type. The component parts of the Lindsay wheel are assembled into two complete self-contained sections or units, hence its name. There are eighty spokes that connect the rim parts and hub parts together. The wheel as a whole is mounted on the inner fixed hub and interlocks with it, also interlocking with the web of the brake drum. The form of structure gives two rows of spokes laced in each side of the wheel, thereby taking care of the side

thrust from either side equally. The tire rim is mounted between the two conical felloe rims of the two wheel sections and is held in place by the rim bolts, thus making it secure. Since the tire rim is secured in place between




Fig. 337 Lindsay Twin Wire Wheel

the two wheel rims by means of rim bolts it is evident that both wheel and tire rims will expand and contract together. By removing the rim bolts with a wrench and taking off the hub dust cap, the outer twin wheel can be dismounted, leaving the inner wheel intact, thereby releasing the tire.

Another type of wire wheel is the Spranger,

a view of which is shown in Figure 338. In this wheel there are 48 spokes interlaced in a simple cross system and equipped with a demountable rim, which like the demountable



Fig. 338 Spranger Wire Wheel

rim on a wooden wheel, can be removed for the changing of the tire. The Spranger wheel itself is not demountable, and when installing these wheels on his car the owner obtains a complete new set of bearings, brake drums, and hub caps. This type of wheel has recently come into extensive use on the Ford and Chevrolet cars. In the construction of the Spranger wire wheel a special type of channel is used. This channel is of structural steel, and is 1½ inches in width by ¾ inch in depth, and into it the spokes are laced. The method of locking the rim to the wheel is as follows: each rim has six steel blocks securely riveted to it, which prevent the rim from rising or losing position, while at the same time there is no wedging action.

In Figure 339 is presented a view of the Houk wire wheel, made by the Wire Wheel Corporation of America.

Each wheel contains 72 steel wire spokes, each of which, before the wheel is assembled, is subjected to a test and must withstand a strain of 3,200 pounds. The spokes are arranged in triple rows as will be seen by the illustration, the triple lacing thus providing a set of spokes to take up the strain from any direction.

One end of each wire spoke is securely riveted to the rim, while the other end is secured to the hub in its proper location also by riveting. It is claimed that the interlacing of the spokes is of such a nature that three-fourths of them are continuously in use, supporting the load by suspension. In case of tire trouble, such as a puncture or blowout, the wheel can be removed in a few minutes

by merely jacking up the car and unscrewing one nut. The wheel with the damaged tire can then be replaced by the extra wheel with a good tire.

Mention has already been made of the increased efficiency of the wire wheel as a tire




Fig. 339 Houk Wire Wheel

cooler, as compared with the wooden wheel. Another point in favor of wire wheels is the small area of spoke surface to be acted upon by the atmosphere in its resistance to the movement of the car. This resistance is always present, and the greater the area of the surface that is presented by a moving body for the atmospheric pressure to act upon, the greater will be the resistance tending to retard that movement.

INDEX

[Note: This index does not aim to give a complete list of subjects treated in *The Automobile Handbook*. The subjects generally are arranged in alphabetical order throughout the book. This index includes the sub-headings under the principal general headings.]

| Pa | ge |
|---|----------------|
| Acetylene gas | 9 |
| | 11 |
| | 9 2 |
| | 16 |
| Air-cooling systems | 5 5 5 |
| | 20 |
| | $\frac{1}{2}$ |
| | $\frac{-}{69}$ |
| | 27 |
| | $\frac{2}{6}$ |
| | <u>-</u> .8 |
| | 15 |
| Table 1 Sur Sur 1 | $\frac{1}{3}$ |
| | 3 8 |
| | 4 0 |
| | - 0 |
| 220110001 22020 38000 | 1 2 9 7 |
| | - • |
| ZZZZZZZZZZZZZZZZZZZZZZZZZZZZZZZZZZZZZZ | 75 |
| 2.4.00 | 42 |
| | 53 |
| 212100 | 67 |
| | 70 |
| 2002 | 77 |
| Domin moderno | 67 |
| omroo dan oor | 81 |
| full floating | 68 |
| | |
| В | |
| D | |
| Ball bearings | 09 |
| Band clutch | 3 2 |
| | 86 |
| Dattolion | 87 |

| a Albama a sa | Page |
|--------------------------------------|------|
| storage | |
| storage, starting and lighting types | |
| Bearing, ball | |
| roller | |
| Bearings, hard and soft | 117 |
| Bendix drive | 125 |
| Berline or berlin | 134 |
| Bevel gear, differential | |
| Bijur equipment | |
| Bodies | |
| classification of | |
| Bosch equipment | _ |
| Bosch magnetos | _ |
| Brakes | |
| proper use of | |
| Brake linings | |
| Brazing | |
| Breakdowns and their remedies | |
| | |
| Chain broken | - |
| Circulating pump leakage | |
| Cranking with safety | |
| Radiator leaking | |
| Rods or links broken | = |
| Trembler blades broken | 65 |
| | |
| C | |
| Cobmiolot | 400 |
| Cabriolet | |
| Camshaft | |
| Carbon deposit | |
| Carburetors, principles of | |
| float feed | |
| Holly, model G | |
| Holly, model H | |
| inspection | |
| Kingston | |
| Krebs | 175 |
| Master | 177 |
| Rayfield | 178 |
| Schebler | 185 |
| spraying | 161 |
| Stromberg | 189 |
| venturi tube | |
| Zenith | |
| Car inspection | |
| | |

| Jamania. | Page |
|---------------------------------|-----------|
| Centrifugal pump | |
| Change speed gearing | 206 |
| Slutch | 230 |
| Slutch troubles | 240 |
| Combustion chamber | 244 |
| Combustion, heat of | 346 |
| commercial car bodies | 136 |
| commercial vehicles | 130 |
| Commutators | 245 |
| compensating joints | 482 |
| compensating joints | 248 |
| omprograd-oir stortors | 565 |
| compressed-air starters | |
| ondenser, use of | 250 |
| one clutch | 233 |
| connecticut ignition system | 381 |
| onstruction of engines | |
| ooling systems | 254 |
| Soupe | 135 |
| | |
| \mathbf{p} | |
| ~ | |
| alton's laws | 262 |
| elco equipment | |
| elco ignition system | 386 |
| ifferential gears | 264 |
| isc valves | |
| isc clutch | 008 |
| | 237 |
| isk clutch | |
| ixie Magnetos | 428 |
| on'ts | 51 |
| ouble-disk friction drive | 209 |
| riving | 42 |
| ry batteries | 87 |
| ry cells for ignition | 59 |
| yneto and Entz equipment | 607 |
| | |
| IE | |
| | |
| isemann magneto | 432 |
| ight-cylinder engine | 308 |
| lectricity, forms of | 274 |
| lectric gear shift | 511 |
| iectric motor vehicles | 516 |
| agines | 278 |
| construction of | _ • - |
| eight and twelve-cylinder types | • |
| eight and twelve-cylinder types | O U O |

| Engines (continued) | Page |
|----------------------------|----------------|
| explosive motors | . 278 |
| four-cycle motor | . 296 |
| fuel consumption | . 301 |
| internal combustion | |
| knight sliding sleeve type | . 303 |
| offset crankshafts | . 284 |
| pistons | . 287 |
| piston displacement | . 289 |
| pistons, length of | . 289 |
| piston materials | . 288 |
| piston position | |
| piston rings | |
| explosive motor engines | . 278 |
| two-cycle motor | |
| | |
| \mathbf{F} | |
| Five-plate clutch | . 239 |
| Float feed carburetor | . 259 . 159 |
| Fluxes for soldering | . 133 . 547 |
| Flywheels | |
| Ford magneto | . 320 . 446 |
| Four-cycle motor | . 296 |
| Friction drive | |
| Fuel consumption | |
| | |
| Fuel feed, vacuum | . 041 |
| \mathbf{G} | |
| Gasoline pipe broken | . 59 |
| Gear changing | |
| Gears | |
| Gears, differential | |
| differential casing | |
| Gear shift, electric | 1 |
| magnetic | - |
| Gearless transmission | |
| Gray & Davis equipment | |
| | |
| H | |
| Horz magnoto | . 448 |
| Herz magneto | |
| Holly carburetor, model G | _ |
| Holly carburetor, Model H | |
| Horsepower | . 350 |

| I | Dame |
|-----------------------------------|------------|
| Ignition commutators | Page 24 |
| Ignition systems | |
| Atwater-Kent | |
| back firing, causes of | |
| induction coil | |
| jump spark coil | |
| secondary spark coil | |
| timing | |
| Ignition, when to advance | |
| | |
| Ignition, when to retard | |
| India rubber | |
| Induction coil | 4 |
| Inspection, carburetor | |
| Internal combustion engines | . 210 |
| J | |
| a | |
| Joints, compensating | . 482 |
| Joints, knuckle | |
| Joints, universal | |
| Jump spark coil | |
| oump space continues | |
| K | |
| Tt | 177 |
| Kingston carburetor | . T(0 |
| Knight sliding sleeve type engine | 400 |
| Knocking, locating cause of | 404 |
| Knuckle joints | . 175 |
| Krebs' carburetor | . 114 |
| L | |
| | |
| Landaulet or landau | . 134 |
| Lighting systems | . 565 |
| Limousine | |
| Lubrication | . 491 |
| Lubricating systems | . 506 |
| force feed | |

force feed and splash

Ford flywheel ofling system

Hancock mechanical oiler

McCord mechanical oiler

Pierce-Arrow oiling system

506

50**6**

501

496

495

500

M

| | rage |
|---------------------------------|------------------|
| Magnetic gear shift | $5\overline{0}9$ |
| | 224 |
| Magnetic transmission | |
| Magneto, Bosch | 411 |
| Dixie | 428 |
| | 432 |
| Eisemann | |
| Ford444, | 446 |
| Herz | 448 |
| | |
| Mea | 453 |
| Remy | 458 |
| Simms | 465 |
| | |
| Splitdorf | 468 |
| U and H | 475 |
| Magneto type ignition system | 405 |
| • | 411 |
| Bosch magnetos | |
| Connecticut | 381 |
| Delco | 386 |
| | 428 |
| Dixie | _ |
| Eisemann Magneto | 432 |
| Ford | 446 |
| | 448 |
| Herz | |
| Magneto type | 405 |
| Mea | 453 |
| | 392 |
| Remy | |
| Remy magneto | 458 |
| Simms | 465 |
| | 468 |
| Splitdorf | |
| U and H magneto | 475 |
| Westinghouse | 396 |
| Westinghouse | 177 |
| Master carburetor | |
| Mea magneto | 453 |
| Miss fire cylinder | 61 |
| WISS HIE CYTHUCI | • - |
| 37 | |
| N | |
| | 000 |
| North East equipment | ozu |
| Nuts and screws, how to loosen | 61 |
| Auts and scrows, now to recomme | _ |
| 0 | |
| U | |
| | 284 |
| Offset crankshaft engines | |
| Overheating | 259 |
| causes of | 259 |
| Causto di | 261 |
| effects of | |
| remedies for | Z 61 |
| Owen magnetic transmission | 225 |
| Owen magnetic transmission | |

| P | |
|-----------------------------|------|
| | Page |
| Passenger bodies | |
| Pistons | |
| Piston displacement | 289 |
| Pistons, length of | |
| Piston materials | |
| Piston position | |
| Piston rings | |
| Pitted valves | |
| Planetary change speed gear | |
| Pounding, causes of | |
| Preignition, causes of | |
| Priming | 62 |
| 75 | |
| ${f R}$ | |
| Radiator leaking | 62 |
| Rayfield carburetor | |
| Remy battery system | |
| Remy equipment | |
| Remy ignition system | |
| Remy magneto | : |
| Reversing | |
| Roadster | |
| Rods or links broken | |
| Roller bearing | |
| Rotary valves | |
| Runabout | |
| Rushmore engine starter | |
| Rushmore equipment | · |
| Rushmore lighting system | |
| Milliammore lighting sheem | 020 |
| S S | |
| | 185 |
| Schebler carburetor | |
| Secondary spark coil | |
| Sedan | |
| Selective sliding gear | |
| Semi-floating rear axle | |
| Skidding | |
| Shop kinks | |
| Simms magneto | |
| Simms-Huff equipment | |
| Sliding gear | |
| Sliding sleeve type engine | 303 |
| Charle Dings | EKA |

| Page |
|-----------------------------------|
| Spark, regulation of |
| Spraying carburetor 161 |
| Specific gravity 655 |
| Speedster or raceabout 133 |
| Splitaorf-Apelco equipment 632 |
| Splitdorf magneto 468 |
| Springs 556 |
| Squeaking springs 65 |
| Starting and lighting systems 565 |
| Allis-Chalmers equipment 569 |
| Auto-Lite equipment 575 |
| Bijur equipment 578 |
| Bosch equipment 583 |
| Compressed-air starters 565 |
| Delco equipment 585 |
| Dyneto and Entz equipment 607 |
| Gray & Davis equipment 610 |
| North East equipment 620 |
| Remy equipment |
| Rushmore equipment 627 |
| Rushmore engine starter 627 |
| Rushmore lighting system 629 |
| Simms-Huff equipment 630 |
| Splitdorf-Apelco equipment 632 |
| U. S. L. equipment 636 |
| Wagner equipment 640 |
| Westinghouse equipment 645 |
| Steering knuckles |
| Stewart vacuum fuel feed tank 327 |
| Storage batteries |
| starting and lighting types 103 |
| Stromberg carburetor |
| TB |
| T. |
| Taxtcab 136 |
| Timing 369 |
| Tires, care and repair |
| Tire vulcanizing |
| Tools, automobile 53 |
| Torpedo 132 |
| Touring car |
| Town car 135 |
| Toy tonneau 132 |
| Transmission, gearless 341 |
| magnetic |

| Transmission (sentiment) | |
|--------------------------------|------------|
| Transmission (continued) | ıge |
| sliding gear | 20 |
| Trembler blades broken | <u>65</u> |
| | 36 |
| <i>9</i> 70 1 44 4 . | 08 |
| | 98 |
| | • |
| ${f U}$ | |
| U and H magneto 4 | 75 |
| | 85 |
| Tigoful hinta | _ |
| | 44 |
| U. S. L. equipment 6 | 36 |
| . $f v$ | |
| | |
| | 27 |
| Valves 6 | 74 |
| | 78 |
| | 78 |
| | 76 |
| | 03 |
| | 84 |
| | 80 |
| | 89 |
| | 87 |
| | 61 |
| | _ |
| Vulcanizing of tires 6 | 66 |
| \mathbf{w} | |
| Wagner equipment 6 | <i>A</i> ∩ |
| | |
| Water circulation | |
| Water circulating pump 5 | |
| Water pump 5 | |
| Welding, autogenous | |
| Westinghouse equipment 6 | |
| Westinghouse ignition system 3 | 96 |
| Wheels 6 | 97 |
| ${f z}$ | |
| Zenith carburetor 2 | ህ 3 |
| ZEHILH CALBUICUL | U |

Books That Really Teach

you the things you want to know, and in a simple, practical way that you can understand

Our illustrated catalogue, which will be sent you free upon request, tells all about the Practical Mechanical Books for



Home Study that we publish There are popular priced books on the operation of trains and station work, practical mechanical drawing and machine designing, pattern making, electrical railroading, power stations, automobiles, gas engines, electrical wiring, armature and magnet winding. dynamo tending, elementary electricity, wireless telegraphy and telephony, carpentry and architecture, concrete construction, plumbing and heating, sign and house painting, amusements, etc., etc.

No matter what your ambition or desire for knowledge

may be, we publish books written by authorities in their different lines that will give you just the training and information that you want and need.

Write today for this up-to-date and complete illustrated catalogue and popular price list. It is free,

FREDERICK J. DRAKE & CO.

PUBLISHERS OF SELF-EDUCATIONAL BOOKS
1006 Michigan Avenue CHICAGO

DRAKE'S MECHANICAL BOOKS

*Title

| Style | Price

Electrical Books

| Electrical Tables and Engineering Data*Lea. | \$1.50 |
|---|---------------|
| Electrical Tables and Engineering | Ψ2.00 |
| Data*Cloth | 1.00 |
| Motion Picture Operation*Lea. | 1.50 |
| Motion Picture Operation*Cloth | 1.00 |
| Alternating Current Lea. | 1.50 |
| Alternating Current Cloth | 1.00 |
| Wiring Diagrams and Descrip- | |
| tions*Lea. | 1.50 |
| Wiring Diagrams and Descrip- | 1.00 |
| tions*Cloth | 1.00 |
| Armature and Magnet Winding*Lea. | 1.50 |
| Armature and Magnet Winding*Cloth | 1.00 |
| Modern Electric Illumination*Lea. | 1.50 |
| Modern Electric Illumination*Cloth | 1.00 |
| Modern Electrical Construction*Lea. | 1.50 |
| Modern Electrical Construction*Cloth | 1.00 |
| Electricians' Operating and Test- | |
| ing Manual*Lea. | 1.50 |
| Electricians' Operating and Test- | |
| ing Manual*Cloth | 1.00 |
| Drake's Electrical Dictionary Lea. | 1.50 |
| Drake's Electrical Dictionary Cloth | 1.00 |
| Electric Motors, Direct and Alter- | |
| nating*Lea. | 1.50 |
| Electric Motors, Direct and Alter- | |
| nating*Cloth | 1.00 |
| Electrical Measurements and Me- | |
| ter Testing Lea. | 1.50 |
| | |

NOTE.—New Books and Revised Editions are marked*

DRAKE'S MECHANICAL BOOKS

*Title | Style | Price

| TM - 4-1-1 | D 1 | C | 1 |
|------------|--------|----------|----------|
| Electrical | DOOKS- | -Contin | uea |

| Electrical Measurements and Meter Testing | Cloth | \$1.00 |
|--|-------|--------|
| Drake's Telephone Handbook | _ | 1.50 |
| Drake's Telephone Handbook | Cloth | 1.00 |
| Elementary Electricity, Up-to- | | |
| Date | Cloth | 1.25 |
| Electricity Made Simple | Cloth | 1.00 |
| Easy Electrical Experiments | Cloth | 1.00 |
| Wireless Telegraph and Telephone | | |
| Handbook | Cloth | 1.00 |
| Telegraphy, Self-taught | Cloth | 1.00 |
| Dynamo-Electric Machines | Cloth | 1.50 |
| Electro-Plating Handbook | Lea. | 1.50 |
| Electro-Plating Handbook | Cloth | 1.00 |
| Modern American Telephony | Lea. | 2.00 |
| Handy Vest-Pocket Electrical Dic- | | |
| tionary | Lea. | .50 |
| Handy Vest-Pocket Electrical Dic- | ••• | |
| tionary | Cloth | .25 |
| Storage Batteries | | _ |
| Elevators—Hydraulic and Electric | Cloth | 1.00 |
| How to Become a Successful Mo- | T | 150 |
| torman | Lea. | 1.50 |
| Motorman's Practical Air Brake Instructor | Lea. | 1.50 |
| Electric Railway Troubles | | |
| Electric Power Stations | | |
| Electrical Railroading | | 3.50 |
| | | |

NOTE.—New Books and Revised Editions are marked*

| DRAKE'S MECHANICAL BOOKS |
|--|
| *Title Style Price |
| Automobile Books |
| Brookes' Automobile Handbook*Lea. \$2.00 |
| Automobile Starting and Light- |
| ing*Lea. 1.50 |
| Automobile Starting and Light- |
| ing*Cloth 1.00 |
| Ford Motor Car and Truck and |
| Tractor Attachments*Lea. 1.50 |
| Ford Motor Car and Truck and |
| Tractor Attachments*Cloth 1.00 |
| Automobile Catechism and Repair |
| ManualLea. 1.25 |
| Practical Gas and Oil Engine |
| HandbookLea. 1.50 |
| Practical Gas and Oil Engine |
| Handbook*Cloth 1.00 |
| Farm Books |
| Farm Buildings, With Plans and |
| Descriptions*Cloth \$1.00 |
| Farm Mechanics*Cloth \$1.00 |
| Traction Farming and Traction |
| Engineering*Cloth 1.50 |
| Farm Engines and How to Run |
| Them |
| Shop Practice Books |
| |
| Twentieth Century Machine Shop |
| Practice |
| Practical Mechanical Drawing Cloth 2.00 |
| Sheet Metal Workers' Manual*Lea. 2.00 |
| Oxy-Acetylene Welding and Cut- |
| tingLea. 1.50 |
| Oxy-Acetylene Welding and Cut- |
| ting*Cloth 1.00 |
| 20th Century Toolsmith and Steel- |
| worker |
| Pattern Making and Foundry |
| Practice Lea. 1.50 |
| Modern Blacksmithing, Horse- |
| shoeing and Wagon Making Cloth 1.00 |
| NOTE.—New Books and Revised Editions are marked* |

DRAKE'S MECHANICAL BOOKS

| *Title Style | Price |
|--|---------------|
| Steam Engineering Books | |
| Swingle's Handbook for Steam Engineers and Electricians*Lea. | \$3.00 |
| Steam Boilers, Construction, Care and Operation*Lea. | 1.50 |
| Complete Examination Questions and Answers for Marine and Stationary Engineers *Lea. | 1.50 |
| Swingle's Catechism of Steam, Gas and Electrical Engineering. Lea. | 1.50 |
| The Steam Turbine, Its Care and Operation | 1.00 |
| Calculation of Horse Power Made Easy | .75 |
| Railroad Books | |
| Modern Locomotive Engineering.*Lea. | \$3.00 |
| Locomotive Fireman's Boiler InstructorLea. | 1.50 |
| Locomotive Engine Breakdowns and How to Repair Them*Lea. | 1.50 |
| Operation of Trains and Station WorkLea. | 2.00 |
| Construction and Maintenance of Railway Roadbed and Track Lea. | 2.00 |
| First, Second and Third Year Standard Examination Ques- | |
| tions and Answers for Locomotive FiremenLea. | 2.00 |
| Complete Air Brake Examination | 9 00 |
| Questions and Answers*Lea. Westinghouse Air Brake System. Cloth | 2.00 2.00 |
| New York Air Brake System Cloth | |
| Walschaert Valve Gear Break- | ∠. 00 |
| downs | 1.00 |
| ···· | |

DRAKE'S MECHANICAL BOOKS *Title | Style | Price

| TILLE | OCH | FIICE |
|--|--------------|--------------|
| Carpentry and Building | Books | |
| Modern Carpentry. Two volumes. | Cloth | \$2.00 |
| Modern Carpentry. Vol. I | Cloth | 1.00 |
| Modern Carpentry. Vol. II | Cloth | 1.00 |
| The Steel Square. Two volumes | Cloth | 2.00 |
| The Steel Square. Vol. I | | |
| The Steel Square. Vol. II | Cloth | 1.00 |
| A. B. C. of the Steel Square | | |
| Common Sense Stair Building and | 4.000 | |
| Handrailing | Cloth | 1.00 |
| Modern Estimator and Contrac- | | 2.00 |
| tor's Guide | *Cloth | 1.50 |
| Light and Heavy Timber Framing | 01041 | 2,00 |
| Made Easy | Cloth | 2.00 |
| Builders' Architectural Drawing | CTOMT | 2.00 |
| Self-taught | Cloth | 2.00 |
| Easy Steps to Architecture | | 1.50 |
| Five Orders of Architecture | | 1.50 |
| Builders' and Contractors' Guide | | 1.50 |
| Practical Bungalows and Cottages | | 1.00 |
| Low Cost American Homes | | 1.00 |
| Practical Cabinet Maker and Fur- | | 7.00 |
| niture Designer | | 2.00 |
| Practical Wood Carving | Cloth | 2.00 1 KA |
| | | |
| Home Furniture Making | CIOM | .00 |
| Concretes, Cements, Mortars, Plasters and Stuccos. | Math | 1.50 |
| Practical Steel Construction | | |
| | CTOUT | .10 |
| 20th Century Bricklayer and Ma- | (IIII | 1 50 |
| son's Assistant | | |
| Practical Bricklaying Self-taught. | | |
| Practical Stonemasonry | | • |
| Practical Up-to-date Plumbing | | T.00 |
| Hot Water Heating, Steam and | | 1 50 |
| Gas Fitting | Cloth | 1.50 |
| Practical Handbook for Mill- | (1) | 0.00 |
| wrights | Cloth | 2.00 |
| Boat Building for Amateurs | Cloth | 1.00 |
| • | | |

NOTE.—New Books and Revised Editions are marked*

| DRAKE'S MECHANICAL BO | OKS |
|--|---------------|
| *Title Style | Price |
| Painting Books | |
| Art of Sign Painting*Cloth | \$3.00 |
| Scene Painting and Bulletin Art *Cloth | 3.00 |
| "A Show at" Sho'Cards Cloth | 3.00 |
| Strong's Book of Designs*Lea. | 3.00 |
| Signist's Modern Book of Alpha- | |
| bets | 1.50 |
| Amateur Artist Cloth | 1.00 |
| Modern Painter's Cyclopedia Cloth | 1.50 |
| Red Book Series of Trade School Manuals— | |
| 1. Exterior Painting, Wood, Iron and Brick Cloth | .60 |
| 2. Interior Painting, Water and | |
| Oil Colors Cloth | .60 |
| 3. Colors | .60 |
| 4. Graining and Marbling Cloth | .60 |
| 5. Carriage Painting Cloth | .60 |
| 6. The Wood Finisher Cloth | .60 |
| New Hardwood Finishing Cloth | 1.00 |
| Automobile Painting*Cloth | 1.25 |
| Estimates, Costs and Profits- | |

NOTE.—New Books and Revised Editions are marked*

House Painting and Interior

| | · ••• | |
|---|----------|-------------|
| DRAKE'S HOME-STUDY | BO | OKS |
| •Title | Style | Price |
| General Instruction and Referen | ence B | ooks |
| Putney's Law Library (12 volumes)Buc | kram \$(| 60.00 |
| Bookkeeping Self-taught | | |
| Complete Courses in Bookkeeping, Including Blank Books and | | |
| Supplies | Cloth | 7.50 |
| Elementary Chemistry Self-taught | Cloth | 1.00 |
| Picture Making for Pleasure and | | |
| Profit | Cloth | 1.25 |
| Complete Courses in Civil Service. | Cloth | 1.25 |
| Felt's Parliamentary Procedure | Cloth | .60 |
| McClure's Horse, Cattle and Sheep Doctor | Cloth | 1.25 |
| Practical Lessons in Hypnotism and Magnetism | Paper | .50 |
| Practical Lessons in Hynotism | | 1.00 |
| and Magnetism | | |
| Chadman's Dictionary of Law | _ | |
| Modern Magician's Handbook | Cloth | 1.50 |
| White House Handbook of Ora- | C1 - 41- | 1 00 |
| tory | | |
| Standard Cyclopedia of Receipts. | Cloth | 1.25 |
| American Star Speaker and Elo- cutionist | Cloth | 1 95 |
| Swimming and Life Saving | | |
| Words as They Look (Webster's | 1 aper | ·JV |
| System of Memorizing Easy | | |
| and Difficult Words) | Cloth | .50 |

NOTE.—New Books and Revised Editions are marked*

1.00

Astrology (Were You Born Under a Lucky Star?)................ Cloth

| DRAKE'S HOME-STUDY BOOKS *Title Style Price |
|--|
| General Instruction and Reference Books |
| Ropp's Calculator— |
| Style A. Large SizeMoroccoline 1.25 |
| Style B. With FlapLeather 1.00 |
| Style C. Pocket SizeMoroccoline .50 |
| Style D. Vest PocketLeather50 |
| Albertus Magnus (Egyptian Se- |
| crets) |
| Sixth and Seventh Books of Moses. Cloth 1.00 |
| Drinks as They Are Mixed Cloth .25 |
| Drinks as They Are Mixed Lea50 |
| Guide to Successful Auctioneering. Paper .25 |
| Safe Methods of Stock Specula- |
| tion |
| Gypsy Witch Fortune Telling |
| CardsPer Pack .50 |
| Mrs. Parker's Monologues and Plays |
| Monologues, Stories, Jingles and |
| Plays*Cloth \$1.00 |
| New Monologues and Dialect Sto- |
| ries |
| Mary Moncure Parker's Plays- |
| Powder and Patches Paper .25 |
| When Your Wife's Away Paper .25 |
| Love Behind the Scenes Paper .15 |
| Mrs. Gadabout's Busy Day Paper .15 |
| Black Art Paper .15 |
| A Day at the Know-It-All |
| Woman's Club |
| The Rehearsal |
| The Princess Innocent Paper .15 |
| A Quiet Evening at Home Paper .15 |
| A Colonial Dream |
| NOTE.—New Books and Revised Editions are marked* |

•

DRAKE'S POPULAR HANDBOOKS *Title Prices

| | | 1000 |
|--|----------------|------------------|
| Speakers | loth | Paper |
| Comic Recitations and Readings | | \$0.25 |
| Conundrums and Riddles | | .25 |
| Complete Debaters' Manual | .50 | |
| McBride's Latest Dialogues | .50 | |
| Little Folk's Dialogues and Dra- | | |
| mas | .50 | .25 |
| Little Folk's Speaker and Enter- | | |
| tainer | .50 | .25 |
| Patriotic Readings and Recitations | .50 | .25 |
| Toasts and After Dinner Speeches | .50 | .25 |
| Practical Ventriloquism | .50 | .25 |
| Etiquette and Letter Wri | ters | |
| Because I Love You | | \$0.25 |
| Practical Etiquette and Society | | V 0 1 2 0 |
| Guide | .50 | .25 |
| Brown's Business Letter Writer | | |
| and Social Forms | .50 | .25 |
| North's Book of Love Letters and | 50 | OE. |
| How to Write Them | .50 | .25 |
| Modern Quadrille Call Book and Complete Dancing Master | .50 | .25 |
| Standard Drill and Marching Book | | |
| | | |
| Card and Sleight of Hand | Book | S |
| Card Sharpers—Their Tricks Ex- | 00 F0 | 40.0 5 |
| posed | 5 0. 50 | \$0.25 |
| The Book of Card Tricks and Sleight of Hand | .50 | .25 |
| Card Tricks—How to Do Them | | |
| Tricks with Coins | | |
| The Expert at the Card Table | | |
| Hermann's Book of Magic and | .00 | .20 |
| Black Art | .50 | .25 |
| | | |

Frederick J. Drake & Cempany's

CATALOGUE OF

Standard Up-to-Date Hand Books on the following Subjects:


Dialogues, Recitations, Tableaux,
Charades, Pantomimes, Mock Trials,
Monologues, Drills, Marches, Minstrel
and Entertainment Books, Magic,
Palmistry, Hypnotism, Black Aft,
Electricity, Speakers, Poultry,
Letter Writers, Dream Books,
Fortune Tellers, Popular Dramas,
Photography, Etiquette, Dancing,
Etc., Etc., Etc., Etc.

Each book in this list is the work of a competent specialist, and will be found reliable,

Any Book Advertised in This Catalogue Sent Postpaid, on Receipt of Price. FREDERICK J. DRAKE & CO.

Twentieth Century Machine Shop Practice

By L. ELLIOTT BROOKES



practical work published on modern machine shop practice. This book is intended for the practical instruction of Machinista, Engineers and others who are interested in the use and operation of the machinery and machine tools in a modern machine shop; The first portion of the book is devoted to practical examples in Arithmetic, Decimal Fractions, Roots of Numbers, Algebraic Signs and Symbols, Reciprocals and Logarithms of Numbers, Practical Geometry and and Mensuration. Also Applied Mechanics—which includes: The lever, The wheel and pinion, The pulley, The inclined planes, The wedge The, screw and safety valve—Specific gravity and the velocity of falling bodies—Friction, Belt Pulleys and Gear wheels.

Properties of steam, The Indicator, Horsepower and Electricity.

The latter part of the book gives full and complete information upon the following subjects: Measuring devices, Machinists' tools, Shop tools, Machine tools, Boring machines, Boring mills, Drill presses, Gear Cutting machines. Gvinding Machines, Lathes and Milling machines. Also auxiliary machine tools, Portable tools, Miscellaneous tools, Plain and Spiral Indexing machines, Notes on Steel. Gas furnaces, Shop talks, Shop kinks, Medical Aid and over Fifty tables.


The book is profusely illustrated and shows views of the latest machinery and the most up-to-date and improved belt and motor-driven machine tools, with full information as to their use and operation. It has been the object of the author to present the subject matter in this work in as simple and not technical manner as is possible.

12mo, cloth, 636 pages, 456 fine illustrations, price, \$2.00

Sold by Booksellers generally, or sent postpaid to any address upon receipt of Price by the Publishers

FREDERICK J. DRAKE & CO. PUBLISHERS CHICAGO, U. S. A.

The Practical Gas & Oil Engine HAND-BOOK



A MANUAL of useful information on the care, maintenance and repair of Cas and Oil Engines.

This work gives full and clear instructions on all points relating to the care, maintenance and repair of Stationary, Portable and Marine, Gas and Oil Engines, including How to Start, How to Stop, How to Adjust, How to Repair, How to Test.

Pocket size, 4x6%.

232 pages. With numerous rules and formulas and diagrams, and over 70 illustrations by L. Elliott Brookes, author of the "Construction of a Gasoline Motor," and the "Automobile Hand-Book."

This book has been written with the intention of furnishing practical information regarding

gas, gasoline and kerosen's engines, for the use of owners, operators and others who may be interested in their construction, operation and management.

In treating the various subjects it has been the endeavor to avoid all technical matter as far as possible, and to present the information given in a clear and practical manner.

16mo. Popular Edition—Cloth. Price...........\$1.00 Edition de Luxe—Full Leather Limp. Price....... 1.50

Sent Postpaid to any Address in the World upon Receipt of Price

FREDERICK J. DRAKE & CO.

PUBLISHERS

